

Compatible with the following models:

ELECTROLUX	B2280 BOSS UPRIGHT
ELECTROLUX	B2283 BOSS UPRIGHT
ELECTROLUX	B2285 BOSS
ELECTROLUX	B2286 BOSS
ELECTROLUX	E82n THE BOSS
ELECTROLUX	Z2250 POWERLITE
ELECTROLUX	Z2252
ELECTROLUX	Z2255
ELECTROLUX	Z2256
ELECTROLUX	Z2270 BOSS
ELECTROLUX	Z2271 BOSS STAIRMASTER
ELECTROLUX	Z2272 BOSS
ELECTROLUX	Z2273 / 74 THE BOSS
ELECTROLUX	Z2901 HILIGHT
ELECTROLUX	Z2905 HILIGHT
ELECTROLUX	Z2910 HILIGHT HARMONY
ELECTROLUX	Z2911 HI-LIGHT
LG	TB-U55 SLIMAX
LG	UR-B UPRIGHT
LG	UVC545 1400
LG	VU5545 SLIMAX
LG	VU5565 UPRIGHT
LG	VUP545 (Tesco)
MORPHY	
RICHARDS	733 ULTRALIGHT
PANASONIC	MC-E40
PANASONIC	MC-E41
PANASONIC	MC-E42
PANASONIC	MC-E43
PANASONIC	MC-E44
PANASONIC	MC-E45
PANASONIC	MC-E46
PANASONIC	MC-E47
PANASONIC	MC-E53
PANASONIC	MC-E54
PANASONIC	MC-E55
PANASONIC	MC-E450
PANASONIC	MC-E451
PANASONIC	MC-E452
PANASONIC	MC-E455 UPRIGHT
PANASONIC	MC-E458 UPRIGHT
PANASONIC	MC-E459 UPRIGHT
PANASONIC	MC-E461
PANASONIC	MC-E465
PANASONIC	MC-E468 UPRIGHT
PANASONIC	MC-E469 UPRIGHT
PANASONIC	MC-E480E
PANASONIC	MC-E540
PANASONIC	MC-E553
PANASONIC	MC-E554
PANASONIC	MC-E555
PANASONIC	MC-E556

PANASONIC	MC-E561 UPRIGHT
PANASONIC	MC-E564 UPRIGHT
PANASONIC	MC-E566 UPRIGHT
PANASONIC	MC-E567 UPRIGHT
PANASONIC	MC-E568 UPRIGHT
PANASONIC	MC-E569 UPRIGHT
PANASONIC	MC-E581 ICON
PANASONIC	MC-E582 ICON
PANASONIC	MC-E583 ICON
PANASONIC	MC-E3001
PANASONIC	MC-E3002WP47 New 4.1 ltr
PANASONIC	MC-E3011RP47
PANASONIC	MC-E3011WP47 2000W
PANASONIC	U20 Bag Ref
PANASONIC	U2R
PANASONIC	Z2275
SANYO	A5A UPRIGHT
SANYO	SC-A42 UPRIGHT
SANYO	SC-A5A UPRIGHT
SANYO	SC-A6A UPRIGHT
SANYO	SC-A6N UPRIGHT
SANYO	SC-PU1 UPRIGHT
SANYO	SC-U8 UPRIGHT
SANYO	SC-U9 UPRIGHT
SANYO	SC-U11 UPRIGHT
SHARP	EC-12S 30 UPRIGHT
SHARP	EC-12S 50 UPRIGHT
TRUVOX	COMMERCIAL VALET UPRIGHT
VACLENSA	PRO UPRIGHT