



smart easy 1 LEARNING

UNIVERSAL

Fernbedienung

Remote Control

Telemando

Télécommande

Telecommando

Afstandsbediening

Távíráyító

• **Optimal für TV und
Digital-Receiver**

• Einfach zu bedienen

• Große Tasten mit Klick-Effekt

• Direkte Bedienung der
Alltags-Funktionen

• Ideal für Senioren und Kinder

• **Optimal for TV and
Digital-Receivers**

• Easy to use

• Big Buttons with Click-Effect

• Direct Operation of
Everyday Functions

• Ideal for Elderly People
and Children

Klon-Funktion integriert
Clone-Function integrated

USER INSTRUCTIONS

**smart easy 1**

INTRODUCTION

Classic **smart easy 1** is a learning universal remote control. It is able to learn and store infrared commands from an original remote control.

19 big buttons are labeled with the most common everyday functions of TV-Sets and Digital-Receivers.

smart easy 1 is ideal für nursing homes, hotels, hospitals but also for private homes for elderly people and children. It can also be used for other devices provided they use infrared signals.

Functions of an already programmed **smart easy 1** can be transferred to another smart easy 1. (Clone-Function)

INSERTING BATTERIES

Your new **smart easy 1** remote control requires 2 Alkaline Batteries (LR03/AAA). Please use only batteries of same type.

The correct polarity is shown inside the battery compartment.

LOW BATTERY WARNING

If the batteries in **smart easy 1** get weak, the red LED is blinking several times after pressing any button. You should now replace the batteries. Please dispose of used batteries according to local laws.

BASICS

Your new **smart easy 1** remote control is supplied non-programmed.

Prior to the first use **smart easy 1** has to learn the desired functions (commands) of your original remote control. Your original remote control you still work properly.

Learned commands don't get lost when batteries get weak or taken out for replacement.



smart easy 1 stores all settings in a non-volatile memory.

A) LEARN-MODE

1. Place **smart easy 1** and Original Remote control head to head (distance approx. ca. 3cm)

smart easy 1

Original Remote Control (example)



2. Press *** + #** simultaneously for min. 3 seconds until the red LED is permanently on.

smart easy 1 is now in the programming-mode.

3. Now press button on smart easy 1 you want to program (target button). The LED blinks 1x and lights on permanently.

smart easy 1 is now in the receiving-mode.

4. Press the button on the original remote control you want to learn (source button) for approx. 3 seconds. The LED blinks 1x and remains on. Command is learned. To learn further functions repeat 3. and 4.

Error message: LED blinks 5x and remains on. Learning failed. Please repeat 4.

5. Press *** + #** simultaneously for min. 3 seconds. LED blinks 3x. **smart easy 1** stores all learned functions and can be used now. Note: If in learn-mode no button is pressed within 30 seconds smart easy 1 returns to normal mode without any changes.

B) ERASING ALL BUTTONS

1. Press *** + #** simultaneously for min. 3 seconds. Red LED lights on permanently.

2. Press **4 + 6** simultaneously for min. 3 seconds. LED blinks 2x. All Buttons are erased now.

3. Press *** + #** simultaneously for min. 3 seconds. LED blinks 3x. **smart easy 1** returns to normal mode.

C) Erasing SINGLE BUTTON

1. Press *** + #** simultaneously for min. 3 seconds. Red LED lights on permanently.

2. Press the button you want to erase for min. 3 seconds. LED blinks 2x. Button is erased now.



3. Press *** + #** simultaneously for min. 3 seconds. LED blinks 3x. **smart easy 1** returns to normal mode.

D) CLONE MODE

1. Place the programmed **smart easy 1** (transmitter) and the **empty smart easy 1** (receiver) head to head (distance approx. ca. 3cm).

smart easy 1 (receiver)

smart easy 1 (transmitter)



2. Press *** + #** on the transmitter simultaneously for min. 3 seconds. Red LED lights on permanently.

3. Press *** + #** on the receiver simultaneously for min. 3 seconds. LED blinks 1x and remains permanently on.

4. Press **1 + 3** on the receiver simultaneously for min. 3 seconds.. LED blinks 1x and remains permanently on.

5. Press **1 + 3** on the transmitter simultaneously for approx. 1 second.

LEDs on transmitter and receiver blink in the rythm of data transfer until the cloning is finished.

This procedure can last for up to 30 seconds. Please don't move transmitter and receiver as long as the data transfer is running. To finalize clone mode:

6. Press *** + #** on the receiver simultaneously for min. 3 seconds. LED blinks 3x. **smart easy 1** stores all cloned functions and can be used now.

7. Press *** + #** on the transmitter simultaneously for min. 3 seconds. LED blinks 3x. **smart easy 1** returns to normal mode.



smart easy 1
LEARNING

UNIVERSAL

Fernbedienung

Remote Control

Telemando

Télécommande

Telecomando

Afstandsbediening

Távíráyító

benötigte Batterien:
batteries required:

AAA LR03

1.5V Alkaline

Art.-No. 84007



Classic Service Parts GmbH

64385 Reichelsheim · Germany

www.classic-serviceparts.com



WEEE-Reg.
DE91546912



D

- Lernt Infrarot Signale aller Marken
- Für Alltagsfunktionen von TV und Digital-Receiver
- Einfache Bedienung durch große und übersichtliche Tasten
- Unkomplizierte Lernmethodik

GB

- Learns Infrared Signals of all Brands
- For Everyday Functions of TV and Digital-Receivers
- Easy Operation due to big and clearly arranged Buttons
- Uncomplicated Learn Method

E

- Aprende señales infrarojas de todas las marcas
- Para las funciones diarias de televisión y receptor digital
- De manejo sencillo gracias a sus grandes teclas
- De fácil aprendizaje

F

- Détecte et mémorise tous les signaux infrarouges de toutes les marques.
- Pour toutes fonctions génériques TV et récepteur numérique.
- Utilisation simple par touche grande taille ergonomique
- Méthode d'apprentissage très simple

I

- Apprende il segnale ad infrarossi di tutte le marche
- Comanda le principali funzioni quotidiane del TV e del ricevitore digitale
- Di facile utilizzo grazie ai tasti grandi
- Facile programmazione mediante autoapprendimento

P

- Grava os sinais infravermelhos de todas as marcas
- Para todas as funções básicas de TV e Receptores Digitais
- Fácil de utilizar, graças às teclas grandes e bem posicionadas
- Fácil de aprender

NL

- Leert infrarood signalen van alle merken
- Voor de dagelijks gebruikte functies van TV en Digital Receiver
- Eenvoudige bediening door grote en overzichtelijke toetsen
- Eenvoudige leermethode

H

- Minden márka infravörös parancsait betanulja
- TV és digitális vevőkészülékek hétköznapi funkcióihoz egyszerű kezelés nagy és áttekinthető gomboknak köszönhetően
- Egyszerű tanulási mód