



**2GB microSD memory card with adapter**

**Part no. MEMORY-SDU-A1**  
**Catalog No. 191087**  
**Alternate Catalog No. MEMORY-SDU-A1**

Similar to illustration

## Delivery program

|              |  |  |
|--------------|--|--|
| Accessories  |  | Memory cards   |
|              |  | For storage of programs, data, recipes                                   |
| Description  |  | Micro SD memory card 2 GB with I-grade adapter, without operating system |
| For use with |  | XC300<br>XV300<br>easyE4   |

## Technical data ETIM 7.0

|   |       |         |
|---|-------|---------|
| PLC's (EG000024) / PLC memory card (EC000192)   |       |         |
| Electric engineering, automation, process control engineering / Control / Programmable logic control (SPS) / SPS memory unit (ecl@ss10.0.1-27-24-22-12 [AKE535014]) |       |         |
| Type of memory  |       | Other   |
| Memory size   | kByte | 2000000 |

## Assets (links)

### Manuals

- MN048017\_DE (German)
- MN048017\_EN (English)
- MN050005\_DE (German)
- MN050005\_EN (English)

## Additional product information (links)

|  |   |
|--|---|
| <b>manual modular control XC300 (MN050005)</b>         |   |
| Modularsteuerung XC300 – Handbuch (MN050005) - Deutsch | <a href="ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN050005_DE.pdf">ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN050005_DE.pdf</a> |
| manual modular control XC300 (MN050005) - English      | <a href="ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN050005_EN.pdf">ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN050005_EN.pdf</a> |
| <b>Manual multi-touchpanel XV300 MN048017</b>          |   |
| Handbuch Multi-Touch-Panel XV300 MN048017 - Deutsch    | <a href="ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN048017_DE.pdf">ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN048017_DE.pdf</a> |
| Manual multi-touchpanel XV300 MN048017 - English       | <a href="ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN048017_EN.pdf">ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN048017_EN.pdf</a> |
| <b>easyE4 (MN050009) manual</b>                        |   |
| easyE4 – Handbuch (MN050009) - Deutsch                 | <a href="ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN050009_DE.pdf">ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN050009_DE.pdf</a> |
| easyE4 (MN050009) manual - English                     | <a href="ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN050009_EN.pdf">ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN050009_EN.pdf</a> |
| Manuale easy E4 (MN050009) - italiano                  | <a href="ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN050009_IT.pdf">ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN050009_IT.pdf</a> |
| instrukcja easyE4 (MN050009) - polski                  | <a href="ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN050009_PL.pdf">ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN050009_PL.pdf</a> |