


PRO-ELEC



Heated Towel Rail

Model: PEL00499

Please read these instructions carefully before use and retain for future reference.

IMPORTANT SAFETY INFORMATION

- When using electrical appliances basic safety precautions should always be followed.
- Check that the voltage indicated on the rating plate corresponds with that of the local network before connecting the appliance to the mains power supply.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge. They should be given supervision and instruction in the use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- If the supply cord is damaged, it must be replaced by a qualified engineer in order to avoid a hazard.
- **WARNING:** In order to avoid a hazard for very young children, this appliance should be installed so that the lowest heated rail is at least 600mm above the floor.
- Ensure that there is sufficient ventilation around the appliance to allow the escape of heat.
- Do not immerse the appliance in water or any other liquid.
- This appliance contains no user-serviceable parts. All repairs should only be carried out by a qualified engineer. Improper repairs may place the user at risk of harm.
- Do not operate the appliance after a malfunction or if it has been dropped or damaged in any way.
- The appliance must be unplugged from the power supply, while any maintenance, such as cleaning, is being carried out.
- Do not use the appliance for any purpose other than that for which it is designed.
- Ensure that the supply cord is kept away from heat or sharp edges that could cause damage.

- This appliance is intended for domestic use only. It should not be used for commercial purposes.
- Do not place too many towels on the rail at once.
- The towel rail's bars are heated. Handle with caution when switched on or just after switching off.

WHAT'S INCLUDED

- Heated towel rail.
- Bag of fastenings including 4 screws, 4 wallplugs and 4 brackets.

WALL MOUNTING

- Drill four holes at the corners of a 560 x 325mm rectangle.
- Place the wallplugs in the holes.
- Insert the screws into the brackets, then screw into the wallplugs, making sure you leave 4mm between the screw head and the start of the bracket.
- Attach the towel rail by inserting the upper and then the lower screws into the notches at the back of the appliance.

IMPORTANT:

- The wallplugs supplied with this product are designed to attach the bracket to solid walls and require a hole to be drilled. For hollow walls or other wall types, use a suitable alternative fixing.
- Do not mount the appliance over a source of heat or moisture.

OPERATION

- Plug in the power cable.
- Press the switch. The indicator light will turn on, indicating that the appliance is on.
- Place your towels on the heating bars.
- Press the switch again when you want to turn off the appliance. The indicator light will turn off.

CLEANING & MAINTENANCE

- Unplug the appliance and wait for it to cool completely before cleaning.
- Clean with a soft damp cloth.
- Do not use any chemicals, abrasives or solvents that could damage the appliance.

TECHNICAL SPECIFICATION

- Power supply: 220-240V~50Hz
- Power consumption rating: 65W



INFORMATION ON WASTE DISPOSAL FOR CONSUMERS OF ELECTRICAL & ELECTRONIC EQUIPMENT.

When this product has reached the end of its life it must be treated as Waste Electrical & Electronics Equipment (WEEE). Any WEEE marked products must not be mixed with general household waste, but kept separate for the treatment, recover and recycling of materials used. Contact your local authority for details of recycling schemes in your area.



Made in China. PR2 9PP

Man Rev 1.1