PRO-SIGNAL	PRO-SIGNAL	PRC
PSG3413-M293 WIRELESS NOISE CANCELLING HEADPHONES	PSG3413-M293 WIRELESS NOISE CANCELLING HEADPHONES	PSG3413-M29 WIRELES CANCEL
 DEFENSION Turn on/off: Press and hold Þil for 3 seconds. The blue & red LED will flash. From your source device search for wireless device "PSG3413-M293" to connect. No pass required. Use "0000" if your device demands one. The blue LED flashes slowly when connected. Play/pause: Short press Þil to play/pause music. Call answer : Short press Þil button again in standby or during music-play mode. Call nedia last number: Press the Þil button twice in standby or music-play mode. Volume: Long press + or - to increase or reduce the volume. Next/last song: Short press + or - to play next or last song. Noise Cancel Function: Short press O button to turn ANC mode on or off. When on, green LED is lit. Charging: Insert the charge cable to the micro 	SAFETY WARNINGS Keep the headphone clean and dust free or the sound quality may be reduced. Do not subject the headphones to impact or excessive vibration. Do not allow water or other liquids to enter the headphones. Be aware that wearing for long periods and at high volume may cause fatigue and hearing damage.	
USB slot, the red LED will light. It will extinguish when fully charged. External Audio Input: In power on mode, plugging in an external source automatically switches to AUX mode.	33	Σ

D-SIGNAL

293 **ESS NOISE** LLING HEADPHONES



MADE IN CHINA PR2 9PP

PRO-SIGNAL

PSG3413-M293 WIRELES NOISE CANCELLING HEADPHONES

- SPECIFICATIONS USB charge: DC 5V Wireless frequency: 2.401-2.480GHz Wireless distance: ≤10 meters Frequency: 20Hz-20KHz Output power: 30mW SNR: ≥75dB Charging time: <2.5 hours

- Charging time: <2.5 hours
 Active noise reduction: 15-20dB