

SPARE PARTS LIST

MODEL NO. 8443D

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	183208-2	HOUSING SET 8443D INC. 20,21	1	
002	853585-3	NAME PLATE 8443D	1	
003	266130-9	*TAPPING SCREW BIND 3X 16 10PK6313DW	8	
004	344391-2	BIT HOLDER 6313DW/8413D-43D	2	
005	654168-0	SPRING TERMIANL (+) 6313DW/8418413-43D	1	
006	654169-8	SPRING TERMINAL (-) 6313D/SC16	1	
007	687085-9	HOLDER 6313DW/8413D-43D/UB120D	1	
008	651968-9	SWITCH 6343DW/8413D-43D/SC161	1	
009	416079-5	F/R CHANGE LEVER 6313DW/8413D	1	
010	125091-1	SPEED CHANGE LEVER ASSY 8413D	1	
011	251464-3	*SPECIAL BOLT M6X22 LTH 5PK	1	
012	193550-3	KEYLESS CHUCK 13 SINGLE ACTION	1	
013	125165-8	GEAR ASSY 8413D/33D/43D	1	
014	629729-5	DC MOTOR 6343DW/8443DW INC. 16,17	1	
015	911006-2	*PAN HD SCREW M3X8 10PK W. SPRING WASHERS	1	
016	191971-3	CARBON BRUSH SET CB-430 8413D-43D/6317-47D	1	
017	643954-4	HOLDER CAP 8413D/33D/43D/BHP46SC161D	2	
018	266134-1	*TAPPING SCREW ST 4 X 8 5PK	3	
019	265999-8	*PT SCREW 4X25 10PK	4	
020	183208-2	HOUSING SET 8443D INC. 1,21	1	
021	819063-3	MAKITA LABEL 500 4305/HR160DW 6313DW/6704D/05D/HR2432	1	
A01	122576-8	STOPPER POLE ASSY 6343DW/8413DBHP451	1	
A02	824626-2	PLASTIC CASE 8414/34/44/6336	1	
A03	414938-7	BATTERY COVER UC120DW/VR250DW 5093DW/LS800DWB	2	
A04	784637-8	*45mm DOUBLE-END PH 2 x SLOT 6	2	
A05	122575-0	GRIP ASSY 6343DW/8413D-43D	1	
A06	193061-8	BATTERY 1835 SET	1	

SERVICE DRAWING

MODEL NO. 8443D

