

OC 3

Leave the dirt where you found it, with the Kärcher OC 3 Portable Cleaner. The ideal solution for on-the-go cleaning of bikes, boots and outdoor equipment.



Order no. 1.680-019.0

- Very compact, easy-to-carry and easy-to-store cleaning device
- Mobile, independent cleaning thanks to the integrated battery and removable water tank

Technical data

EAN code		4054278636344
Pressure range		Low pressure
Flow Rate	l/min	max. 2
Battery powered devices		1
Battery Type		Lithium ion battery
Battery running time	min	15
Battery charging time	min	180
Weight without accessories	kg	2.2
Weight incl. packaging	kg	3
Dimensions (L × W × H)	mm	277 × 234 × 201

Equipment

Water tank volume	l	4
Lithium ion battery		■
Spiral hose	m	2.8
Flat jet nozzle		■
Device filter		■
Battery charging cable		■
Integrated water filter		■

■ included in delivery.



Compact design

- Convenient storage of the spiral hose and trigger gun under the removable water tank.
- Easy to transport, with space-saving storage.



Integrated lithium-ion battery

- Cleaning independent of a power source.
- Long battery runtime, meaning it can be used several times before it must be recharged. The LED warns you when the battery is low.



Efficient, but gentle low pressure

- Low pressure offers the advantage of cleaning that is both efficient and extremely gentle at the same time.
- The standard nozzle with a flat spray enables you to watch the dirt wash away. The cone-spray nozzle is ideal for more sensitive cleaning like dog paws.

EQUIPMENT FOR OC 3

1.680-019.0



		Order no.	Description	
MOBILE OUTDOOR CLEANER				
Car adapter	1	2.643-876.0	Always enough power on the road: With the car adapter, the OC 3 Outdoor Cleaner can be conveniently operated via the car battery.	<input type="checkbox"/>
Adventure Accessory Box	2	2.643-857.0	With the Adventure box's accessories, outdoor equipment can be cleaned effortlessly, anywhere. Ideal for anyone who is on the road a lot.	<input type="checkbox"/>
Bike Accessory Box	3	2.643-858.0	The bike accessory box has the perfect set of accessories for cleaning bicycles and bicycle equipment.	<input type="checkbox"/>
Pet Accessory Box	4	2.643-859.0	With the Pet box's optimally tailored accessories, pets and dog paws can be cleaned effortlessly, anywhere.	<input type="checkbox"/>
Universal brush	5	2.643-870.0	The universal brush is mounted onto the trigger gun of the portable cleaner, to help you remove stubborn dirt while protecting delicate components.	<input type="checkbox"/>
Suction hose	6	2.643-871.0	The suction hose for the portable cleaner enables the use of alternative water sources like water canisters and buckets.	<input type="checkbox"/>
Detail nozzle	7	2.644-125.0		<input type="checkbox"/>
Microfibre cloth	8	2.643-872.0	The high-quality fleece microfibre cloth enables you to quickly dry objects you have cleaned before they are stored away or placed in your car.	<input type="checkbox"/>
Cone-spray nozzle	9	2.643-875.0	Clean your pet quickly and easily with the cone spray nozzle. It can be attached to the trigger gun of the portable cleaner and produces a gentle shower stream.	<input type="checkbox"/>
Viscose towel	10	2.643-873.0	The Viscose towel is a special microfibre cloth for drying off dogs. It absorbs a lot of water and eliminates unpleasant odours.	<input type="checkbox"/>
Fur cleaning brush	11	2.643-874.0	For thoroughly brushing animal fur: the fur-cleaning brush removes even stubborn dirt from fur.	<input type="checkbox"/>
Splash guard *INT	12	2.644-169.0		<input type="checkbox"/>
VEHICLE MAINTENANCE				
Bike Cleaner	13	6.295-763.0	Gently and effectively remove dirt such as brake dust, tyre wear, insects, mud and oil with the Kärcher bike cleaner. It's sticky gel formula makes it simple to use.	<input type="radio"/>

■ Included in delivery. ☐ Available accessories. ☐ Detergent.