

Switching Regulator Series

Synchronous Buck-Boost DC/DC Converter BD83070GWL Evaluation Board

BD83070GWL-EVK-002

Introduction

This application note will provide the steps necessary to operate and evaluate ROHM's synchronous buck-boost DC/DC converter using BD83070GWL evaluation board. Component selection and operating procedures are included.

Description

The BD83070GWL converter is a power supply solution designed for battery powered devices. It can operate at pulse frequency modulation (PFM) to suppress loss and current consumption during light load which has 2.8 μ A quiescent current at no load. Capable to support up to 1A output on pulse width modulation (PWM) and provides high efficiency for heavy load. It is possible to disable auto-PFM/PWM mode by via MODE pin. User can select from 2 preset output voltage via VSEL pin and it changes between buck and boost operations depending on the relation between input voltage and output voltage.

Application

Single Cell Li-ion or 3 Cell NiMH Battery-Powered Portable Products
Tablet Terminal Device
Smartphone

Features

Automation PFM/PWM Mode and Fixed PWM Mode
Input Voltage Range : 2.0 V to 5.5 V
Output Current : Up To 1 A ($V_{IN} > 2.7$ V, $V_{OUT} = 3.3$ V)
Selectable Output Voltage : 2.5 V or 3.3 V
Efficiency : Up To 95 %

Switching Frequency : 1.5 MHz(Typ)
Quiescent V_{IN} Current : 2.8 μ A(Typ)
UCSP50L1C package (1.20 mm $\times$ 1.60 mm $\times$ 0.57 mm)
UVLO Detection : 1.61 V(Max)
Built-in Thermal, Over Voltage, And Over Current Protection

Evaluation Board Operating Limits

Parameter	Symbol	Limit			Unit	Conditions
		MIN	TYP	MAX		
Supply Voltage	V_{IN}	2.0	-	5.5	V	
Output Current	I_{OUT}	1	-	-	A	$V_{IN} > 2.7$ V, $V_{OUT} = 3.3$ V

Evaluation Board

Material of PCB: FR-4
 Number of Layer: 4
 PCB thickness: 1.6mm




Figure 1. BD83070GWL Evaluation Board

Board Schematic




Figure 2. BD83070GWL Evaluation Board Schematic

Output Voltage Settings

Below is a table of output voltages selectable using VSEL pin.

VSEL Pin	VOUT
HIGH ($\geq V_{IN}-0.3\text{ V}$)	3.3V
LOW ($\leq 0.3\text{ V}$)	2.5V

Table 1. Output Voltage Settings

Operation State Settings

Below is a table of BD83070GWL Condition selectable using EN pin.

EN Pin	BD83070GWL Condition
HIGH ($\geq 1.2\text{ V}$)	Enable
LOW ($\leq 0.4\text{ V}$)	Shutdown

Table 2. EN Pin Settings

Operation Mode Settings

Below is a table of operation modes selectable using MODE pin.

MODE Pin	MODE
HIGH ($\geq 1.2\text{ V}$)	Forced PWM
LOW ($\leq 0.4\text{ V}$)	Automatic PFM-PWM

Table 3. MODE Pin Settings

Evaluation Board BOM

Below is a table showing the Bill of Materials. Part numbers and suppliers are included.

Reference	Part Number	Manufacturer	Description [Unit: inch (mm)]	Qty.
CIN1	GRM158R61A226ME15D	Murata	22 μ F, 15V, X5R, 0402 (1005)	1
CIN2	-	-	-	1
CIN3, COUT2, COUT3	-	-	-	3
VIN_S, VOUT_S	CONSMB001-G	TE Connectivity Linx	50ohm SM PC Mount Straight Jack Receptacle	2
CN_EN, CN_MODE, CN_VSEL	M20-9990345	Harwin	HDR1X3 Switch, Through Hole, Pitch 2.54	3
COUT1	GRM188R60J226MEA0D	Murata	22 μ F, 6.3V, X5R, 0603 (1608)	1
CREF	GRM022R60J474ME15L	Murata	0.47 μ F, 6.3V, X5R, 01005 (0402)	1
L1	LSCNB1005EET1R0MB	TAIYO YUDEN	1 μ H, 0.8A, 0402 (1005)	1
VIN, EN, MODE, VSEL, GND, GND, GND, GND, VOUT	1502-2	Keystone Electronics	TEST POINT PC MULTI PURPOSE	9
U1	BD83070GWL	ROHM	3.3V/2.5V 2A Buck-Boost DC/DC	1

Table 4: Bill of Materials

Board Operating Procedure

1. Set the output voltage using the switch settings at CN_VSEL. (refer to Table 1)
2. Set the operation mode using the switch settings at CN_MODE. (refer to Table 3)
3. Disable the IC by setting the CN_EN jumper to the upper position (EN $\rightarrow$ GND).
4. Connect the power supply's GND terminal to one of each of the GND test point on the evaluation board.
5. Connect the power supply's VCC terminal to the VIN test point on the evaluation board. This will provide VIN to the IC. Please note that VIN should be in the range of 2.0V to 5.5V.
6. Connect the electronic load to one of each of GND and VOUT. Connect the voltmeter to one of each of GND and VOUT_S.
7. Turn on the power supply and enable the IC by setting the jumper at CN_EN to the lower position (EN $\rightarrow$ VIN). The output voltage can be measured at test point VOUT_S. Now turn on the load. The load can be increased up to 1.0A.

Board Layout

The following are layers of the Evaluation Board of BD83070GWL




Figure 3. Top Layer




Figure 4. Middle 1 Layer




Figure 5. Middle 2 Layer




Figure 6. Bottom Layer

Reference Application Data

The following are graphs of efficiency, switching frequency, load response, output voltage, ripple, startup and shutdown.

Typical Performance Curves




Figure 7. Efficiency vs Output Current
(VSEL=High, MODE=Low: Auto-PFM/PWM)




Figure 8. Efficiency vs Output Current
(VSEL=High, MODE=High: Forced-PWM)




Figure 9. Efficiency vs Output Current
(VSEL=Low, MODE=Low: Auto-PFM/PWM)




Figure 10. Efficiency vs Output Current
(VSEL=Low, MODE=High: Forced-PWM)

Typical Performance Curves - continued




Figure 11. Output Voltage 2 vs Output Current
("Load Regulation", VSEL=Low, MODE=High: Forced-PWM)




Figure 12. Output Voltage 1 vs Output Current
("Load Regulation", VSEL=High, MODE=High: Forced-PWM)




Figure 13. Output Voltage 2 vs Output Current
("Load Regulation", VSEL=Low, MODE=Low:
Auto-PFM/PWM)




Figure 14. Output Voltage 1 vs Output Current
("Load Regulation", VSEL=High, MODE=Low:
Auto-PFM/PWM)

Typical Performance Curves - continued




Figure 15. Transient Response
(VIN=2.3 V, VSEL=High, MODE=Low: Auto-PFM/PWM,
Output current 20 mA->600 mA)




Figure 16. Transient Response
(VIN=2.3 V, VSEL=High, MODE=Low: Auto-PFM/PWM,
Output current 600 mA->20 mA)




Figure 17. Transient Response
(VIN=3.6 V, VSEL=High, MODE=Low: Auto-PFM/PWM,
Output current 50 mA->1000 mA)




Figure 18. Transient Response
(VIN=3.6 V, VSEL=High, MODE=Low: Auto-PFM/PWM,
Output current 1000 mA->50 mA)

Typical Performance Curves - continued




Figure 19. Startup Waveform
(VIN=2.4 V, VSEL=High, MODE=High: Forced-PWM,
5.5 Ω resistive load)




Figure 20. Startup Waveform
(VIN=3.6 V, VSEL=High, MODE=High: Forced-PWM,
3.3 Ω resistive load)




Figure 21. Shutdown Waveform
(VIN=3.6 V, VSEL=Low, MODE=Low: Auto-PFM/PWM,
No load)




Figure 22. Shutdown Waveform
(VIN=3.6 V, VSEL=High, MODE=Low: Auto-PFM/PWM,
No load)

Typical Performance Curves – continued




Figure 23. Switching Frequency vs Power Supply Voltage (MODE=High: Forced-PWM, No load)




Figure 24. Ripple Voltage vs Output Current ($V_{IN}=3.6$ V, VSEL=High)




Figure 25. Power Supply Voltage vs Ripple Voltage ($I_{OUT}=10$ μ A, VSEL=High)




Figure 26. Quiescent V_{IN} Current vs Power Supply Voltage (MODE=Low: Auto-PFM/PWM, $V_{FB}=3.5$ V, No load)




Figure 27. Shutdown VIN current vs Power Supply Voltage
(EN=MODE=Low, No load)

Revision History

Date	Revision	Changes
14.Apr.2026	001	New Release

Notice

- 1) The information contained in this document is intended to introduce ROHM Group (hereafter referred to as ROHM) products. When using ROHM products, please verify the latest specifications or datasheets before use.
- 2) ROHM products are designed and manufactured for use in general electronic equipment and applications (such as Audio Visual equipment, Office Automation equipment, telecommunication equipment, home appliances, amusement devices, etc.) or specified in the datasheets. Therefore, please contact the ROHM sales representative before using ROHM products in equipment or devices requiring extremely high reliability and whose failure or malfunction may cause danger or injury to human life or body or other serious damage (such as medical equipment, transportation, traffic, aircraft, spacecraft, nuclear power controllers, fuel control, automotive equipment including car accessories, etc. hereafter referred to as Specific Applications). Unless otherwise agreed in writing by ROHM in advance, ROHM shall not be in any way responsible or liable for any damages, expenses, or losses incurred by you or third parties arising from the use of ROHM Products for Specific Applications.
- 3) Electronic components, including semiconductors, can fail or malfunction at a certain rate. Please be sure to implement, at your own responsibilities, adequate safety measures including but not limited to fail-safe design against physical injury, and damage to any property, which a failure or malfunction of products may cause.
- 4) The information contained in this document, including application circuit examples and their constants, is intended to explain the standard operation and usage of ROHM products, and is not intended to guarantee, either explicitly or implicitly, the operation of the product in the actual equipment it will be used. As a result, you are solely responsible for it, and you must exercise your own independent verification and judgment in the use of such information contained in this document. ROHM shall not be in any way responsible or liable for any damages, expenses, or losses incurred by you or third parties arising from the use of such information.
- 5) When exporting ROHM products or technologies described in this document to other countries, you must abide by the procedures and provisions stipulated in all applicable export laws and regulations, such as the Foreign Exchange and Foreign Trade Act and the US Export Administration Regulations, and follow the necessary procedures in accordance with these provisions.
- 6) The technical information and data described in this document, including typical application circuits, are examples only and are not intended to guarantee to be free from infringement of third parties intellectual property or other rights. ROHM does not grant any license, express or implied, to implement, use, or exploit any intellectual property or other rights owned or controlled by ROHM or any third parties with respect to the information contained herein.
- 7) No part of this document may be reprinted or reproduced in any form by any means without the prior written consent of ROHM.
- 8) All information contained in this document is current as of the date of publication and subject to change without notice. Before purchasing or using ROHM products, please confirm the latest information with the ROHM sales representative.
- 9) ROHM does not warrant that the information contained herein is error-free. ROHM shall not be in any way responsible or liable for any damages, expenses, or losses incurred by you or third parties resulting from errors contained in this document.



Thank you for your accessing to ROHM product informations.
More detail product informations and catalogs are available, please contact us.

ROHM Customer Support System

<https://www.rohm.com/contactus>