


DESCRIPTION

Key for MX and BCP call points.

DIMENSIONS

51.5 x 20 x 11.5mm

USAGE

Insert and turn toothed end, rotate 90°CW to drop the activated plate. Rotate 90°CCW and push inwards to set plate back in place.

Insert and turn keyed section 90°CCW to remove front of call point from base. Reverse to lock in place.



KNIGHT
FIRE & SECURITY

Unit 84 Seawall Road Ind. Estate
Cardiff UK CF24 5TH
Tel: +44 (0) 2920 488 129
Fax: +44(0) 2920 489 132

Drawing #: MX001
Drawn: Gareth Carpenter
Date: 01/11/2024
Revision: 1

All dimensions in mm
Do not scale



© Knight Fire & Security Products Ltd
All cases of infringement will be pursued.