

System Prerequisites


Recommended configuration

| | |
|-------------------------|--|
| Processor | Pentium® 4 or higher with support of all customary operating systems |
| Operating system | Microsoft Windows not lower than Vista |
| Memory | 512 MB RAM or higher |
| Monitor | VGA (1024 x 768) |
| Drive | CD-ROM |
| Input device | Mouse or compatible |
| Interface | USB for data transmission |

Install Software

- Insert the provided CD disk into CD-ROM drive.
- Double-click “XXX.exe”
- The pop-up windows will guide you through the program setup process.


Main Screen



- ① Main display screen of measurement
- ② Secondary display screen for measurement
- ③ Blinking indicates meter is connected to the software
- ④ Measurement data in graph

Using Program

Click "Connection" and is blinking indicates meter is successfully connected to the PC and meter will automatically start taking measurements. Primary display screen shows measurement, secondary display screen shows all measurement data.



- ① Zoom graphic
- ② Save graph in current page as *.bmp
- ③ Deleting current data and create a new data.
- ④ Last page
- ⑤ Next page
- ⑥ Current page
- ⑦ Previous page
- ⑧ First page
- ⑨ Set numbers of measurement data on graph display