Smart Home Hub Controller

70010126

TUV CE FC *RoHS COMPLIANT*

Important: Read All Instructions Prior to Installation

Function introduction

Red LED indicator:
Signal transmission

Green LED indicator:
Power normal

Blue LED indicator:
WiFi connected

Ethernet

12VDC Power Input

41 mm

Reset
Switch

WiFi Reset switch: press and hold down for 10S then release, the blue WiFi indicator will go off and go on again, WiFi setting will be factory reset.

Note: When the hub is configured to home router, use the button to reset WiFi setting to enable to control directly through the hub network again.

Product Data

Radio protocol	RF+Z-Wave Plus+ZigBee HA
Operation Frequency	868.40MHz/908.40MHz/921.40MHz/2.4GHz
Power Supply	12VDC
Operating temperature	0-40°C
Relative humidity	8% to 80%
Dimensions	110x85x24.2mm

• One APP + One Hub for controlling all your lighting devices

• RF+Z-Wave+ZigBee provide the widest range of supported devices

• Compatible with ZigBee lighting devices supporting the Home Automation Profile.

• Compatible with Z-Wave Plus enabled lighting devices.

• Compatible with RF receivers.

• Free APP is available for IOS or Android smart phones or tablets.

• Can be controlled by smart phones or from home network.

• Waterproof grade: Ip20.

Safety & Warnings

• DO NOT install with power applied to device.

• DO NOT expose the device to moisture.

Wiring diagram

Method 1: Connect the hub to your home network router, then configure it to your home network, then connect your smart phone with your home network router

1.Easyhome RF

RF LED Receiver

12VDC
power input

Router

2.Easyhome Z-Wave

Z-Wave Controller

12VDC
Power Input

Router

Z-Wave Controller

Z-Wave Controller

12VDC
Power Input

3.Easyhome ZigBee

ZigBee Controller

12VDC
Power Input

Router

ZigBee Controller

ZigBee Controller

12VDC
Power Input

Method 2: Connect your smart phone directly with the hub network

1.Easyhome RF

RF LED Receiver

RF LED Receiver

Learning Key

12VDC
Power Input

Operation

1. Download "Easy Home" APP from "APP Store" or "Google Play" by searching "Easy Home – Smart Home".

2. If the hub controller has been configured to a router, then connect your
cell phone to your router network. If the hub controller has not been
configured to a router, then connect your cell phone to the hub controller network directly.
(Password: 0123456789)

3. Run the Easy Home application and operate according the application manual.