

DeoxIT®

TIP Attachments

INSTRUCTIONS

PERFECT-STRAW™ TIP ATTACHMENT INSTRUCTIONS

Part Nos. PS-SS45T and PS-P180T



Part No. PS-SS45T



Part No. PS-P180T



Link to Instructional Video:
<https://caig.com/accessories>
(Select Tip, then Select Video TAB)



Hold hands around can. With thumbs, push up on tab, as shown.
NOTE: Aim sprayer away from face!



Once Perfect-Straw™ is off one side of valve, lift off.



Select Perfect-Straw™ TIP
(PS-SS45T or PS-P180T)





Audio/Video



Computers



Automotive



Communications



Marine



Electrical



Energy



Photography



Security



Medical



Avionics



Set the new actuator so it is evenly aligned on the valve.



Push down evenly on the Perfect-Straw™ actuator so it sits evenly on the valve.



CORRECT



WRONG



If you placed the new Perfect-Straw™ actuator on “**WRONG**”, go to the following page to correct;
<https://caig.com/re-align>

BULLETIN: SB-PS-TIPS, Date: 8/2019



CAIG Laboratories, Inc.
12200 Thatcher Court, Poway, CA 92064 U.S.A.
P: 858/486-8388 | **E:** info@caig.com
WEB: www.caig.com | www.deoxit.com

Home of the DeoxIT® family of
Environmentally-Safer Contact Cleaners and
Connector Enhancing Treatments
Made in USA