Troubleshooting

Lamp flickers:

- · Adjust spindle on end of module to trim the minimum dim level
- Load incompatible with leading edge dimming Consider using DANLERS trailing edge, Quiet Grid dimmer.

Rotary dimmer fails after some time:

LED lamp or fitting has failed.

Rotary dimmer 'buzzes':

This can occur with leading edge dimmers,
 Consider using DANLERS trailing edge, Quiet Grid dimmer.

Rotary dimmer gets warm:

• This can occur with dimmers, especially when controlling large loads.

Precautions and Warranty

This product conforms to BS EN 60669-2-1 and BS EN 55015:1993

Please ensure the most recent edition of the appropriate local wiring regulations are observed and suitable protection is provided e.g. 6 amps over current, 1kV over voltage. Please ensure that this device is disconnected from the supply if an insulation test is made.

This product is covered by a warranty which extends to 5 years from the date of manufacture.

Disclaimer

DANLERS cannot guarantee that DP_D LED dimmers will successfully dim <u>all</u> LED lamps and fittings.

The dimming performance of LED lamps and fittings may vary or not work at all when a mixture of different types of lamps are fitted in the circuit.

DANLERS cannot take responsibility for reduced lamp life to that claimed by lamp manufacturers.

Also available from DANLERS

- · PIR occupancy switches · Daylight linked dimmers · Manual high frequency dimmers
- Photocells Radio remote controls Time lag switches Outdoor security switches
- $\bullet \ \ \text{Dimmers} \ \bullet \ \text{Heating}, ventilation \ \text{and air-conditioning controls} \ \bullet \ \text{Bespoke} \ / \ \text{O.E.M.} \ products$

Please call for more information or a free catalogue, or visit our website.

DANLERS Limited, Vincients Road, CHIPPENHAM, Wiltshire, SN14 6NQ, UK. Telephone: +44 (0)1249 443377 Fax: +44 (0)1249 443388 E-mail: sales@danlers.co.uk Web: www.danlers.co.uk Company Registered Number 2570169 VAT Registration Number 543 5491 38

(E

DANLERS

Installation notes

Plated rotary 2-way (push-on, push-off) Dimmers for resistive loads

DP1D LED DP2D LED DP3D LED DP4D LED

DANLERS plated push and rotary 2-way 'leading edge' LED dimmers are available as either one gang or two gang dimmers on a square plate or as three or four gang dimmers on a rectangular plate.

Press the knob to turn the lamp on and off, rotate it clockwise to brighten the lamp and anti-clockwise to dim it.

Each DP_D LED has an adjustable trim spindle on the end of the dimmer module for designating the minimum dim level.

The lamp can be switched from other locations by using standard 2-way and intermediate wall switches. It cannot be dimmed from another location and no other dimmer should be connected into the same switch circuit.

Loading

DANLERS plated push and rotary LED dimmers are compatible with many reputable LED lamps and fittings.

DANLERS cannot guarantee that these dimmers will successfully dim ALL LED lamps and fittings. The dimming performance of LED lamps and fittings may vary when different types of lamps are fitted in the circuit.

Each individual dimmer switch can dim within the following loading limits, they need the following wall box depth and are supplied on the following plate shape.

Part Code	Gang	Min* (per gang)	Max (per gang)	Box depth	Plate style
DP1D LED	1	5W*	250W	35mm	Square
DP2D LED	2	5W*	250W	35mm	Square
DP3D LED	3	5W*	250W	35mm	Rectangular
DP4D LED	4	5W*	250W	35mm	Rectangular

*5W is the optimum minimum load on LED lamps tested by DANLERS. However due to the variable nature of LED lamp drivers we cannot guarantee 5W is the minimum with ALL LED lamps and fittings.

26/02/13 INSxxx DPxDLED

Installation procedure

- Please read these notes carefully before commencing work.
 In case of doubt please consult a qualified electrician.
 Make sure the power is isolated from the circuit.
- 2. The LED dimmer should be connected as:
 - L1 Live 1 (position 1 of 2-way switch)
 - L2 Live 2 (position 2 of 2-way switch)
 - V Common (common of 2-way switch).
- 3 Typical wiring diagrams are shown opposite.
- 4. Should the LED lamps or fittings flicker when the dimmer is in the lower end of its range the minimum dim level spindle should be turned to the point at which the lamp stops flickering - see diagram opposite.
- Once the wiring has been completed and verified, switch on the supply and test the operation.



Typical wiring diagrams

