



ADC 8 CLICK

PID: MIKROE-3394 Weight: 25 g

ADC 8 Click is a high precision, low-power, 16-bit analog-to-digital converter (ADC), based around the ADS1115 IC. It is capable of sampling signals on four single-ended or two differential input channels. Although the ADS1115 cannot use an external reference, it incorporates a low-drift programmable voltage reference, along with the programmable gain amplifier (PGA). This allows for great flexibility in terms of the input signal level: it can sample signals from ± 256 mV, up to 6.144 V, allowing a very high precision for a wide range of input signals, making it an excellent choice for various instrumentation applications.

ADC 8 Click is supported by a mikroSDK compliant library, which includes functions that simplify software development. This Click board™ comes as a fully tested product, ready to be used on a system equipped with the mikroBUS™ socket.

The conversion output is available over the I2C interface, in 16-bit two's complement LSB/MSB format. A positive input signal can have values in the range from 0x0001 to 0x7FFF, while the negative input signal can have values in the range from 0x0000 to 0x8000. The slave I2C address of the device can be selected by moving the SMD jumper labeled as ADDR. It allows four different I2C addresses to be selected and thus, up to four different ADC 8 clicks can be used on a single I2C bus.

Signal to Noise ratio (SNR) depends on two factors: the reference voltage and the output data rate. Delta-sigma ADCs are based on the oversampling principle: the input signal is sampled at a higher frequency and it is subsequently filtered and decimated, until the output value is obtained, at the requested output data rate. The ratio between the high sampling frequency (modulator) and the output data rate is called oversampling ratio (OSR). By increasing the OSR, less noise appears at the output, since more values are included in the averaging process.

As already mentioned, the ADS1115 IC cannot use an external voltage reference. However, it has a high-precision internal reference with low drift over temperature. It can be selected from several available values: ± 0.256 , ± 0.512 , ± 1.024 , ± 2.048 V, ± 4.096 , and ± 6.144 . Note, however, that the input signal should not be greater than $V_{CC} + 0.3$ V. In other words, it is not possible to use the 4.096V if the power supply source is 3.3V. ADC 8 click is equipped with the SMD jumper labeled as VCC SEL, which allows selection between 3.3V and 5V.

SPECIFICATIONS

Type	ADC
Applications	It is well suited for portable instrumentation applications, battery voltage, and current monitoring, analog sensor output conversion, etc.
On-board modules	ADS1115 IC, an ultra-small, low-power, high-precision, 16-bit A/D converter, from Analog Devices.
Key Features	Analog to digital conversion from 4 single-ended channels or 2 differential input channels, sampling resolution of 16 bits over the I2C interface, programmable high-precision internal reference...
Interface	I2C
Input Voltage	3.3V or 5V

Click board size	M (42.9 x 25.4 mm)
-------------------------	--------------------

PINOUT DIAGRAM

This table shows how the pinout on **ADC 8 Click** corresponds to the pinout on the mikroBUS™ socket (the latter shown in the two middle columns).

Notes	Pin					Pin	Notes
	NC	1	AN	PWM	16	NC	
	NC	2	RST	INT	15	INT	Alert/Data Ready
	NC	3	CS	RX	14	NC	
	NC	4	SCK	TX	13	NC	
	NC	5	MISO	SCL	12	SCL	I2C Clock
	NC	6	MOSI	SDA	11	SDA	I2C Data
Power Supply	3V3	7	3.3V	5V	10	5V	Power supply
Ground	GND	8	GND	GND	9	GND	Ground

ONBOARD SETTINGS AND INDICATORS

Label	Name	Default	Description
LD1	PWR	-	Power LED indicator

JP1	VREF SEL	Left	Power supply voltage selection, left position 3.3V, right 5V
JP2, JP3	ADDR	Down	Slave I2C Address Selection

SOFTWARE SUPPORT

We provide a library for the **ADC 8 Click** on our LibStock page, as well as a demo application (example), developed using MikroElektronika compilers. The demo can run on all the main MikroElektronika development boards.

Library Description

The library contains functions for the complete communication of the MCU with click. The user can use functions to read the ADC values and voltage on the channel. The library also offers functions for writing data into the register and reading data from the register, as well as the configuration of the device for successful measurement.

Key functions:

- float adc8_getVoltage(uint8_t channel) - Read Voltage in mV
- uint16_t adc8_getADCValue(uint8_t channel) - Get ADC value reads from the channel
- void adc8_deviceConfig(uint16_t cfg) - Device configuration for measurement

Examples description

The application is composed of the three sections :

- System Initialization - Initializes I2C module and sets INT pin as INPUT
- Application Initialization - Initialization driver init and configuration device for measurement.
- Application Task - Reads voltage from each channel one by one and the voltage difference between specified channels

Note: On the input channel AIN0,AIN1,AIN2 and AIN3 sets maximum voltage $GND - 0.3V < VIN < VDD + 0.3V$.

```
void applicationTask()
{
    // Single channel
    vSingle_CH0 = adc8_getVoltage(_ADC8_SINGLE_CHANNEL_0);
    vSingle_CH1 = adc8_getVoltage(_ADC8_SINGLE_CHANNEL_1);
    vSingle_CH2 = adc8_getVoltage(_ADC8_SINGLE_CHANNEL_2);
}
```

```

vSingle_CH3 = adc8_getVoltage(_ADC8_SINGLE_CHANNEL_3);

mikrobus_logWrite("_____ ", _LOG_LINE);
mikrobus_logWrite(" Channel | CH 0 | CH 1 | CH 2 | CH 3 |", _LOG_LINE);
mikrobus_logWrite(" Single |", _LOG_TEXT);

IntToStr(vSingle_CH0, demoText);
mikrobus_logWrite(demoText, _LOG_TEXT);
mikrobus_logWrite(" |", _LOG_TEXT);

IntToStr(vSingle_CH1, demoText);
mikrobus_logWrite(demoText, _LOG_TEXT);
mikrobus_logWrite(" |", _LOG_TEXT);

IntToStr(vSingle_CH2, demoText);
mikrobus_logWrite(demoText, _LOG_TEXT);
mikrobus_logWrite(" |", _LOG_TEXT);

IntToStr(vSingle_CH3, demoText);
mikrobus_logWrite(demoText, _LOG_TEXT);
mikrobus_logWrite(" |", _LOG_LINE);

// Diff channel
vDiff_CH01 = adc8_getVoltage(_ADC8_DIFF_CHANNEL_0_1);
vDiff_CH03 = adc8_getVoltage(_ADC8_DIFF_CHANNEL_0_3);
vDiff_CH13 = adc8_getVoltage(_ADC8_DIFF_CHANNEL_1_3);
vDiff_CH23 = adc8_getVoltage(_ADC8_DIFF_CHANNEL_2_3);

mikrobus_logWrite("_____ ", _LOG_LINE);
mikrobus_logWrite(" Channel | CH 0-1 | CH 0-3 | CH 1-3 | CH 2-3 |", _LOG_LINE);
mikrobus_logWrite(" Diff |", _LOG_TEXT);

IntToStr(vDiff_CH01, demoText);
mikrobus_logWrite(demoText, _LOG_TEXT);
mikrobus_logWrite(" |", _LOG_TEXT);

IntToStr(vDiff_CH03, demoText);

```

```

mikrobus_logWrite(demoText, _LOG_TEXT);
mikrobus_logWrite(" |", _LOG_TEXT);

IntToStr(vDiff_CH13, demoText);
mikrobus_logWrite(demoText, _LOG_TEXT);
mikrobus_logWrite(" |", _LOG_TEXT);

IntToStr(vDiff_CH23, demoText);
mikrobus_logWrite(demoText, _LOG_TEXT);
mikrobus_logWrite(" |", _LOG_LINE);

mikrobus_logWrite("|-----|", _LOG_LINE);
Delay_1sec();
}

```

The full application code, and ready to use projects can be found on our LibStock page. Other mikroE Libraries used in the example:

- I2C
- Conversions


Additional notes and informations

Depending on the development board you are using, you may need USB UART click, USB UART 2 click or RS232 click to connect to your PC, for development systems with no UART to USB interface available on the board. The terminal available in all MikroElektronika compilers, or any other terminal application of your choice, can be used to read the message.

MIKROSDK

This click board is supported with mikroSDK - MikroElektronika Software Development Kit. To ensure proper operation of mikroSDK compliant click board demo applications, mikroSDK should be downloaded from the LibStock and installed for the compiler you are using.

For more information about mikroSDK, visit the official page.



<https://www.mikroe.com/adc-8-click/3-21-19>