

650W 5 Fin Oil Filled Heater

User Manual



Part Number: PELL0203 & PELL0204

Newark.com/exclusive-brands Farnell.com/exclusive-brands Element14.com/exclusive-brands





Important Safety Information

Please read these instructions carefully before use and retain for future reference.

- · When using electrical appliances basic safety precautions should always be followed.
- Check that the voltage indicated on the rating plate corresponds with that of the local network before connecting the appliance
 to the mains power supply.
- · The appliance must be used on a stable surface.
- · In order to avoid overheating do not cover the heater.
- This appliance is intended for domestic use only. It should not be used for commercial purposes.
- · Always turn the product to the OFF position and unplug it from the electrical outlet when not in use.
- The heater must not be located immediately below an electrical socket-outlet.
- Do not operate the heater with a damaged cord or plug, or after the heater malfunctions, has been dropped, or damaged in any manner.
- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person to avoid a hazard.
- This heater is filled with a precise quantity of oil. Repairs requiring the opening of the oil container are only to be made by the manufacturer or his service agent who should be contacted if there is an oil leak.
- · This appliance contains no user-serviceable parts.
- · When scrapping the heater, follow the regulations concerning the disposal of oil.
- Don't use this heater in the immediate surroundings of a bath, a shower or a swimming pool or where it may fall into a bathtub or other water container.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Children of less than 3 years should be kept away unless continuously supervised.
- Children aged from 3 years and less than 8 years shall only switch on/off the appliance provided that it has been placed or
 installed in its intended normal operating position and they have been given supervision or instruction concerning use of the
 appliance in a safe way and understand the hazards involved. Children aged from 3 years and less than 8 years shall not
 plug in, regulate and clean the appliance or perform user maintenance.
- This heater includes an overheat protection system that shuts off the heater when parts of the heater are getting excessively hot.
- The appliance must be unplugged from the power supply after use and whilst any maintenance such as cleaning is carried out.
- This heater is a high-power product. A worn mains socket will result in over-heating of the plug and socket. If this occurs consult a qualified electrician.
- Do not use an extension lead most are unable to handle the power this product requires.

CAUTION - Some parts of this product can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are present.





Product Overview



- 1. Power switch
- 2. Thermostat control
- 3. Handle
- 4. Finned body
- 5. Feet

Assembly Instructions

- · The heater is packaged with the feet unattached. You must attach them before operating the heater.
- 1. Place the radiator body upside-down on a scratch-free location, make sure it is stable and will not fall.
- 2. Slot the rear foot onto the bottom of the rearmost fin
- 3. Push the front foot into the slot at the base of the front panel.
- 4. Check that the heater stands upright and is stable before applying power.

WARNING: Do not operate without feet attached.

Only operate the heater in an upright position (feet on the bottom, handle on the top), any other position could create a hazardous situation.



Instructions For Use

- Before using the heater, make sure that it is on a flat and stable surface. Damage may occur if it is placed on an incline or uneven surface.
- · Set all the controls to OFF position and insert the plug into a mains socket
- Rotate the thermostat knob clockwise to MAX position and switch the heater on.
- When the heating element is on the power switch will illuminate.
- When your room reaches the desired temperature, slowly rotate the thermostat control counter clockwise until the power light goes out. The thermostat can now be left at this setting. As soon as the room temperature has dropped below the set temperature, the unit will switch it self on automatically until the set temperature has been reached again. In this way the room temperature remains constant with the most economical use of electricity.

Newark.com/exclusive-brands Farnell.com/exclusive-brands Element14.com/exclusive-brands





 If you want to change the room temperature setting, rotate the thermostat knob clockwise to raise the temperature, or counter clockwise to lower it.

Cleaning and Maintenance

- · Always remove the plug from the mains socket and allow the radiator to cool down before cleaning the heater.
- · Wipe the radiator with a soft damp (not wet) cloth.
- · Do not use any cleaning chemicals such as detergents and abrasives.

Specifications

Model	PELL0203	PELL0204
Rated Voltage	220-240VAC	220-240VAC
Frequency	50/60Hz	50/60Hz
Rated Power	650W	650W
Heat Output		
Nominal heat output Pnom	0.3492kW	0.3492kW
Min heat output Pmin	0kW	0kW
Max heat output Pmax	0.3492kW	0.3492kW
Auxiliary electricity consumption		
At nominal heat output elmax	0kW	0kW
At minimum heat output elmin	0kW	0kW
In standby mode elsb	N/A	N/A
With mechanical thermostat room temperature control	YES	YES



INFORMATION ON WASTE DISPOSAL FOR CONSUMERS OF ELECTRICAL & ELECTRONIC EQUIPMENT.

When this product has reached the end of its life it must be treated as Waste Electrical & Electronics Equipment (WEEE). Any WEEE marked products must not be mixed with general household waste, but kept separate for the treatment, recovery and recycling of the materials used. Contact your local authority for details of recycling schemes in your area.

As is typical for all portable heaters -

This product is only suitable for well insulated spaces or occasional use.

Made in China. PR2 9PP Man Ref 1.0

Important Notice: This data sheet and its contents (the "Information") belong to the members of the AVNET group of companies (the "Group") or are licensed to it. No licence is granted for the use of it other than for information purposes in connection with the products to which it relates. No licence of any intellectual property rights is granted. The Information is subject to change without notice and replaces all data sheets previously supplied. The Information supplied is believed to be accurate but the Group assumes no responsibility for its accuracy or completeness, any error in or omission from it or for any use made of it. Users of this data sheet should check for themselves the Information and the suitability of the products for their purpose and not make any assumptions based on information included or omitted. Liability for loss or damage resulting from any reliance on the Information or use of it (including liability resulting from negligence or where the Group was aware of the possibility of such loss or damage arising) is excluded. This will not operate to limit or restrict the Group's liability for death or personal injury resulting from its negligence. pro-ELEC is the registered trademark of Premier Farnell Limited 2019.

Newark.com/exclusive-brands Farnell.com/exclusive-brands Element14.com/exclusive-brands

