

# **13A 250V EXTENSION LEAD** SWITCHED OR UNSWITCHED WITH USB

### **IMPORTANT PRODUCT SAFETY INFORMATION**



- DO check the user manual provided with all high powered domestic appliances including kitchen appliances and air conditioning units for suitability before connecting to an extension lead.
- DO ensure the mains cable must be fully unwound before use.
- DO position an extension lead carefully to prevent any risk of damage or a trip hazard. If the cable has to cross a pathway, cover it with a rubber protector strip.
- DO check that the extension cable is suitable for your local mains voltage and socket.
- DO check that plugs and sockets are undamaged before use and the cable is not damaged due to being walked over, continually bent at the same point, or stored badly.
- DO NOT remove the fused plug and connect directly to a mains supply.
- DO NOT use extension cables with multi-way adapters or adapter blocks, as this can overload the socket which increases the risk of fire.
- DO NOT connect multiple extension leads together.
- DO NOT exceed the total maximum load across all outlets of 13A / 3120W.
- DO NOT push objects other than the appliance plug into the extension cable sockets.
- DO NOT use in damp conditions.
- DO NOT use outdoors for indoor use only.

## **RECOMMENDED USAGE**

- Disconnect the power before connecting equipment to the extension lead sockets.
- An extension lead should only be used when it is not possible to reach a wall socket with the appliance cable.
- BEWARE power tools used with extension cables can frequently become tangled.
- BEWARE high power equipment such as kitchen appliances may overload the extension lead, always check the safety instructions supplied with the appliance before use.







Safety Shutters Fire Retardent Materals

13A Plug Fuse



## **USB SAFETY**



- DO refer to the user manual of your USB device to determine manufacturers required voltage and current requirements.
- ✓ Always use an appropriate cable for your device.
- DO NOT exceed the total shared output across all USB sockets.
- X DO NOT use with a damaged USB cable as it can cause overheating and damage.