USER MANUAL

Toslink/Optical Audio 3x1 Switcher

Model #: 33-12745

FEATURES

● Audio format support : LPCM2.0/DTS 5.1/Dolby-AC3
● Support signal retiming
● Utilizing optical fiber cable loss less the 0.2Db/m. Output distance is up to 40m.
● This input control can through 50V and also can directly press the button
● Supports source unit memory, where the last source used when turned off will still be selected when turned back on
● Over-voltage protection
● LED status indication
● No loss of quality
● Installs in minutes

Contents:

1.	Toslink Switch	1 piece
2.	5V power adapter	1 piece
3.	User manual	1 piece
4.	Remote	1 piece
5.	IR extension	1 piece

---

1. Channel input indication
2. Switch button for channel
3. IR extender line input port

4. SPDIF/TosLink input port 1,2
5. SPDIF/TosLink input port 3
6. SPDIF/TosLink output port
7. DC/5V Power Adaptor Interface

IR Remote Functions

1. Power button

2. SPDIF/Toslink input switch button. If you want to choose input source 2, press numeric key 2

SPECIFICATIONS:

Support audio format..LPCM2.0/DTS/Dolby-AC3
Peak wavelength...650nm
Max baud rate..16Mbps
Output cable distance ....≤40m(Use the optical fiber cable loss less the 0.2Db/m)
Max working current...100mA
Power adapter format...........Input:AC (50HZ, 60HZ) 100V-240V; Output: DC5V/500mA
Operating Temperature range..(0 to +40℃)
Operating Humidity range...5 to 90%RH (No Condensation)
Dimension (L x W x H)..2.1" x 2.1" x 0.9"
Weight..1.2 oz

Notes:

Please use this device as the instructions have described to improve the longevity and safety of the unit.
1.The unit should be placed in a location away from damp, high-temperature, dusty, erosive, and oxidative conditions.
2.Please hold the power adapter head and do not pull the power cord when disconnecting from the socket.
3.Please turn the power off when the unit is not being used for long time.
4.Please use the original factory power adapter.

Troubleshooting

Issue	Cause and Ways to deal with
No Power	1. Make sure the power plug is inserted securely into the unit. 2. Check the power source to make sure it is connected to an outlet.
Remote Not Working	1. Make sure the plastic tab is removed from the battery compartment. 2. Make sure the battery has a charge.
No sound output	1. Check the equipment to make sure all pieces are on and in working condition 2. Ensure all cables are properly installed and in working condition

---