

Introduction

The STM32 Nucleo-144 board (NUCLEO-F207ZG, NUCLEO-F303ZE, NUCLEO-F429ZI, NUCLEO-F446ZE, NUCLEO-F746ZG) provides an affordable and flexible way for users to try out new ideas and build prototypes with the STM32 microcontroller, choosing from the various combinations of performance, power consumption and features. The ST Zio connector, which extends the Arduino™ Uno connectivity, and the ST morpho headers provide access to a wider range of peripherals and make it easy to expand the functionality of the Nucleo open development platform with a large choice of specialized shields. The STM32 Nucleo-144 board does not require any separate probe as it integrates the ST-LINK/V2-1 debugger/programmer. The STM32 Nucleo-144 board comes with the STM32 comprehensive software HAL library, together with various packaged software examples, as well as the direct access to the ARM® mbed™ on-line resources at <http://mbed.org>.

Figure 1. Nucleo 144 board (top view)





Figure 2. Nucleo 144 board (bottom view)



1. Pictures not contractual.



Contents

- 1 Features 6**
- 2 Product marking 7**
- 3 Order code 7**
- 4 Conventions 8**
- 5 Quick start 8**
 - 5.1 Getting started 8
 - 5.2 System requirements 9
- 6 Hardware layout and configuration 10**
 - 6.1 Cuttable PCB 13
 - 6.2 Embedded ST-LINK/V2-1 13
 - 6.2.1 Drivers 14
 - 6.2.2 ST-LINK/V2-1 firmware upgrade 14
 - 6.2.3 Using the ST-LINK/V2-1 to program and debug
the STM32 on board 14
 - 6.2.4 Using ST-LINK/V2-1 to program and debug an external STM32
application 16
 - 6.3 Power supply and power selection 18
 - 6.3.1 Power supply input from ST-LINK/V2-1 USB connector 18
 - 6.3.2 External power supply inputs 19
 - 6.3.3 External power supply output 21
 - 6.4 LEDs 21
 - 6.5 Push buttons 22
 - 6.6 JP5 (IDD) 22
 - 6.7 OSC clock 22
 - 6.7.1 OSC clock supply 22
 - 6.7.2 OSC 32 KHz clock supply 23
 - 6.8 USART communication 23
 - 6.9 USB FS OTG or device 24
 - 6.10 Ethernet 25

6.11	Solder bridges	26
6.12	Extension connectors	29
6.13	ST Zio connectors	31
6.14	ST morpho connector	49
7	Electrical schematics	53
8	Mechanical drawing	59
9	Revision history	61

List of tables

Table 1.	Ordering information	7
Table 2.	ON/OFF conventions	8
Table 3.	CN4 states of the jumpers	13
Table 4.	Debug connector CN6 (SWD)	16
Table 5.	JP1 configuration table	18
Table 6.	External power sources	19
Table 7.	Power related jumper	20
Table 8.	USART3 pins	23
Table 9.	USB pins configuration	24
Table 10.	Ethernet pins	25
Table 11.	Solder bridges	26
Table 12.	NUCLEO-F746ZG pin assignments	32
Table 13.	NUCLEO-F446ZE pin assignments	35
Table 14.	NUCLEO-F303ZE pin assignments	39
Table 15.	NUCLEO-F207ZG pin assignments	43
Table 16.	NUCLEO-F429ZI pin assignments	46
Table 17.	ST morpho connector for NUCLEO-F207ZG, NUCLEO-F429ZI, NUCLEO-F446ZE, NUCLEO-F746ZG	50
Table 18.	ST morpho connector for NUCLEO-F303ZE	51
Table 19.	Document revision history	61

List of figures

Figure 1.	Nucleo 144 board (top view)	1
Figure 2.	Nucleo 144 board (bottom view)	1
Figure 3.	Hardware block diagram	10
Figure 4.	Top layout	11
Figure 5.	Bottom layout	12
Figure 6.	Updating the list of drivers in Device Manager	14
Figure 7.	Connecting the STM32 Nucleo-144 board to program the on-board STM32	15
Figure 8.	Using ST-LINK/V2-1 to program the STM32 on an external application	17
Figure 9.	NUCLEO-F746ZG/F429ZI/F207ZG	29
Figure 10.	NUCLEO-F303ZE	30
Figure 11.	NUCLEO-F446ZE	31
Figure 12.	Top and Power	53
Figure 13.	MCU	54
Figure 14.	ST-LINK/V2-1	55
Figure 15.	USB	56
Figure 16.	Ethernet PHY with RJ45 connector	57
Figure 17.	Extension connectors	58
Figure 18.	Nucleo-144 board mechanical drawing in millimeter	59
Figure 19.	Nucleo-144 board mechanical drawing in mil	60

1 Features

The STM32 Nucleo-144 boards offer the following features:

- STM32 microcontroller in LQFP144 package
- Two types of extension resources:
 - ST Zio connector including:
 - Support for Arduino™ Uno Revision 3 connectivity (A0 to A5, D0 to D15)
 - Additional signals exposing a wide range of peripherals (A6 to A8, D16 to D72)
 - ST morpho extension pin header footprints for full access to all STM32 I/Os
- ARM® mbed™ -enabled (see <http://mbed.org>), planned in the second quarter of 2016
- On-board ST-LINK/V2-1 debugger/programmer with SWD connector:
 - Selection-mode switch to use the kit as a standalone ST-LINK/V2-1
 - USB re-enumeration capability. Three different interfaces supported on USB:
 - Virtual Com port
 - Mass storage
 - Debug port
- Flexible board power supply:
 - 5V from ST-LINK/V2-1 USB VBUS (U5V)
 - External power sources:
 - 3.3 V and 7 - 12 V on ST Zio or ST morpho connectors
 - 5 V on ST morpho connector
- USB OTG or device full speed with Micro-AB connector (depending on STM32 support)
- IEEE-802.3-2002 compliant Ethernet connector (depending on STM32 support)
- Three user LEDs
- Two push buttons: USER and RESET
- LSE crystal:
 - 32.768KHz crystal oscillator
- Comprehensive free software HAL library including a variety of software examples
- Supported by wide choice of Integrated Development Environments (IDEs) including IAR™, Keil®, GCC-based IDEs, ARM® mbed™

2 Product marking

Evaluation tools marked as “ES” or “E” are not yet qualified and therefore not ready to be used as reference design or in production. Any consequences deriving from such usage will not be at ST charge. In no event, ST will be liable for any customer usage of these engineering sample tools as reference design or in production.

“E” or “ES” marking examples of location:

- On the targeted STM32 that is soldered on the board (for illustration of STM32 marking, refer to the STM32 datasheet “Package information” paragraph at the www.st.com website).
- Next to the evaluation tool ordering part number that is stuck or silk-screen printed on the board.

3 Order code

To order the Nucleo-144 board corresponding to the targeted STM32, use the order code given in the below [Table 1](#):

Table 1. Ordering information

Target STM32	Order code
STM32F207ZGT6	NUCLEO-F207ZG
STM32F303ZET6	NUCLEO-F303ZE
STM32F429ZIT6	NUCLEO-F429ZI
STM32F446ZET6	NUCLEO-F446ZE
STM32F746ZGT6	NUCLEO-F746ZG

Order code codification NUCLEO-TXXXZY meaning:

- T describes the STM32 family (F or L)
- XXX describes the silicon special features
- Z describes the pin count (Z for 144 pins)
- Y describes the Flash memory size (E for 512K, G for 1MB, I for 2MB)

This order code is mentioned on a sticker placed on top side of the board.

4 Conventions

[Table 2](#) provides the conventions used for the ON and OFF settings in the present document.

Table 2. ON/OFF conventions

Convention	Definition
Jumper JPx ON	Jumper fitted
Jumper JPx OFF	Jumper not fitted
Solder bridge SBx ON	SBx connections closed by solder or 0 ohm resistor
Solder bridge SBx OFF	SBx connections left open

In this document the references for all information, that is common to all sale types, are “STM32 Nucleo-144 board” and “STM32 Nucleo-144 boards”.

5 Quick start

The STM32 Nucleo-144 board is a low-cost and easy-to-use Development Kit, used to quickly evaluate and start a development with an STM32 microcontroller in LQFP144 package.

Before installing and using the product, accept the Evaluation Product License Agreement from the www.st.com/epla webpage.

For more information on the STM32 Nucleo-144 and for demonstration software, visit www.st.com/stm32nucleo webpage.

5.1 Getting started

Follow the sequence below to configure the Nucleo-144 board and launch the demonstration application (refer to [Figure 4: Top layout](#) for components location):

- Check jumper position on the board:
 - JP1 OFF (PWR-EXT) selected (see [Section 6.3.1: Power supply input from ST-LINK/V2-1 USB connector](#) for details)
 - JP3 on U5V (Power source) selected (see [Table 6: External power sources](#) for details)
 - JP5 ON (IDD) selected (see [Section 6.6: JP5 \(IDD\)](#) for details)
 - CN4 ON selected (see [Table 3: CN4 states of the jumpers](#) for details)
- For the correct identification of all the device interfaces from the host PC and before connecting the board, install the Nucleo USB driver available on the www.st.com/stm32nucleo website.
- Connect the STM32 Nucleo-144 board to a PC with a USB cable ‘type A to micro-B’ through USB connector CN1 to power the board. Green LED LD6 (PWR) and LD4 (COM) light up and the red LED LD3 blinks.

4. Press button B1 (left button).
5. Observe the blinking frequency of the three LEDs LD1 to LD3 changes, by clicking on the button B1.
6. The software demonstration and the several software examples, that allow the user to use the Nucleo features, are available at the www.st.com/stm32nucleo webpage.
7. Develop an application, using the available examples.

5.2 System requirements

- Windows® OS (XP, 7, 8)
- USB type A to Micro-B USB cable

6 Hardware layout and configuration

The STM32 Nucleo-144 board is designed around the STM32 microcontrollers in a 144-pin LQFP package.

Figure 3 shows the connections between the STM32 and its peripherals (ST-LINK/V2-1, push buttons, LEDs, USB, Ethernet, ST Zio connectors and ST morpho headers).

Figure 4 and *Figure 5* show the location of these features on the STM32 Nucleo-144 board.

Figure 3. Hardware block diagram




Figure 4. Top layout





Figure 5. Bottom layout



6.1 Cuttable PCB

The STM32 Nucleo-144 board is divided into two parts: ST-LINK and target STM32. The ST-LINK part of the PCB can be cut out to reduce the board size. In this case the remaining target STM32 part can only be powered by VIN, E5V and 3.3V on ST morpho connector CN11, or VIN and 3.3V on ST Zio connector CN8. It is still possible to use the ST-LINK part to program the main STM32, using wires between CN6 and SWD signals available on ST morpho connector (SWCLK CN11 pin 15, SWDIO CN11 pin 13 and NRST CN11 pin 14).

6.2 Embedded ST-LINK/V2-1

The ST-LINK/V2-1 programming and debugging tool is integrated in the STM32 Nucleo-144 boards.

The ST-LINK/V2-1 makes the STM32 Nucleo-144 boards mbed enabled.

The embedded ST-LINK/V2-1 supports only SWD for STM32 devices. For information about debugging and programming features refer to *ST-LINK/V2 in-circuit debugger/programmer for STM8 and STM32*, UM1075 User manual, which describes in details all the ST-LINK/V2 features.

The changes versus ST-LINK/V2 version are listed below.

New features supported on ST-LINK/V2-1:

- USB software re-enumeration
- Virtual com port interface on USB
- Mass storage interface on USB
- USB power management request for more than 100 mA power on USB

Features not supported on ST-LINK/V2-1:

- SWIM interface
- Minimum supported application voltage limited to 3 V

Known limitation:

- Activating the readout protection on ST-LINK/V2-1 target, prevents the target application from running afterwards. The target readout protection must be kept disabled on ST-LINK/V2-1 boards.

There are two different ways to use the embedded ST-LINK/V2-1, depending on the jumper state (see [Table 3](#)):

- Program/debug the STM32 on board
- Program/debug the STM32 in an external application board, using a cable connected to SWD connector CN6

Table 3. CN4 states of the jumpers

Jumper state	Description
Both CN4 jumpers ON	ST-LINK/V2-1 functions enabled for on board programming (default). See Section 6.2.3 .
Both CN4 jumpers OFF	ST-LINK/V2-1 functions enabled for external CN6 connector (SWD supported). See Section 6.2.4 .


6.2.1 Drivers

The ST-LINK/V2-1 requires a dedicated USB driver, which can be found on www.st.com for Windows® XP, 7, 8.

In case the STM32 Nucleo-144 board is connected to the PC before the driver is installed, some Nucleo interfaces may be declared as “Unknown” in the PC device manager. In this case the user must install the driver files (*Figure 6*), and from the device manager he must update the driver of the connected device.

Note: Prefer using the “USB Composite Device” handle for a full recovery.

Figure 6. Updating the list of drivers in Device Manager




6.2.2 ST-LINK/V2-1 firmware upgrade

The ST-LINK/V2-1 embeds a firmware upgrade mechanism for in-situ upgrade through the USB port. As the firmware may evolve during the life time of the ST-LINK/V2-1 product (for example new functionalities, bug fixes, support for new microcontroller families), it is recommended to visit www.st.com before starting to use the STM32 Nucleo-144 board and periodically, in order to stay up-to-date with the latest firmware version.

6.2.3 Using the ST-LINK/V2-1 to program and debug the STM32 on board

To program the STM32 on board, place on the connector CN4 the two jumpers marked in red, as shown in *Figure 7*. The CN6 connector must not be used, since it could disturb the communication with the STM32 microcontroller of the Nucleo-144 board.

Figure 7. Connecting the STM32 Nucleo-144 board to program the on-board STM32



6.2.4 Using ST-LINK/V2-1 to program and debug an external STM32 application

It is very easy to use the ST-LINK/V2-1 to program the STM32 on an external application.


Simply remove the two jumpers from CN4, as shown in [Figure 8](#), and connect the application to the CN6 debug connector according to [Table 4](#).

Note: **SB111 NRST (target STM32 RESET) must be OFF when CN6 pin 5 is used in an external application.**

Table 4. Debug connector CN6 (SWD)

Pin	CN6	Designation
1	VDD_TARGET	VDD from application
2	SWCLK	SWD clock
3	GND	Ground
4	SWDIO	SWD data input/output
5	NRST	RESET of target STM32
6	SWO	Reserved

Figure 8. Using ST-LINK/V2-1 to program the STM32 on an external application



6.3 Power supply and power selection

The power supply is provided either by the host PC through the USB cable or by an external source: VIN (7V-12V), E5V (5V) or +3V3 power supply pins on CN8 or CN11. In case VIN, E5V or +3V3 is used to power the Nucleo-144 board, this power source must comply with the standard EN-60950-1: 2006+A11/2009 and must be Safety Extra Low Voltage (SELV) with limited power capability.

In case the power supply is +3V3, the ST-LINK is not powered and cannot be used.

6.3.1 Power supply input from ST-LINK/V2-1 USB connector

The STM32 Nucleo-144 board and shield can be powered from the ST-LINK USB connector CN1 (U5V), by placing a jumper between the pins 3 and 4 of JP3, as shown in [Table 7: Power related jumper](#). Note that only the ST-LINK part is power supplied before the USB enumeration, as the host PC only provides 100 mA to the board at that time. During the USB enumeration, the STM32 Nucleo-144 board requires 300 mA of current to the host PC. If the host is able to provide the required power, the targeted STM32 microcontroller is powered and the green LED LD6 is turned ON, thus the STM32 Nucleo-144 board and its shield can consume a maximum of 300 mA current, not more. If the host is not able to provide the required current, the targeted STM32 microcontroller and the extension boards are not power supplied. As a consequence the green LED LD6 stays turned OFF. In such case it is mandatory to use an external power supply as explained in the next section.

After the USB enumeration succeeds, the ST-LINK U5V power is enabled, by asserting the PWR_EN pin. This pin is connected to a power switch (ST890), which powers the board. This power switch features also a current limitation to protect the PC in case of short-circuit on board. If an over current (more than 500 mA) happens on board, the red LED LD5 is lit.

JP1 is configured according to the maximum current consumption of the board when powered by USB (U5V). JP1 jumper can be set ON to inform the host PC that the maximum current consumption does not exceed 100 mA (including potential extension board or ST Zio shield). In such condition USB enumeration will always succeed, since no more than 100 mA is requested to the PC. Possible configurations of JP1 are summarized in [Table 5](#).

Table 5. JP1 configuration table

Jumper state	Power supply	Allowed current
JP1 jumper OFF	USB power through CN1	300mA max
JP1 jumper ON		100mA max
JP1 jumper (do not care)	VIN, +3V3, +5V power	For current limitation refer to Table 7

Warning: In case maximum the current consumption of the STM32 Nucleo-144 board and its shield boards exceed 300mA, it is mandatory to power the STM32 Nucleo-144 board, using an external power supply connected to E5V, VIN or +3V3.

Note: In case the board is powered by a USB charger, there is no USB enumeration, so the green LED LD6 stays in OFF state permanently and the target STM32 is not powered. In this

specific case the jumper JP1 needs to be set to ON, to allow the board to be powered anyway. But in any cases the current will be limited to 500 mA by U4 (ST890).

6.3.2 External power supply inputs

The Nucleo-144 board and its shields boards can be powered in three different ways from an external power supply, depending on the voltage used. The three power sources are summarized in the [Table 6](#).

When STM32 Nucleo-144 board is power supplied by VIN or E5V, the jumper configuration must be the following:




- Jumper JP3 on pin 1 and pin 2 for E5V or jumper JP3 on pin 5 and pin 6 for VIN
- Jumper JP1 OFF

Table 6. External power sources

Input power name	Connector pins	Voltage range	Max current	Limitation
VIN	CN8 pin 15 CN11 pin 24	7V to 12V	800mA	From 7V to 12V only and input current capability is linked to input voltage: 800mA input current when VIN=7V 450mA input current when 7V<VIN<9V 250mA input current when 9V<VIN<12V
E5V	CN11 pin 6	4.75V to 5.25V	500mA	-
+3V3	CN8 pin 7 CN11 pin 16	3V to 3.6V	-	Two possibilities: ST-LINK PCB is cut SB3 and SB111 OFF (ST-LINK not powered)

The 5V power source is selected by the jumper JP3 as shown in [Table 7](#).

Table 7. Power related jumper

Jumper	Description
JP3	U5V (ST-LINK VBUS) is used as power source when JP3 is set as shown to the right (Default setting)
	
	E5V is used as power source when JP3 is set as shown to the right:
	
	VIN is used as power source when JP3 is set as shown to the right:
	

Using VIN or E5V as an external power supply

When powered by VIN or E5V, it is still possible to use the ST-LINK for programming or debugging only, but it is mandatory to power the board first using VIN or E5V, then to connect the USB cable to the PC. By this way the enumeration will succeed anyway, thanks to the external power source.

The following power sequence procedure must be respected:

1. Connect jumper JP3 between pin 1 and pin 2 for E5V or between pin 5 and pin 6 for VIN
2. Check that JP1 is removed
3. Connect the external power source to VIN or E5V
4. Power on the external power supply $7V < VIN < 12V$ to VIN, or 5V for E5V
5. Check that the green LED LD6 is turned ON
6. Connect the PC to the USB connector CN1

If this order is not respected, the board may be powered by USB (U5V) first, then by VIN or E5V as the following risks may be encountered:

1. If more than 300 mA current is needed by the board, the PC may be damaged or the current supply can be limited by the PC. As a consequence the board is not powered correctly.
2. 300 mA is requested at enumeration (since JP1 must be OFF) so there is risk that the request is rejected and the enumeration does not succeed if the PC cannot provide such current. Consequently the board is not power supplied (LED LD6 remains OFF).

External power supply input: + 3V3

Using the +3V3 (CN8 pin 7 or CN11 pin 16) directly as power input, can be interesting, for instance, in case the 3.3 V is provided by a shield board. In this case, the ST-LINK is not powered thus the programming and debug features are not available.

Two different configurations are possible to use +3V3 to power the board:

- ST-LINK is removed (PCB cut)
- SB3 (3V3 regulator) and SB111 (NRST) are OFF.

6.3.3 External power supply output

When powered by USB, VIN or E5V, the +5V (CN8 pin 9 or CN11 pin 18) can be used as output power supply for a ST Zio shield or an extension board. In this case, the maximum current of the power source specified in [Table 6: External power sources](#) must be respected.

The +3.3 V (CN8 pin 7 or CN11 pin 16) can be used also as power supply output. The current is limited by the maximum current capability of the regulator U6 (500 mA max).

6.4 LEDs

User LD1: a green user LED is connected to STM32 I/O PB0 (SB120 ON and SB119 OFF) or PA5 (SB119 ON and SB120 OFF) corresponding to ST Zio D13.

User LD2: a blue user LED is connected to PB7.

User LD3: a red user LED is connected to PB14.

These user LEDs are on when the I/O is HIGH value, and it is off when the I/O is LOW.

LD4 COM: the tricolor LED (green, orange, red) LD4 provides information about ST-LINK communication status. LD4 default color is red. LD4 turns to green to indicate that communication is in progress between the PC and the ST-LINK/V2-1, with the following setup:

- Slow blinking red/off: at power-on before USB initialization
- Fast blinking red/off: after the first correct communication between PC and ST-LINK/V2-1 (enumeration)
- Red LED on: when the initialization between the PC and ST-LINK/V2-1 is complete
- Green LED on: after a successful target communication initialization
- Blinking red/green: during communication with target
- Green on: communication finished and successful
- Orange on: communication failure

LD5 USB power fault: LD5 indicates that the board power consumption on USB exceeds 500mA, consequently the user must power the board using an external power supply.

LD6 PWR: the green LED indicates that the STM32 part is powered and +5V power is available on CN8 pin 9 and CN11 pin 18.

LD7 and LD8 USB FS: refer to [Section 6.9: USB FS OTG or device](#).

6.5 Push buttons

B1 USER: the user button is connected to the I/O PC13 by default (Tamper support, SB173 ON and SB180 OFF) or PA0 (Wakeup support, SB180 ON and SB173 OFF) of the STM32 microcontroller.

B2 RESET: this push button is connected to NRST and is used to RESET the STM32 microcontroller.

6.6 JP5 (IDD)

Jumper JP5, labeled IDD, is used to measure the STM32 microcontroller consumption by removing the jumper and by connecting an ammeter.

- JP5 ON: STM32 is powered (default).
- JP5 OFF: an ammeter must be connected to measure STM32 current. If there is no ammeter, the STM32 is not powered.

In order to get a correct current consumption, Ethernet PHY should be set in power down mode or SB13 should be removed. Refer to [Section 6.10: Ethernet](#) for details.

6.7 OSC clock

6.7.1 OSC clock supply

There are four ways to configure the pins corresponding to external high-speed clock (HSE):

- **MCO from ST-LINK (Default):** MCO output of ST-LINK is used as input clock. This frequency cannot be changed, it is fixed at 8 MHz and connected to PF0/PH0-OSC_IN of STM32 microcontroller. The following configuration is needed:
 - SB148 OFF
 - SB112 and SB149 ON
 - SB8 and SB9 OFF
- **HSE oscillator on-board from X3 crystal (not provided):** for typical frequencies and its capacitors and resistors, refer to STM32 microcontroller datasheet and to the AN2867 for oscillator design guide. The X3 crystal has the following characteristics: 8 MHz, 8 pF, 20 ppm. It is recommended to use NX3225GD-8.000M-EXS00A-CG04874 manufactured by NIHON DEMPA KOGYO CO., LTD. The following configuration is needed:
 - SB148 and SB163 OFF
 - SB8 and SB9 soldered
 - C37 and C38 soldered with 4.3 pF capacitors
 - SB112 and SB149 OFF
- **Oscillator from external PF0/PH0:** from an external oscillator through pin 29 of CN11 connector. The following configuration is needed:
 - SB148 ON
 - SB112 and SB149 OFF
 - SB8 and SB9 removed

- **HSE not used:** PF0/PH1 and PF1/PH1 are used as GPIOs instead of clock. The following configuration is needed:
 - SB148 and SB163 ON
 - SB112 and SB149 (MCO) OFF
 - SB8 and SB9 removed

6.7.2 OSC 32 KHz clock supply

There are three ways to configure the pins corresponding to low-speed clock (LSE):

- **On-board oscillator (Default):** X2 crystal. Refer to the AN2867 for oscillator design guide for STM32 microcontrollers. It is recommended to use NX3214SA-32.768KHZ-EXS00A-MU00525 (32.768KHz, 6pF load capacitance, 200ppm) from Nihon Dempa Kogyo CO, LTD.

Note: For STM32F0 and STM32F3 series it is recommended to use the low drive mode configuration of the LSE (low drive capability in LSEDRV register), due to the 6pF load capacitance of the crystal on board.

- **Oscillator from external PC14:** from external oscillator through the pin 25 of CN11 connector. The following configuration is needed:
 - SB144 and SB145 ON
 - R37 and R38 removed
- **LSE not used:** PC14 and PC15 are used as GPIOs instead of low speed clock. The following configuration is needed:
 - SB144 and SB145 ON
 - R37 and R38 removed

6.8 USART communication

The USART3 interface available on PD8 and PD9 of the STM32 can be connected to ST-LINK or to ST morpho connector. The choice can be changed by setting the related solder bridges. By default the USART3 communication between the target STM32 and ST-LINK is enabled, in order to support Virtual Com Port for mbed (SB5 and SB6 ON).

Table 8. USART3 pins

Pin name	Function	Virtual Com Port (default configuration)	ST morpho connection
PD8	USART3 TX	SB5 ON and SB7 OFF	SB5 OFF and SB7 ON
PD9	USART3 RX	SB6 ON and SB4 OFF	SB6 OFF and SB4 ON

6.9 USB FS OTG or device

The STM32 Nucleo-144 board supports USB OTG or device full speed communication via a USB Micro-AB connector (CN13) and USB power switch (U12) connected to VBUS.

Note: NUCLEO-F303ZE supports the USB device FS only. All the other STM32 Nucleo-144 support the USB OTG.

Warning: USB Micro-AB connector (CN13) cannot power the Nucleo-144 board. In order to avoid damaging the STM32, it is mandatory to power the Nucleo-144 before connecting a USB cable on CN13. Otherwise there is a risk of current injection on STM32 IOs.

A green LED LD8 will be lit in one of these cases:

- Power switch (U12) is ON and STM32 Nucleo-144 board works as a USB host
- VBUS is powered by another USB host when STM32 Nucleo-144 board works as a USB device.

The red LED LD7 will be lit if over-current occurs when +5V is enabled on VBUS in USB host mode.

- Note:*
1. It is better to power Nucleo-144 board by external power supply when using USB OTG or host function.
 2. JP4 must be closed when using USB OTG FS.

NUCLEO-F303ZE does not support OTG function but it supports USB 2.0 full speed device mode communication via a USB Micro-AB connector (CN13). USB disconnection simulation can be implemented by PG6, which can control 1.5 K pull-up resistor (R70) on USB D+ line. Detection of 5 V power on USB connector (CN13) is available on PG7 thanks to R62 and R63 resistors bridge.

Table 9. USB pins configuration

Pin name	Function	Configuration when using USB connector	Configuration when using ST morpho connector	Remark
PA8	USB SOF	-	-	Test point TP1
PA9	USB VBUS	SB127 ON	SB127 OFF	Not on NUCLEO-F303ZE
PA10	USB ID	SB125 ON	SB125 OFF	Not on NUCLEO-F303ZE
PA11	USB DM	SB133 ON	SB133 OFF	-
PA12	USB DP	SB132 ON	SB132 OFF	-
PG6	USB GPIO OUT	NUCLEO-F303ZE: SB186 ON, SB187 OFF	NUCLEO-F303ZE: SB186 OFF	NUCLEO-F303ZE: D+ pull up control
		All others Nucleo: SB186 OFF, SB187 ON	All others Nucleo: SB187 OFF	All others Nucleo: USB power switch control

Table 9. USB pins configuration (continued)

Pin name	Function	Configuration when using USB connector	Configuration when using ST morpho connector	Remark
PG7	USB GPIO IN	NUCLEO-F303ZE: JP4 ON, SB184 ON, SB185 OFF	JP4 OFF	NUCLEO-F303ZE: VBUS detection
		All others Nucleo: JP4 ON, SB184 OFF SB185 ON		All others Nucleo: USB Over current alarm

ESD protection part ESDA6V1BC6 is implemented on USB port because all USB pins on STM32 can be used as VBUS or GPIO on STM32 Nucleo-144 board.

Note: If these pins are dedicated to USB port only, the USBLC6-4SC6 protection part is more suitable to protect USB port. If USB pin ID is not used, USBLC6-2SC6 can be used.

6.10 Ethernet

The STM32 Nucleo-144 board supports 10M/100M Ethernet communication by a PHY LAN8742A-CZ-TR (U9) and RJ45 connector (CN14). Ethernet PHY is connected to STM32 microcontroller via RMII interface. 50 MHz clock for the STM32 microcontroller is generated by the PHY RMII_REF_CLK.

Note:

1. NUCLEO-F303ZE, and NUCLEO-F446ZE do not support Ethernet function.
2. JP6 and JP7 must be closed when using Ethernet.
3. Ethernet PHY LAN8742A should be set in power down mode (Ethernet PHY ref clock will be turned off in this mode) to achieve the expected low power mode current. This is done by configuring Ethernet PHY LAN8742A Basic Control Register (at address 0x00) Bit 11 (Power Down) to '1'. SB13 can be also removed to get the same effect.

Table 10. Ethernet pins

Pin name	Function	Conflict with ST Zio connector signal	Configuration when using Ethernet	Configuration when using ST Zio or ST morpho connector
PA1	RMII Reference Clock	-	SB13 ON	SB13 OFF
PA2	RMII MDIO	-	SB160 ON	SB160 OFF
PC1	RMII MDC	-	SB164 ON	SB164 OFF
PA7	RMII RX Data Valid	D11	JP6 ON	JP6 OFF
PC4	RMII RXD0	-	SB178 ON	SB178 OFF
PC5	RMII RXD1	-	SB181 ON	SB181 OFF
PG11	RMII TX Enable	-	SB183 ON	SB183 OFF
PG13	RXII TXD0	-	SB182 ON	SB182 OFF
PB13	RMII TXD1	I2S_A_CK	JP7 ON	JP7 OFF

6.11 Solder bridges

SBxx can be found on top layer and SB1xx can be found on bottom layer.

Table 11. Solder bridges

Bridge	State ⁽¹⁾	Description
SB2 (+3V3_PER)	ON	Peripheral power +3V3_PER is connected to +3V3.
	OFF	Peripheral power +3V3_PER is not connected.
SB3 (3.3V)	ON	Output of voltage regulator LD39050PU33R is connected to 3.3V.
	OFF	Output of voltage regulator LD39050PU33R is not connected.
SB7, SB4 (GPIO)	ON	PD8 and PD9 on STM32 are connected to ST morpho connectors CN11 and CN12. If these pins are used on ST morpho connectors, SB5 and SB6 should be OFF.
	OFF	PD8 and PD9 on STM32 are disconnected to ST morpho connectors CN11 and CN12.
SB5, SB6 (ST-LINK-USART)	ON	PA2 and PA3 on ST-LINK STM32F103CBT6 are connected to PD8 and PD9 to enable Virtual Com Port for mbed support. Thus PD8 and PD9 on ST morpho connectors cannot be used.
	OFF	PA2 and PA3 on ST-LINK STM32F103CBT6 are disconnected to PD8 and PD9 on STM32.
SB12 (VDDA)	ON	VDDA on STM32 is connected to VDD.
	OFF	VDDA on STM32 is not connected to VDD and can be provided from pin 7 of CN12 and pin 1 of CN10.
SB101,103,105,108 (DEFAULT)	ON	Reserved, do not modify.
SB102,104,106,109 (RESERVED)	OFF	Reserved, do not modify.
SB107 (STM_RST)	OFF	No incidence on ST-LINK STM32F103CBT6 NRST signal.
	ON	ST-LINK STM32F103CBT6 NRST signal is connected to GND (ST-LINK reset to reduce power consumption).
SB110 (SWO)	ON	SWO signal of the STM32 (PB3) is connected to ST-LINK SWO input.
	OFF	SWO signal of STM32 is not connected.
SB111 (NRST)	ON	Board RESET signal (NRST) is connected to ST-LINK reset control IO (T_Nrst).
	OFF	Board RESET signal (NRST) is not connected to ST-LINK reset control IO (T_Nrst).
SB113, SB114 (IOREF)	OFF, ON	IOREF is connected to +3V3.
	ON, OFF	IOREF is connected to +3V3_PER.
SB116 (SDMMC_D0), SB117 (SDMMC_D1)	ON	These pins are connected to ST morpho connector CN12.
	OFF	These pins are disconnected from ST morpho connector CN12 to avoid stub of SDMMC data signals on PCB.

Table 11. Solder bridges (continued)

Bridge	State ⁽¹⁾	Description
SB120, SB119 (LD1-LED)	ON, OFF	Green user LED LD1 is connected to PB0.
	OFF,ON	Green user LED LD1 is connected to D13 of Arduino signal (PA5).
	OFF,OFF	Green user LED LD1 is not connected.
	ON,ON	Forbidden
SB139 (LD2-LED)	ON	Blue user LED LD2 is connected to PB7.
	OFF	Blue user LED LD2 is not connected.
SB118 (LD3-LED)	ON	Red user LED LD3 is connected to PB14.
	OFF	Red user LED LD3 is not connected.
SB121, SB122 (D11)	ON, OFF	D11 (Pin 14 of CN7) is connected to STM32 PA7 (SPI_A_MOSI/TIM_E_PWM1).
	OFF,ON	D11 (Pin 14 of CN7) is connected to STM32 PB5 (SPI_A_MOSI/TIM_D_PWM2).
SB144,145 (X2 crystal)	OFF	PC14, PC15 are not connected to ST morpho connector CN11. (X2 used to generate 32 KHz clock).
	ON	PC14, PC15 are connected to ST morpho connector CN11. (R37 and R38 should be removed).
SB148 (PF0/PH0), SB163 (PF1/PH1) (Main clock)	OFF, ON	PF0/PH0 is not connected to ST morpho PF1/PH1 is connected to ST morpho connector CN11 (MCO is used as main clock for STM32 on PF0/PH0).
	OFF,OFF	PF0/PH0, PF1/PH1 are not connected to ST morpho connector CN11 (X3, C37, C38, SB8 and SB9 provide a clock as shown in Section 7: Electrical schematics . In this case SB149 must be removed).
	ON, ON	PF0/PH0 and PF1/PH1 are connected to ST morpho connector CN11. (SB8, SB9 and SB149 must be removed).
SB112, SB149 (MCO)	ON	MCO of ST-LINK (STM32F103CBT6) is connected to PF0/PH0 of STM32.
	OFF	MCO of ST-LINK (STM32F103CBT6) is not connected to PF0/PH0 of STM32.
SB8, SB9 (external 8M crystal)	OFF	PF0/PH0 and PF1/PH1 are not connected to external 8 MHz crystal X3.
	ON	PF0/PH0 and PF1/PH1 are connected to external 8 MHz crystal X3.
SB156 (VBAT)	ON	VBAT pin of STM32 is connected to VDD.
	OFF	VBAT pin of STM32 is not connected to VDD.
SB173, SB180 (B1-USER)	ON, OFF	B1 pushbutton is connected to PC13.
	OFF,ON	B1 pushbutton is connected to PA0 (Set SB179 OFF if ST Zio connector is used).
	OFF,OFF	B1 pushbutton is not connected.
SB179 (PA0)	ON	PA0 is connected to ST Zio connector (Pin 29 of CN10)
	OFF	PA0 is not connected to ST Zio connector (Pin 29 of CN10)

Table 11. Solder bridges (continued)

Bridge	State ⁽¹⁾	Description
SB142, SB152 (BOOT1, Only for F2 and F4 series)	OFF, OFF	BOOT1 (PB2) function is not used.
	ON, OFF	BOOT1 (PB2) is pulled up.
	OFF, ON	BOOT1 (PB2) is pulled down.
	ON, ON	Forbidden
SB147, SB157 (A4 and A5) Or SB167, SB171 (only for NUCLEO-F303ZE)	ON	ADC_IN are connected to A4 and A5 (pin 9 and 11) on ST Zio connector CN9. Thus SB138 and SB143 must be OFF.
	OFF	ADC_IN are not connected to A4 and A5 (pin 9 and 11) on ST Zio connector CN9.
SB138, SB143 (I2C on A4 and A5)	OFF	PB9 and PB8 (I2C) are not connected to A4 and A5 (pin 9 and 11) on ST Zio connector CN9.
	ON	PB9 and PB8 (I2C) are connected to A4 and A5 (pin 9 and 11) on ST Zio connector CN9. Thus SB147 and SB157 (or SB167 and SB171 for NUCLEO-F303ZE) must be OFF.
RMII Signals SB13 (PA1), SB164 (PC1), SB160 (PA2), SB178 (PC4), SB181 (PC5), SB182 (PG13), SB183 (PG11)	ON	These pins are used as RMII signals and connected to Ethernet PHY. These port must not be used on ST morpho or ST Zio connectors.
	OFF	These pins are used as GPIOs on ST morpho connectors and not connected to Ethernet PHY.
SB177 (Ethernet nRST)	ON	NRST of STM32 is connected to Ethernet PHY (U9).
	OFF	NRST of STM32 is not connected to Ethernet PHY (U9).
USB signals: SB186 (NUCLEO-F303ZE) or SB187 (all others Nucleo) (PG6)	ON	PG6 is connected to R70 to control USB D+ pull up (NUCLEO-F303ZE) PG6 is connected to 5V switch Enable (U12) to control VBUS or CN13 (All other NUCLEO).
	OFF	This pin is used as GPIO on ST morpho connectors.
SB132 (PA12), SB133 (PA11)	ON	These pins are used as D+ and D- on USB connector CN13.
	OFF	These pins are used as GPIOs on ST morpho connectors.

1. Default SBx state is shown in bold.

All the other solder bridges present on the STM32 Nucleo-144 board are used to configure several IOs and power supply pins for compatibility of features and pinout with STM32 supported.

All STM32 Nucleo-144 boards are delivered with the solder-bridges configured according to the target STM32 supported.

6.12 Extension connectors

The following figures show the signals connected by default to ST Zio (including support for Arduino Uno Revision 3) connectors (CN7, CN8, CN9, CN10), for each STM32 Nucleo-144 board.

Figure 9. NUCLEO-F746ZG/F429ZI/F207ZG




Figure 10. NUCLEO-F303ZE





Figure 11. NUCLEO-F446ZE



6.13 ST Zio connectors

CN7, CN8, CN9 and CN10 are female on top side and male on bottom side connectors. They include support for Arduino Uno Revision 3. Most shields designed for Arduino Uno can fit to the STM32 Nucleo-144 boards.

To cope with Arduino Uno Revision 3, apply the following modifications:

- SB138 and SB143 should be ON
- SB140/147/150/157/167/171 should be OFF to connect I2C on A4 (pin 5) and A5 (pin 6 of CN8).

Caution: The IOs of STM32 microcontroller are 3.3 V compatible instead of 5 V for Arduino Uno.

Table 12 to Table 16 show the pin assignment for each main STM32 microcontroller on ST Zio connectors.

Table 12. NUCLEO-F746ZG pin assignments

Connector	Pin	Pin name	Signal name	STM32 pin	Function	Remark	
Left connectors							
CN8	1	NC	NC	-	-	Arduino support	
	3	IOREF	IOREF	-	3.3V Ref		
	5	RESET	RESET	NRST	RESET		
	7	+3V3	+3V3	-	3.3V input/output		
	9	+5V	+5V	-	5V output		
	11	GND	GND	-	Ground		
	13	GND	GND	-	Ground		
	15	VIN	VIN	-	Power input		
	2	D43	SDMMC_D0	PC8	SDMMC/I2S_A	-	
	4	D44	SDMMC_D1/ I2S_A_CKIN	PC9			
	6	D45	SDMMC_D2	PC10			
	8	D46	SDMMC_D3	PC11			
	10	D47	SDMMC_CK	PC12			
	12	D48	SDMMC_CMD	PD2			
	14	D49	I/O	PG2	I/O		
	16	D50	I/O	PG3			
CN9	1	A0	ADC	PA3	ADC123_IN3		Arduino support
	3	A1	ADC	PC0	ADC123_IN10		
	5	A2	ADC	PC3	ADC123_IN13		
	7	A3	ADC	PF3	ADC3_IN9		
	9	A4	ADC	PF5 or PB9 ⁽¹⁾	ADC3_IN15 (PF5) or I2C1_SDA (PB9)		
	11	A5	ADC	PF10 or PB8 ⁽¹⁾	ADC3_IN8 (PF10) or I2C1_SCL (PB8)		

Table 12. NUCLEO-F746ZG pin assignments (continued)

Connector	Pin	Pin name	Signal name	STM32 pin	Function	Remark
CN9	13	D72	NC	-	-	-
	15	D71	I/O	PA7 ⁽²⁾	I/O	
	17	D70	I2C_B_SMBA	PF2	I2C_2	
	19	D69	I2C_B_SCL	PF1		
	21	D68	I2C_B_SDA	PF0		
	23	GND	GND	-	Ground	
	25	D67	CAN_RX	PD0	CAN_1	
	27	D66	CAN_TX	PD1		
	29	D65	I/O	PG0	I/O	
	2	D51	USART_B_SCLK	PD7	USART_2	
	4	D52	USART_B_RX	PD6		
	6	D53	USART_B_TX	PD5		
	8	D54	USART_B_RTS	PD4		
	10	D55	USART_B_CTS	PD3		
	12	GND	GND	-	Ground	
	14	D56	SAI_A_MCLK	PE2 ⁽³⁾	SAI_1_A	
	16	D57	SAI_A_FS	PE4		
	18	D58	SAI_A_SCK	PE5		
	20	D59	SAI_A_SD	PE6		
	22	D60	SAI_B_SD	PE3	SAI_1_B	
24	D61	SAI_B_SCK	PF8			
26	D62	SAI_B_MCLK	PF7			
28	D63	SAI_B_FS	PF9			
30	D64	I/O	PG1	I/O		
Right Connectors						
CN7	1	D16	I2S_A_MCK	PC6	I2S_2	-
	3	D17	I2S_A_SD	PB15		
	5	D18	I2S_A_CK	PB13 ⁽⁴⁾		
	7	D19	I2S_A_WS	PB12		
	9	D20	I2S_B_WS	PA15	I2S_3 / SPI3	
	11	D21	I2S_B_MCK	PC7		
	13	D22	I2S_B_SD/ SPI_B_MOSI	PB5		
	15	D23	I2S_B_CK/ SPI_B_SCK	PB3		
	17	D24	SPI_B_NSS	PA4		
	19	D25	SPI_B_MISO	PB4		
	2	D15	I2C_A_SCL	PB8	I2C1_SCL	

Table 12. NUCLEO-F746ZG pin assignments (continued)

Connector	Pin	Pin name	Signal name	STM32 pin	Function	Remark	
CN7	4	D14	I2C_A_SDA	PB9	I2C1_SDA		
	6	AREF	AREF	-	AVDD		
	8	GND	GND	-	Ground		
	10	D13	SPI_A_SCK	PA5	SPI1_SCK		
	12	D12	SPI_A_MISO	PA6	SPI1_MISO		
	14	D11	SPI_A_MOSI/ TIM_E_PWM1	PA7 ⁽¹⁾⁽²⁾ or PB5 ⁽¹⁾	SPI1_MOSI/ TIM14_CH1		
	16	D10	SPI_A_CS/ TIM_B_PWM3	PD14	SPI1_CS/ TIM4_CH3		
	18	D9	TIMER_B_PWM2	PD15	TIM4_CH4		
	20	D8	I/O	PF12	-		
CN10	1	AVDD	AVDD	-	Analog VDD		
	3	AGND	AGND	-	Analog Ground		
	5	GND	GND	-	Ground		
	7	A6	ADC_A_IN	PB1	ADC12_IN9		
	9	A7	ADC_B_IN	PC2	ADC123_IN12		
	11	A8	ADC_C_IN	PF4	ADC3_IN14		
	13	D26	QSPI_CS	PB6	QSPI_BK1		
	15	D27	QSPI_CLK	PB2	QSPI_CLK		
	17	GND	GND	-	Ground		
	19	D28	QSPI_BK1_IO3	PD13	QSPI_BK1		
	21	D29	QSPI_BK1_IO1	PD12			
	23	D30	QSPI_BK1_IO0	PD11			
	25	D31	QSPI_BK1_IO2	PE2 ⁽³⁾			
	27	GND	GND	-	Ground		
	29	D32	TIMER_C_PWM1	PA0	TIM2_CH1		
	31	D33	TIMER_D_PWM1	PB0	TIM3_CH3		
	33	D34	TIMER_B_ETR	PE0	TIM4_ETR		
	2	D7	I/O	PF13	-		Arduino support
	4	D6	TIMER_A_PWM1	PE9	TIM1_CH1		
	6	D5	TIMER_A_PWM2	PE11	TIM1_CH2		
	8	D4	I/O	PF14	-		
	10	D3	TIMER_A_PWM3	PE13	TIM1_CH3		
12	D2	I/O	PF15	-			
14	D1	USART_A_TX	PG14	USART6			
16	D0	USART_A_RX	PG9				
18	D42	TIMER_A_PWM1N	PE8	TIM1_CH1N			
20	D41	TIMER_A_ETR	PE7	TIM1_ETR			
22	GND	GND	-	Ground			

Table 12. NUCLEO-F746ZG pin assignments (continued)

Connector	Pin	Pin name	Signal name	STM32 pin	Function	Remark
CN10	24	D40	TIMER_A_PWM2N	PE10	TIM1_CH2N	-
	26	D39	TIMER_A_PWM3N	PE12	TIM1_CH3N	
	28	D38	I/O	PE14	I/O	
	30	D37	TIMER_A_BKIN1	PE15	TIM1_BKIN1	
	32	D36	TIMER_C_PWM2	PB10	TIM2_CH3	
	34	D35	TIMER_C_PWM3	PB11	TIM2_CH4	

1. Refer to [Table 11: Solder bridges](#) for details.
2. PA7 is used as D11 and connected to CN7 pin 14 by default, if JP6 is ON, it is also connected to both Ethernet PHY as RMII_DV and CN9 pin 15. In this case only one function of Ethernet or D11 could be used.
3. PE2 is connected to both CN9 pin 14 (SAI_A_MCLK) and CN10 pin 25 (QSPI_BK1_IO2). Only one function can be used at one time.
4. PB13 is used as I2S_A_CK and connected to CN7 pin 5 by default, if JP7 is ON, it is also connected to Ethernet PHY as RMII_TXD1. In this case only one function of Ethernet or I2S_A could be used.

Table 13. NUCLEO-F446ZE pin assignments

Connector	Pin	Pin name	Signal name	STM32 pin	Function	Remark
Left connectors						
CN8	1	NC	NC	-	-	Arduino support
	3	IOREF	IOREF	-	3.3V Ref	
	5	RESET	RESET	NRST	RESET	
	7	+3V3	+3V3	-	3.3V input/output	
	9	+5V	+5V	-	5V output	
	11	GND	GND	-	Ground	
	13	GND	GND	-	Ground	
	15	VIN	VIN	-	Power input	
	2	D43	SDMMC_D0	PC8	SDMMC/I2S_A	-
	4	D44	SDMMC_D1/ I2S_A_CKIN	PC9		
	6	D45	SDMMC_D2	PC10		
	8	D46	SDMMC_D3	PC11		
	10	D47	SDMMC_CK	PC12		
	12	D48	SDMMC_CMD	PD2		
	14	D49	I/O	PG2	I/O	
	16	D50	I/O	PG3		

Table 13. NUCLEO-F446ZE pin assignments (continued)

Connector	Pin	Pin name	Signal name	STM32 pin	Function	Remark	
CN9	1	A0	ADC	PA3	ADC123_IN3	Arduino support	
	3	A1	ADC	PC0	ADC123_IN10		
	5	A2	ADC	PC3	ADC123_IN13		
	7	A3	ADC	PF3	ADC3_IN9		
	9	A4	ADC	PF5 or PB9 ⁽¹⁾	ADC3_IN15 (PF5) or I2C1_SDA (PB9)		
	11	A5	ADC	PF10 or PB8 ⁽¹⁾	ADC3_IN8 (PF10) or I2C1_SCL (PB8)		
		13	D72	NC	-	-	-
		15	D71	NC	-	-	
		17	D70	I2C_B_SMBA	PF2	I2C_2	
		19	D69	I2C_B_SCL	PF1		
		21	D68	I2C_B_SDA	PF0		
		23	GND	GND	-	Ground	
		25	D67	CAN_RX	PD0	CAN_1	
		27	D66	CAN_TX	PD1		
		29	D65	I/O	PG0	I/O	
CN9	2	D51	USART_B_SCLK	PD7	USART_2	-	
	4	D52	USART_B_RX	PD6			
	6	D53	USART_B_TX	PD5			
	8	D54	USART_B_RTS	PD4			
	10	D55	USART_B_CTS	PD3			
		12	GND	GND	-		Ground
		14	D56	SAI_A_MCLK	PE2 ⁽²⁾		SAI_1_A
		16	D57	SAI_A_FS	PE4		
		18	D58	SAI_A_SCK	PE5		
		20	D59	SAI_A_SD	PE6		SAI_1_B
		22	D60	SAI_B_SD	PE3		
		24	D61	SAI_B_SCK	PF8		
		26	D62	SAI_B_MCLK	PF7		
		28	D63	SAI_B_FS	PF9		
		30	D64	I/O	PG1		I/O
Right Connectors							
CN7	1	D16	I2S_A_MCK	PC6	I2S_2	-	
	3	D17	I2S_A_SD	PB15			

Table 13. NUCLEO-F446ZE pin assignments (continued)

Connector	Pin	Pin name	Signal name	STM32 pin	Function	Remark
CN7	3	D17	I2S_A_SD	PB15	I2S_2	-
	5	D18	I2S_A_CK	PB13		
	7	D19	I2S_A_WS	PB12		
	9	D20	I2S_B_WS	PA15	I2S_3 / SPI3	
	11	D21	I2S_B_MCK	PC7		
	13	D22	I2S_B_SD/ SPI_B_MOSI	PB5		
	15	D23	I2S_B_CK/ SPI_B_SCK	PB3		
	17	D24	SPI_B_NSS	PA4		
	19	D25	SPI_B_MISO	PB4		
	2	D15	I2C_A_SCL	PB8		
	4	D14	I2C_A_SDA	PB9	I2C1_SDA	
	6	AREF	AREF	-	AVDD	
	8	GND	GND	-	Ground	
	10	D13	SPI_A_SCK	PA5	SPI1_SCK	
	12	D12	SPI_A_MISO	PA6	SPI1_MISO	
	14	D11	SPI_A_MOSI/ TIM_E_PWM1	PA7 ⁽¹⁾ or PB5 ⁽¹⁾	SPI1_MOSI/ TIM14_CH1	
	16	D10	SPI_A_CS/ TIM_B_PWM3	PD14	SPI1_CS/ TIM4_CH3	
	18	D9	TIMER_B_PWM2	PD15	TIM4_CH4	
	20	D8	I/O	PF12	-	
	CN10	1	AVDD	AVDD	-	
3		AGND	AGND	-	Analog Ground	
5		GND	GND	-	Ground	
7		A6	ADC_A_IN	PB1	ADC12_IN9	
9		A7	ADC_B_IN	PC2	ADC123_IN12	
11		A8	ADC_C_IN	PF4	ADC3_IN14	
13		D26	QSPI_CS	PB6	QSPI_BK1	
15		D27	QSPI_CLK	PB2	QSPI_CLK	
17		GND	GND	-	Ground	

Table 13. NUCLEO-F446ZE pin assignments (continued)

Connector	Pin	Pin name	Signal name	STM32 pin	Function	Remark	
CN10	19	D28	QSPI_BK1_IO3	PD13	QSPI_BK1	-	
	21	D29	QSPI_BK1_IO1	PD12			
	23	D30	QSPI_BK1_IO0	PD11			
	25	D31	QSPI_BK1_IO2	PE2 ⁽²⁾			
	27	GND	GND	-	Ground		
	29	D32	TIMER_C_PWM1	PA0	TIM2_CH1		
	31	D33	TIMER_D_PWM1	PB0	TIM3_CH3		
	33	D34	TIMER_B_ETR	PE0	TIM4_ETR		
	2	D7	I/O	PF13	-		Arduino support
	4	D6	TIMER_A_PWM1	PE9	TIM1_CH1		
	6	D5	TIMER_A_PWM2	PE11	TIM1_CH2		
	8	D4	I/O	PF14	-		
	10	D3	TIMER_A_PWM3	PE13	TIM1_CH3		
	12	D2	I/O	PF15	-		
	14	D1	USART_A_TX	PG14	USART6		
	16	D0	USART_A_RX	PG9			
	18	D42	TIMER_A_PWM1N	PE8	TIM1_CH1N	-	
	20	D41	TIMER_A_ETR	PE7	TIM1_ETR		
	22	GND	GND	-	Ground		
	24	D40	TIMER_A_PWM2N	PE10	TIM1_CH2N		
	26	D39	TIMER_A_PWM3N	PE12	TIM1_CH3N		
	28	D38	I/O	PE14	I/O		
	30	D37	TIMER_A_BKIN1	PE15	TIM1_BKIN1		
	32	D36	TIMER_C_PWM2	PB10	TIM2_CH3		
	34	D35	TIMER_C_PWM3	PB11	TIM2_CH4		

1. Refer to [Table 11: Solder bridges](#) for details.
2. PE2 is connected to both CN9 pin 14 (SAI_A_MCLK) and CN10 pin 25 (QSPI_BK1_IO2). Only one function can be used at one time.

Table 14. NUCLEO-F303ZE pin assignments

Connector	Pin	Pin name	Signal name	STM32 pin	Function	Remark
Left connectors						
CN8	1	NC	NC	-	-	Arduino support
	3	IOREF	IOREF	-	3.3V Ref	
	5	RESET	RESET	NRST	RESET	
	7	+3V3	+3V3	-	3.3V input/output	
	9	+5V	+5V	-	5V output	
	11	GND	GND	-	Ground	
	13	GND	GND	-	Ground	
	15	VIN	VIN	-	Power input	
	2	D43	I/O	PC8	I/O	-
	4	D44	I2S_A_CKIN	PC9	I2S_A	
	6	D45	I/O	PC10	I/O	
	8	D46	I/O	PC11		
	10	D47	I/O	PC12		
	12	D48	I/O	PD2	I/O	
	14	D49	I/O	PG2		
	16	D50	I/O	PG3	I/O	
CN9	1	A0	ADC	PA3	ADC1_IN4	Arduino support
	3	A1	ADC	PC0	ADC12_IN6	
	5	A2	ADC	PC3	ADC12_IN9	
	7	A3	ADC	PD11	ADC34_IN8	
	9	A4	ADC	PD12 or PB9 ⁽¹⁾	ADC34_IN9 (PD12) or I2C1_SDA (PB9)	
	11	A5	ADC	PD13 or PB8 ⁽¹⁾	ADC34_IN10 (PD13) or I2C1_SCL (PB8)	
	13	D72	COMP1_INP	PA1	COMP	-
	15	D71	COMP2_INP	PA7 ⁽²⁾		
	17	D70	I2C_B_SMBA	PA8	I2C_2	
	19	D69	I2C_B_SCL	PA9		
	21	D68	I2C_B_SDA	PA10		
	23	GND	GND	-	Ground	
	25	D67	CAN_RX	PD0	CAN_1	
27	D66	CAN_TX	PD1			
29	D65	I/O	PG0	I/O		

Table 14. NUCLEO-F303ZE pin assignments (continued)

Connector	Pin	Pin name	Signal name	STM32 pin	Function	Remark
CN9	2	D51	USART_B_SCLK	PD7	USART_2	
	4	D52	USART_B_RX	PD6		
	6	D53	USART_B_TX	PD5		
	8	D54	USART_B_RTS	PD4		
	10	D55	USART_B_CTS	PD3		
	12	GND	GND	-	Ground	
	14	D56	I/O	PE2 ⁽³⁾	I/O	
	16	D57	I/O	PE4		
	18	D58	I/O	PE5		
	20	D59	I/O	PE6	I/O	
	22	D60	I/O	PE3		
	24	D61	I/O	PF8		
	26	D62	I/O	PF7		
	28	D63	I/O	PF9		
30	D64	I/O	PG1	I/O		
Right Connectors						
CN7	1	D16	I2S_A_MCK	PC6	I2S_2	
	3	D17	I2S_A_SD	PB15		
	5	D18	I2S_A_CK	PB13		
	7	D19	I2S_A_WS	PB12		
	9	D20	I2S_B_WS	PA15	I2S_3 / SPI3	
	11	D21	I2S_B_MCK	PC7		
	13	D22	I2S_B_SD/ SPI_B_MOSI	PB5		
	15	D23	I2S_B_CK/ SPI_B_SCK	PB3		
	17	D24	SPI_B_NSS	PA4		
	19	D25	SPI_B_MISO	PB4		
	2	D15	I2C_A_SCL	PB8		I2C1_SCL
	4	D14	I2C_A_SDA	PB9	I2C1_SDA	
	6	AREF	AREF	-	AVDD	Arduino support
	8	GND	GND	-	Ground	
	10	D13	SPI_A_SCK	PA5	SPI1_SCK	
	12	D12	SPI_A_MISO	PA6	SPI1_MISO	
	14	D11	SPI_A_MOSI/ TIM_E_PWM1	PA7 ⁽¹⁾⁽²⁾ or PB5 ⁽¹⁾	SPI1_MOSI/ TIM14_CH1	

Table 14. NUCLEO-F303ZE pin assignments (continued)

Connector	Pin	Pin name	Signal name	STM32 pin	Function	Remark	
CN7	16	D10	SPI_A_CS/ TIM_B_PWM3	PD14	SPI1_CS/ TIM4_CH3	Arduino support	
	18	D9	TIMER_B_PWM2	PD15	TIM4_CH4		
	20	D8	I/O	PF12	-		
CN10	1	AVDD	AVDD	-	Analog VDD	-	
	3	AGND	AGND	-	Analog Ground		
	5	GND	GND	-	Ground		
	7	A6	ADC_A_IN	PB1	ADC3_IN1		
	9	A7	ADC_B_IN	PC2	ADC12_IN8		
	11	A8	ADC_C_IN	PF4	ADC3_IN14		
	13	D26	I/O	PB6	I/O		
	15	D27	I/O	PB2			
	17	GND	GND	-	Ground		
	19	D28	I/O	PF10	I/O		
	21	D29	I/O	PF5			
	23	D30	I/O	PF3			
	25	D31	I/O	PE2 ⁽³⁾			
	27	GND	GND	-	Ground		
	29	D32	TIMER_C_PWM1	PA0	TIM2_CH1		
	31	D33	TIMER_D_PWM1	PB0	TIM3_CH3		
	33	D34	TIMER_B_ETR	PE0	TIM4_ETR		
	2	D7	I/O	PF13	-		Arduino support
	4	D6	TIMER_A_PWM1	PE9	TIM1_CH1		
6	D5	TIMER_A_PWM2	PE11	TIM1_CH2			
8	D4	I/O	PF14	-			

Table 14. NUCLEO-F303ZE pin assignments (continued)

Connector	Pin	Pin name	Signal name	STM32 pin	Function	Remark
CN10	10	D3	TIMER_A_PWM3	PE13	TIM1_CH3	-
	12	D2	I/O	PF15	-	
	14	D1	USART_A_TX	PC4	USART1	
	16	D0	USART_A_RX	PC5		
	18	D42	TIMER_A_PWM1N	PE8	TIM1_CH1N	
	20	D41	TIMER_A_ETR	PE7	TIM1_ETR	
	22	GND	GND	-	Ground	
	24	D40	TIMER_A_PWM2N	PE10	TIM1_CH2N	
	26	D39	TIMER_A_PWM3N	PE12	TIM1_CH3N	
	28	D38	TIMER_A_BKIN2	PE14	TIM1_BKIN2	
	30	D37	TIMER_A_BKIN1	PE15	TIM1_BKIN1	
	32	D36	TIMER_C_PWM2	PB10	TIM2_CH3	
	34	D35	TIMER_C_PWM3	PB11	TIM2_CH4	

1. Refer to [Table 11: Solder bridges](#) for details.
2. PA7 is used as D11 and connected to CN7 pin 14 by default, if JP6 is ON, it is also connected to CN9 pin 15 as COMP2_INP. In this case only one function of Comparator input or D11 could be used.
3. PE2 is connected to both CN9 pin 14 (IO) and CN10 pin 25 (IO). Only one connector pin can be used at one time.

Table 15. NUCLEO-F207ZG pin assignments

Connector	Pin	Pin name	Signal name	STM32 pin	Function	Remark	
Left connectors							
CN8	1	NC	NC	-	-	Arduino support	
	3	IOREF	IOREF	-	3.3V Ref		
	5	RESET	RESET	NRST	RESET		
	7	+3V3	+3V3	-	3.3V input/output		
	9	+5V	+5V	-	5V output		
	11	GND	GND	-	Ground		
	13	GND	GND	-			
	15	VIN	VIN	-	Power input		
	2	D43	SDMMC_D0	PC8	SDMMC/I2S_A		-
	4	D44	SDMMC_D1/ I2S_A_CKIN	PC9			
	6	D45	SDMMC_D2	PC10			
	8	D46	SDMMC_D3	PC11			
	10	D47	SDMMC_CK	PC12			
	12	D48	SDMMC_CMD	PD2			
	14	D49	I/O	PG2	I/O	-	
	16	D50	I/O	PG3			
CN9	1	A0	ADC	PA3	ADC123_IN3	Arduino support	
	3	A1	ADC	PC0	ADC123_IN10		
	5	A2	ADC	PC3	ADC123_IN13		
	7	A3	ADC	PF3	ADC3_IN9		
	9	A4	ADC	PF5 or PB9 ⁽¹⁾	ADC3_IN15 (PF5) or I2C1_SDA (PB9)		
	11	A5	ADC	PF10 or PB8 ⁽¹⁾	ADC3_IN8 (PF10) or I2C1_SCL (PB8)		
	13	D72	NC	-	-		-
	15	D71	I/O	PA7 ⁽²⁾	I/O		
	17	D70	I2C_B_SMBA	PF2	I2C_2		
	19	D69	I2C_B_SCL	PF1			
	21	D68	I2C_B_SDA	PF0			
	23	GND	GND	-	Ground		
	25	D67	CAN_RX	PD0	CAN_1		
	27	D66	CAN_TX	PD1			
29	D65	I/O	PG0	I/O			

Table 15. NUCLEO-F207ZG pin assignments (continued)

Connector	Pin	Pin name	Signal name	STM32 pin	Function	Remark	
CN9	2	D51	USART_B_SCLK	PD7	USART_2		
	4	D52	USART_B_RX	PD6			
	6	D53	USART_B_TX	PD5			
	8	D54	USART_B_RTS	PD4			
	10	D55	USART_B_CTS	PD3			
	12	GND	GND	-	Ground		
	14	D56	I/O	PE2 ⁽³⁾	I/O		
	16	D57	I/O	PE4			
	18	D58	I/O	PE5			
	20	D59	I/O	PE6			
	22	D60	I/O	PE3			
	24	D61	I/O	PF8			
	26	D62	I/O	PF7			
	28	D63	I/O	PF9			
30	D64	I/O	PG1				
Right Connectors							
CN7	1	D16	I2S_A_MCK	PC6	I2S_2		
	3	D17	I2S_A_SD	PB15			
	5	D18	I2S_A_CK	PB13 ⁽⁴⁾			
	7	D19	I2S_A_WS	PB12			
	9	D20	I2S_B_WS	PA15	I2S_3 / SPI3		
	11	D21	I2S_B_MCK	PC7			
	13	D22	I2S_B_SD/ SPI_B_MOSI	PB5			
	15	D23	I2S_B_CK/ SPI_B_SCK	PB3			
	17	D24	SPI_B_NSS	PA4			
	19	D25	SPI_B_MISO	PB4			
	2	D15	I2C_A_SCL	PB8	I2C1_SCL		Arduino support
	4	D14	I2C_A_SDA	PB9	I2C1_SDA		
	6	AREF	AREF	-	AVDD		
	8	GND	GND	-	Ground		
	10	D13	SPI_A_SCK	PA5	SPI1_SCK		
	12	D12	SPI_A_MISO	PA6	SPI1_MISO		
	14	D11	SPI_A_MOSI/ TIM_E_PWM1	PA7 ⁽¹⁾⁽²⁾ or PB5 ⁽¹⁾	SPI1_MOSI/ TIM14_CH1		
	16	D10	SPI_A_CS/ TIM_B_PWM3	PD14	SPI1_CS/ TIM4_CH3		
	18	D9	TIMER_B_PWM2	PD15	TIM4_CH4		
	20	D8	I/O	PF12	-		

Table 15. NUCLEO-F207ZG pin assignments (continued)

Connector	Pin	Pin name	Signal name	STM32 pin	Function	Remark	
CN10	1	AVDD	AVDD	-	Analog VDD	-	
	3	AGND	AGND		Analog Ground		
	5	GND	GND		Ground		
	7	A6	ADC_A_IN	PB1	ADC12_IN9		
	9	A7	ADC_B_IN	PC2	ADC123_IN12		
	11	A8	ADC_C_IN	PF4	ADC3_IN14		
	13	D26	I/O	PB6	I/O		
	15	D27	I/O	PB2			
	17	GND	GND	-	Ground		
	19	D28	I/O	PD13	I/O		
	21	D29	I/O	PD12			
	23	D30	I/O	PD11			
	25	D31	I/O	PE2 ⁽³⁾			
	27	GND	GND	-	Ground		
	29	D32	TIMER_C_PWM1	PA0	TIM2_CH1		
	31	D33	TIMER_D_PWM1	PB0	TIM3_CH3		
	33	D34	TIMER_B_ETR	PE0	TIM4_ETR		
	2	D7	I/O	PF13	-		Arduino support
	4	D6	TIMER_A_PWM1	PE9	TIM1_CH1		
	6	D5	TIMER_A_PWM2	PE11	TIM1_CH2		
	8	D4	I/O	PF14	-		
	10	D3	TIMER_A_PWM3	PE13	TIM1_CH3		
	12	D2	I/O	PF15	-		
	14	D1	USART_A_TX	PG14	USART6		
	16	D0	USART_A_RX	PG9	-		
	18	D42	TIMER_A_PWM1N	PE8	TIM1_CH1N		-
	20	D41	TIMER_A_ETR	PE7	TIM1_ETR		
	22	GND	GND	-	Ground		
	24	D40	TIMER_A_PWM2N	PE10	TIM1_CH2N		
	26	D39	TIMER_A_PWM3N	PE12	TIM1_CH3N		
	28	D38	I/O	PE14	I/O		
	30	D37	TIMER_A_BKIN1	PE15	TIM1_BKIN1		
	32	D36	TIMER_C_PWM2	PB10	TIM2_CH3		
	34	D35	TIMER_C_PWM3	PB11	TIM2_CH4		

1. Refer to [Table 11: Solder bridges](#) for details.
2. PA7 is used as D11 and connected to CN7 pin 14 by default, if JP6 is ON, it is also connected to both Ethernet PHY as RMII_DV and CN9 pin 15. In this case only one function of Ethernet or D11 could be used.
3. PE2 is connected to both CN9 pin 14 (IO) and CN10 pin 25 (IO). Only one connector pin can be used at one time.
4. PB13 is used as I2S_A_CK and connected to CN7 pin 5 by default, if JP7 is ON, it is also connected to Ethernet PHY as RMII_TXD1. In this case only one function of Ethernet or I2S_A could be used.

Table 16. NUCLEO-F429ZI pin assignments

Connector	Pin	Pin name	Signal name	STM32 pin	Function	Remark
Left connectors						
CN8	1	NC	NC	-	-	Arduino support
	3	IOREF	IOREF	-	3.3V Ref	
	5	RESET	RESET	NRST	RESET	
	7	+3V3	+3V3	-	3.3V input/output	
	9	+5V	+5V		5V output	
	11	GND	GND		Ground	
	13	GND	GND			
	15	VIN	VIN	Power input		
	2	D43	SDMMC_D0	PC8	SDMMC/I2S_A	-
	4	D44	SDMMC_D1/ I2S_A_CKIN	PC9	I/O	
	6	D45	SDMMC_D2	PC10		
	8	D46	SDMMC_D3	PC11		
	10	D47	SDMMC_CK	PC12		
	12	D48	SDMMC_CMD	PD2		
	14	D49	I/O	PG2		
	16	D50	I/O	PG3		
CN9	1	A0	ADC	PA3		ADC123_IN3
	3	A1	ADC	PC0	ADC123_IN10	
	5	A2	ADC	PC3	ADC123_IN13	
	7	A3	ADC	PF3	ADC3_IN9	
	9	A4	ADC	PF5 or PB9 ⁽¹⁾	ADC3_IN15 (PF5) or I2C1_SDA (PB9)	
	11	A5	ADC	PF10 or PB8 ⁽¹⁾	ADC3_IN8 (PF10) or I2C1_SCL (PB8)	
	13	D72	NC	-	-	-
	15	D71	I/O	PA7 ⁽²⁾	I/O	
	17	D70	I2C_B_SMBA	PF2	I2C_2	
	19	D69	I2C_B_SCL	PF1		

Table 16. NUCLEO-F429ZI pin assignments (continued)

Connector	Pin	Pin name	Signal name	STM32 pin	Function	Remark
CN9	21	D68	I2C_B_SDA	PF0	I2C_2	-
	23	GND	GND	-	Ground	
	25	D67	CAN_RX	PD0	CAN_1	
	27	D66	CAN_TX	PD1		
	29	D65	I/O	PG0	I/O	
	2	D51	USART_B_SCLK	PD7	USART_2	
	4	D52	USART_B_RX	PD6		
	6	D53	USART_B_TX	PD5		
	8	D54	USART_B_RTS	PD4		
	10	D55	USART_B_CTS	PD3		
	12	GND	GND	-	Ground	
	14	D56	SAI_A_MCLK	PE2 ⁽³⁾	SAI_1_A	
	16	D57	SAI_A_FS	PE4		
	18	D58	SAI_A_SCK	PE5		
	20	D59	SAI_A_SD	PE6		
	22	D60	SAI_B_SD	PE3	SAI_1_B	
	24	D61	SAI_B_SCK	PF8		
	26	D62	SAI_B_MCLK	PF7		
28	D63	SAI_B_FS	PF9			
30	D64	I/O	PG1	I/O		
Right Connectors						
CN7	1	D16	I2S_A_MCK	PC6	I2S_2	-
	3	D17	I2S_A_SD	PB15		
	5	D18	I2S_A_CK	PB13 ⁽⁴⁾		
	7	D19	I2S_A_WS	PB12		
	9	D20	I2S_B_WS	PA15	I2S_3 / SPI3	
	11	D21	I2S_B_MCK	PC7		
	13	D22	I2S_B_SD/ SPI_B_MOSI	PB5		
	15	D23	I2S_B_CK/ SPI_B_SCK	PB3		
	17	D24	SPI_B_NSS	PA4		

Table 16. NUCLEO-F429ZI pin assignments (continued)

Connector	Pin	Pin name	Signal name	STM32 pin	Function	Remark
CN7	19	D25	SPI_B_MISO	PB4	I2S_3 / SPI3	-
	2	D15	I2C_A_SCL	PB8	I2C1_SCL	Arduino support
	4	D14	I2C_A_SDA	PB9	I2C1_SDA	
	6	AREF	AREF	-	AVDD	
	8	GND	GND		Ground	
	10	D13	SPI_A_SCK	PA5	SPI1_SCK	
	12	D12	SPI_A_MISO	PA6	SPI1_MISO	
	14	D11	SPI_A_MOSI/ TIM_E_PWM1	PA7 ⁽¹⁾⁽²⁾ or PB5 ⁽¹⁾	SPI1_MOSI/ TIM14_CH1	
	16	D10	SPI_A_CS/ TIM_B_PWM3	PD14	SPI1_CS/ TIM4_CH3	
	18	D9	TIMER_B_PWM2	PD15	TIM4_CH4	
	20	D8	I/O	PF12	-	
CN10	1	AVDD	AVDD	-	Analog VDD	
	3	AGND	AGND		Analog Ground	
	5	GND	GND		Ground	
	7	A6	ADC_A_IN	PB1	ADC12_IN9	
	9	A7	ADC_B_IN	PC2	ADC123_IN12	
	11	A8	ADC_C_IN	PF4	ADC3_IN14	
	13	D26	I/O	PB6	I/O	
	15	D27	I/O	PB2		
	17	GND	GND	-	Ground	
	19	D28	I/O	PD13	I/O	
	21	D29	I/O	PD12		
	23	D30	I/O	PD11		
	25	D31	I/O	PE2 ⁽³⁾		
	27	GND	GND	-	Ground	
	29	D32	TIMER_C_PWM1	PA0	TIM2_CH1	
	31	D33	TIMER_D_PWM1	PB0	TIM3_CH3	
	33	D34	TIMER_B_ETR	PE0	TIM4_ETR	
2	D7	I/O	PF13	-	Arduino support	

Table 16. NUCLEO-F429ZI pin assignments (continued)

Connector	Pin	Pin name	Signal name	STM32 pin	Function	Remark
CN10	4	D6	TIMER_A_PWM1	PE9	TIM1_CH1	Arduino support
	6	D5	TIMER_A_PWM2	PE11	TIM1_CH2	
	8	D4	I/O	PF14	-	
	10	D3	TIMER_A_PWM3	PE13	TIM1_CH3	
	12	D2	I/O	PF15	-	
	14	D1	USART_A_TX	PG14	USART6	
	16	D0	USART_A_RX	PG9		
	18	D42	TIMER_A_PWM1N	PE8	TIM1_CH1N	-
	20	D41	TIMER_A_ETR	PE7	TIM1_ETR	
	22	GND	GND	-	Ground	
	24	D40	TIMER_A_PWM2N	PE10	TIM1_CH2N	
	26	D39	TIMER_A_PWM3N	PE12	TIM1_CH3N	
	28	D38	I/O	PE14	I/O	
	30	D37	TIMER_A_BKIN1	PE15	TIM1_BKIN1	
	32	D36	TIMER_C_PWM2	PB10	TIM2_CH3	
	34	D35	TIMER_C_PWM3	PB11	TIM2_CH4	

1. Refer to [Table 11: Solder bridges](#) for details.
2. PA7 is used as D11 and connected to CN7 pin 14 by default. If JP6 is ON, it is also connected to both Ethernet PHY as RMII_DV and CN9 pin 15. In this case only one function of Ethernet or D11 could be used.
3. PE2 is connected to both CN9 pin 14 (SAI_A_MCLK) and CN10 pin 25 (IO). Only one function can be used at one time.
4. PB13 is used as I2S_A_CK and connected to CN7 pin 5 by default. If JP7 is ON, it is also connected to Ethernet PHY as RMII_TXD1. In this case only one function of Ethernet or I2S_A could be used.

6.14 ST morpho connector

The ST morpho connector consists in male pin header footprints CN11 and CN12 (not soldered by default). They can be used to connect the STM32 Nucleo-144 board to an extension board or a prototype/wrapping board placed on top of the STM32 Nucleo-144 board. All signals and power pins of the STM32 are available on ST morpho connector. This connector can also be probed by an oscilloscope, logical analyzer or voltmeter.

[Table 17](#) and [Table 18](#) show the pin assignment of each main STM32 on ST morpho connector.

Table 17. ST morpho connector for NUCLEO-F207ZG, NUCLEO-F429ZI, NUCLEO-F446ZE, NUCLEO-F746ZG

CN11 odd pins		CN11 even pins		CN12 odd pins		CN12 even pins	
Pin	Pin name	Pin	Pin name	Pin	Pin name	Pin	Pin name
1	PC10	2	PC11	1	PC9	2	PC8
3	PC12	4	PD2	3	PB8	4	PC6
5	VDD	6	E5V	5	PB9	6	PC5
7	BOOT0 ⁽¹⁾	8	GND	7	AVDD	8	U5V ⁽²⁾
9	PF6	10	-	9	GND	10	PD8
11	PF7	12	IOREF	11	PA5	12	PA12
13	PA13 ⁽³⁾	14	RESET	13	PA6	14	PA11
15	PA14 ⁽³⁾	16	+3V3	15	PA7	16	PB12
17	PA15	18	+5V	17	PB6	18	PB11
19	GND	20	GND	19	PC7	20	GND
21	PB7	22	GND	21	PA9	22	PB2
23	PC13	24	VIN	23	PA8	24	PB1
25	PC14	26	-	25	PB10	26	PB15
27	PC15	28	PA0	27	PB4	28	PB14
29	PH0	30	PA1	29	PB5	30	PB13
31	PH1	32	PA4	31	PB3	32	AGND
33	VBAT	34	PB0	33	PA10	34	PC4
35	PC2	36	PC1	35	PA2	36	PF5
37	PC3	38	PC0	37	PA3	38	PF4
39	PD4	40	PD3	39	GND	40	PE8
41	PD5	42	PG2	41	PD13	42	PF10
43	PD6	44	PG3	43	PD12	44	PE7
45	PD7	46	PE2	45	PD11	46	PD14
47	PE3	48	PE4	47	PE10	48	PD15
49	GND	50	PE5	49	PE12	50	PF14
51	PF1	52	PF2	51	PE14	52	PE9
53	PF0	54	PF8	53	PE15	54	GND
55	PD1	56	PF9	55	PE13	56	PE11
57	PD0	58	PG1	57	PF13	58	PF3
59	PG0	60	GND	59	PF12	60	PF15
61	PE1	62	PE6	61	PG14	62	PF11
63	PG9	64	PG15	63	GND	64	PE0
65	PG12	66	PG10	65	PD10	66	PG8

Table 17. ST morpho connector for NUCLEO-F207ZG, NUCLEO-F429ZI, NUCLEO-F446ZE, NUCLEO-F746ZG (continued)

CN11 odd pins		CN11 even pins		CN12 odd pins		CN12 even pins	
Pin	Pin name	Pin	Pin name	Pin	Pin name	Pin	Pin name
67	-	68	PG13	67	PG7	68	PG5
69	PD9	70	PG11	69	PG4	70	PG6

1. Default state of BOOT0 is 0. It can be set to 1 when a jumper is on pins 5-7 of CN11.
2. U5V is 5V power from ST-LINKV2-1 USB connector and it rises before +5V.
3. PA13 and PA14 are shared with SWD signals connected to ST-LINK/V2-1. It is not recommended to use them as IO pins if ST-LINK part is not cut.

Table 18. ST morpho connector for NUCLEO-F303ZE

CN11 odd pins		CN11 even pins		CN12 odd pins		CN12 even pins	
Pin No.	Name	Pin No.	Name	Pin No.	Name	Pin No.	Name
1	PC10	2	PC11	1	PC9	2	PC8
3	PC12	4	PD2	3	PB8	4	PC6
5	VDD	6	E5V	5	PB9	6	PC5
7	BOOT0 ⁽¹⁾	8	GND	7	AVDD	8	U5V ⁽²⁾
9	PF6	10	-	9	GND	10	PD8
11	PF7	12	IOREF	11	PA5	12	PA12
13	PA13 ⁽³⁾	14	RESET	13	PA6	14	PA11
15	PA14 ⁽³⁾	16	+3V3	15	PA7	16	PB12
17	PA15	18	+5V	17	PB6	18	PB11
19	GND	20	GND	19	PC7	20	GND
21	PB7	22	GND	21	PA9	22	PB2
23	PC13	24	VIN	23	PA8	24	PB1
25	PC14	26	-	25	PB10	26	PB15
27	PC15	28	PA0	27	PB4	28	PB14
29	PF0	30	PA1	29	PB5	30	PB13
31	PF1	32	PA4	31	PB3	32	AGND
33	VBAT	34	PB0	33	PA10	34	PC4
35	PC2	36	PC1	35	PA2	36	PF5
37	PC3	38	PC0	37	PA3	38	PF4
39	PD4	40	PD3	39	GND	40	PE8
41	PD5	42	PG2	41	PD13	42	PF10
43	PD6	44	PG3	43	PD12	44	PE7
45	PD7	46	PE2	45	PD11	46	PD14

Table 18. ST morpho connector for NUCLEO-F303ZE (continued)

CN11 odd pins		CN11 even pins		CN12 odd pins		CN12 even pins	
Pin No.	Name	Pin No.	Name	Pin No.	Name	Pin No.	Name
47	PE3	48	PE4	47	PE10	48	PD15
49	GND	50	PE5	49	PE12	50	PF14
51	PH1	52	PF2	51	PE14	52	PE9
53	PH0	54	PF8	53	PE15	54	GND
55	PD1	56	PF9	55	PE13	56	PE11
57	PD0	58	PG1	57	PF13	58	PF3
59	PG0	60	GND	59	PF12	60	PF15
61	PE1	62	PE6	61	PG14	62	PF11
63	PG9	64	PG15	63	GND	64	PE0
65	PG12	66	PG10	65	PD10	66	PG8
67	PH2	68	PG13	67	PG7	68	PG5
69	PD9	70	PG11	69	PG4	70	PG6

1. Default state of BOOT0 is 0. It can be set to 1 when a jumper is on pin 5-7 of CN11.
2. U5V is 5V power from ST-LINK/V2-1 USB connector and it rises before +5V.
3. PA13 and PA14 are shared with SWD signals connected to ST-LINK/V2-1, it is not recommended to use them as IO pins if ST-LINK part is not cut.

7 Electrical schematics

Figure 12. Top and Power








Figure 13. MCU



Title: MCU		
Project: NUCLEOK_XXXZX		
Size: A3	Reference: MB1137	
Date: 10/13/2015	Revision: B-01	
Sheet 2 of 6		lib.augmented

Figure 14. ST-LINK/V2-1




Title: STLINKV2-1	
Project: NUCLEOX_XXXZX	
Size A4	Reference MB1137
Date: 8/27/2015	Revision: B-01
Sheet: 3 of 6	






Figure 15. USB



Title: USB		
Project: NUCLEOK XXXZX		
Size A4	Reference MB1137	Revision: B-01
Date: 8/24/2015	Sheet 4 of 6	




Figure 16. Ethernet PHY with RJ45 connector



Title: Ethernet PHY with RJ45connector			
Project NUCLEOX XXXZX			
Size A4	Reference MB1137		Revision: B-01
Date: 8/27/2015	Sheet 5 of 6		life.augmented



Figure 17. Extension connectors



8 Mechanical drawing

Figure 18. Nucleo-144 board mechanical drawing in millimeter





Figure 19. Nucleo-144 board mechanical drawing in mil



9 Revision history

Table 19. Document revision history

Date	Revision	Revision Details
21-Dec-2015	1	Initial version.

IMPORTANT NOTICE – PLEASE READ CAREFULLY

STMicroelectronics NV and its subsidiaries ("ST") reserve the right to make changes, corrections, enhancements, modifications, and improvements to ST products and/or to this document at any time without notice. Purchasers should obtain the latest relevant information on ST products before placing orders. ST products are sold pursuant to ST's terms and conditions of sale in place at the time of order acknowledgement.

Purchasers are solely responsible for the choice, selection, and use of ST products and ST assumes no liability for application assistance or the design of Purchasers' products.

No license, express or implied, to any intellectual property right is granted by ST herein.

Resale of ST products with provisions different from the information set forth herein shall void any warranty granted by ST for such product.

ST and the ST logo are trademarks of ST. All other product or service names are the property of their respective owners.

Information in this document supersedes and replaces information previously supplied in any prior versions of this document.

© 2015 STMicroelectronics – All rights reserved