

Freescall and the Freescall logo are trademarks of Freescall Semiconductor Inc., Reg. U.S. Pat. & Tm. Off. All other product or service names are the property of their respective owners. © 2015 Freescall Semiconductor Inc. FRDMK64FAGM010RC REV 2 920-76666 REV B

freescall
For more information,
visit freescall.com/sensortoolbox

**FRDM-
K64F-
AGM01**

FRDM-K64F-AGM01

**FRDM-
K64F-
AGM01**

Quick Reference Card

9-axis Sensor Toolbox Demonstration Kit

Enabled for sensor fusion with FXAS21002C 3-axis gyroscope, FXOS8700C 6-axis integrated e-compass, and Freescall Freedom FRDM-K64F development board



Get Started

Download tools and documentation under
Jump Start Your Design
at freescall.com/sensortoolbox



FREESCALE FREEDOM PLATFORM

- 1 Verify package contents:
 - FRDM-K64F/FRDM-STBC-AGM01 assembly
 - USB cable
- 2 Download the mbed Windows serial port driver:
developer.mbed.org/handbook/Windows-serial-configuration
- 3 Plug one end of a USB cable into the SDA port on the assembly. Plug the other end of the cable into the USB port on the computer.
- 4 Download and install the latest Sensor Toolbox software at:
freescall.com/sensortoolbox
- 5 Start the Sensor Toolbox software.

For more information, go to:
freescall.com/sensortoolbox


FXOS8700C 6-axis sensor with integrated linear accelerometer and magnetometer
16 QFN (3 mm x 3 mm x 1.2 mm)

INT1-8700 - 3
INT2-8700 - 5
INT1-21002 - 6

INT2-21002 - 1
SPI-CSB-21002 - 3
SPI-MOSI - 4
SA0-MISO - 5
SPI-SCLK - 6
GND - 7

I2C_SDA0 - 9
I2C_SCL0 - 10

FXAS21002C 3-axis digital angular rate gyroscope
24 QFN (4 mm x 4 mm x 1 mm)



6 - I2C-SCL1
5 - I2C-SDA1
4 - RST-GPIO
3 - SPI-CSB-8700

7 - GND
6 - GND
4 - VDD
3 - RST-MCU
2 - VDD

Test points (18 places)

Get to Know the FRDM-K64F-AGM01



Learn more at freescall.com/sensortoolbox