



4k 8 Way HDMI Splitter



User Guide









Contents

General Safety	2
Introduction	
Box contents	2
Specifications	3
Operation - Panels and Functions	
Typical Setup	
Remote IR System	4

General Safety

- For optimum performance and safety, please read these instructions carefully before connecting, operating or adjusting this product. Keep this manual for future reference.
- To prevent fire or shock hazard, do not expose any part of this device to rain or moisture.
- This product is for indoor use only
- The unit should not be exposed to direct sunlight, very high or low temperature, moisture, vibrations or dusty environments.
- Do not place the product in enclosed bookcases or racks without proper ventilation.
- Do not use abrasives, benzene, thinner or other solvents to clean the surface of the unit.
 To clean, disconnect the unit from the mains, wipe with a clean soft cloth and add a mild detergent solution if necessary.
- Do not disassemble the splitter or power supply they contain no user serviceable parts. Refer servicing to qualified personnel only.
- Do not overload wall outlets and extension cords as this can result in the risk of fire or electrical shock.
- SURGE PROTECTION DEVICE RECOMMENDED: This product contains sensitive electrical components that may be damaged by electrical spikes, surges, lightning strikes, etc.

Introduction

The Labgear range of 4k splitters are designed to split the HDMI signal from a single high resolution source to mutiple displays without signal loss. They also have a backward IR function allowing remote control of the source from the display location.*

- Compliant with HDMI2.0, HDCP2.2 and DVI 1.0
- Support video format up to 4k2k@30Hz with 24bit RGB/YcbCR 4:4:4/YCBCR 4:2:2 and up to 4k2k@60Hz with 12bit YCBCR 4:2:0
- Support 3D frame sequential video format up to 1080p@60
- Support high resolution VESA mode video format up to QSXGA@60Hz
- Support LPCM 7.1CH, Dolby True HD and DTS-HD Master Audio
- Support smart EDID control
- Support Remote IR System for controlling a source from any connected display

Box Contents

1x 8 Way HDMI Splitter 1x 5V == 2A Power adaptor 1x User guide

Specifications	
Video Bandwidth	300MHz/10.2 Gbps
Input Ports	1 × HDMI
Output Ports	8 × HDMI
Output Resolution	480i ~1080p 50/60Hz, 4Kx2K@24/30Hz, YCBCR 4:2:0
ESD Protection (Human Body model:)	±8 kV (air-gap discharge) ±4 kV (contact discharge)
Power Supply	5V/1A DC (US/EU standards, CE/FCC/UL certified)
Dimensions	235mm (W) × 82mm (D) × 17mm (H)
Weight	360g
Chassis Material	Metal
Operating Temperature	0°C ~ 40°C / 32°F ~ 104°F
Storage Temperature	-20°C ~ 60 °C / -4 °F ~ 140 °F
Relative Humidity	20 ~ 90 % RH (non-condensing)
Power Consumption (Max)	3.5W

Operation - Panels and Functions



- 1. Power: Blue LED indicates power supply connection.
- 2. Input: Blue LED indicates Source to splitter unit.
- 3-10. Out 1 Out 8: Blue LEDs indicate an active TV/display/monitor is connected to the indicated HDMI Outputs.
- 11. IR Tx: 3.5mm IR Emitter socket for IR control.
- 12. USB: For firmware updates only
- 13. EDID Std: When in 'Std' mode, the EDID will be set to output 1080p@60Hz video and LPCM 2CH Stereo audio. Use this mode if there are display problems in 'Auto' Mode. EDID Auto: When in 'Auto' mode, the unit will read the EDID settings of the display device connected to HDMI OUT 1. If it detects a 4K2K capable EDID setting it will transmit the signal in that format to all outputs. If no 4K2K capable EDID is detected then the unit will output the best resolution that all displays can support.
- 14-21. HDMI Output 1 Output 8: Connects HDMI Outputs1 8 to HDMI displays for simultaneous HDMI distribution, or connects an output to another transmitter to extend the operating distance.

- 14. HDMI Input: Connects the HDMI or DVI output of your source device such as a DVD player or set-top box via an HDMI cable.
- 15. DC 5V: Connects the splitter unit to the 5V DC PSU suppplied which is then plugged into a mains socket.

Typical Setup



Remote IR System

The Remote IR System in conjunction with the HD2 IRK IR Extender Kit (sold separately) allows you to control your source device from the location of the the display using the source remote control.



Customer Careline

If you experience any problems setting up your splitter or have any other queries, please call the Labgear Customer Care Line: **08457 573 479** - (Local Rate UK only). Alternatively, please visit our website at www.labgear.co.uk



Waste electrical and electronic products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority for recycling advice.

