

Dismiss

## Join GitHub today

GitHub is home to over 28 million developers working together to host and review code, manage projects, and build software together.

[Sign up](#)

# QuickStart

[Jump to bottom](#)

credenticity edited this page on Aug 20, 2016 · 15 revisions

If you have a PRUDAQ board and are ready to start collecting samples, you've come to the right place.

Standard disclaimer: any time you're working with circuit boards, you really should use an anti-static mat and wrist strap. We break this rule just like most other people do, but be warned that the AD9201 is quite sensitive and could easily be damaged by electrostatic discharge (even if you don't see or feel a spark).

## Set the jumpers

For this example we won't be using the SMA coax connectors on the board, so make sure that jumpers J4, J5 and J6 are not installed. (They enable 50 ohm termination resistors which would load down the clock signal and inputs, which we don't want in this case).

J1 is a 3 pin header labeled **clock source** that lets you choose where the ADC clock signal comes from. The ADC's two channels will be simultaneously sampled each time the clock goes high.

The [Circuit Description](#) doc describes the clock options in detail, but let's keep it simple and choose the GPIO clock option by installing a jumper on J1 between the center pin and the pin near the center of the board labeled "GPIO Clock".

The GPIO clock is easy to configure in software for any sample rate we want.

## Attach a dummy input

We'll be reading from inputs 0 and 4. Inputs left unconnected can show up with all sorts of values, so let's connect input 0 to the analog ground reference, and input 4 to the 1V "vref" voltage, which is sometimes used to make sure an input signal is centered at mid-scale. Our 10-bit samples take on values between 0 and 1023, so we expect to see a value of about 512 from input 4.



On the black 8-pin header, the left 4 pins connect to analog ground. Analog ground is electrically connected to the BeagleBone's ground, but with careful layout on the PRUDAQ board to minimize stray noise. The green wire in the photo connects it to input 0.

The right 4 pins connect to vref. vref really is just a reference; drawing any current from it will make it sag toward ground, and mess up the samples you collect. So really we should buffer it (say, with a voltage-following op-amp) before connecting it to an input, especially if we were going to use it with the round-robin code in the examples/ directory. But we just want to collect some samples with a value that isn't near zero, and connecting the 3.3V AVCC would exceed the 0-2V input range for the ADC. The white wire in the photo connects it to input 4.

## Attach PRUDAQ to your BeagleBone Black or BeagleBone Green

With the BeagleBone powered down, stack the PRUDAQ cape on top of the BeagleBone. It can be tricky to get all 96 header pins on the cape lined up straight, so be patient. Try to get the pins started all the way around, then work your way around the board a few times pushing the pins in a few millimeters at a time.

Take care that you don't push the cape in too far. On our BeagleBone Black, for instance, there's a capacitor near the large USB jack that hits the bottom of the cape as the cape bottoms out, and you don't want the pins on the bottom of the RAW1 SMA jack to short to the USB jack's metal shell.

Attach the PRUDAQ cape before powering on the BeagleBone, then connect it to your computer with a USB cable. The Beaglebone should boot up as usual. You'll know it booted successfully if you see the BeagleBone show up as a storage device on your PC, and if, a minute or so later, you can open the website served by your BeagleBone <http://192.168.7.2> with your browser.

## SSH into the BeagleBone

---

```
$ ssh debian@192.168.7.2
Debian GNU/Linux 7
```

```
BeagleBoard.org Debian Image 2015-07-13
```

```
default username:password is [debian:temppwd]
```

```
debian@192.168.7.2's password: (password is temppwd)
Last login: Mon Mar  9 21:52:01 2015 from 192.168.7.1
debian@beaglebone:~$
```

On older BeagleBone Black distros, you may instead have to login as root with a blank password.

## Decide which codebase to use

---

Once you've verified that you can SSH into your beaglebone, it's time to decide between using BeagleLogic's PRUDAQ driver, or our sample code. We recommend that you start with BeagleLogic, and only worry about our sample code if you want to write your own firmware and don't need sampling rates more than about 10MSPS.

Option 1: Much better throughput (5-10x), necessary for sample rates >6MSPS. Easy to read data from `/dev/beaglelogic`

Option 2: Uses PRU0 to control GPIO clock and input selection, necessary for low latency reads and round-robin sampling (see `src/examples/round_robin`). Much worse throughput. Simpler codebase for hacking on.

## Option 1: Use the BeagleLogic system image

---

BeagleLogic uses a BeagleBone as a logic analyzer by sampling digital input pins very quickly. Its software needs are very similar to our own, so the maintainer worked with us to add PRUDAQ support to the BeagleLogic software.

Step 1: Download the latest [BeagleLogic system image](#) to your host PC.

Step 2: On your host PC, unzip the 7zip archive: `$ 7zr x beaglelogic-prudaq-system.img.xz` (You might need to `$ sudo apt-get install p7zip` if you don't have 7zip installed).

Step 3: Plug a 4GB or bigger microSD card into your host PC and make sure you know its device name. Let's assume it's `/dev/sdm`. Make sure it's not mounted (eg., `sudo umount /dev/sdm1`).

Step 4: Install the BeagleLogic image onto the microSD card. Again, make sure you have the right device name! This step will destroy any data on the device specified. `sudo dd if=beaglelogic-prudaq-system.img of=/dev/sdm bs=1M` This step may take a long time (on the order of an hour).

Step 5: When it's finished copying, install the microSD card in the BeagleBone and reboot. Keep in mind you will need to keep the microSD card on the BeagleBone for as long as you use the BeagleLogic image.

Step 6: Replace the stock BeagleLogic PRU1 firmware with the PRUDAQ firmware.

```
$ # Back up the original BeagleLogic firmware
$ cd /lib/firmware
$ sudo mv beaglelogic-pru1 beaglelogic-pru1.orig

$ # Build the PRUDAQ firmware
$ sudo date -s '7 July 2016 1645 PDT' # Set the system clock to the current time so
make doesn't complain
$ cd /opt/BeagleLogic/beaglelogic-firmware/custom/prudaq
$ sudo -E make

$ # Install in /lib/firmware and reboot
$ sudo cp prudaq-ch01 /lib/firmware/beaglelogic-pru1
$ sudo reboot
```

Step 7: Copy the [Setup script](#) to your beaglebone and run it as root.

```
$ chmod 755 beaglelogic-prudaq-setup.sh
$ sudo ./beaglelogic-prudaq-setup.sh
```

The green "enabled" LED will light up on the PRUDAQ.

Step 8: Start sampling!

```

debian@beaglebone:~$ hexdump -d /dev/beaglelogic |head
00000000  00003  00513  00003  00512  00003  00513  00003  00512
00000010  00003  00512  00003  00512  00003  00512  00003  00512
00000020  00003  00512  00003  00512  00004  00512  00003  00513
00000030  00003  00513  00004  00512  00003  00513  00003  00512
00000040  00003  00512  00003  00513  00003  00512  00003  00513
00000050  00003  00512  00003  00513  00003  00513  00003  00512
00000060  00003  00512  00003  00512  00003  00512  00004  00512
00000070  00004  00512  00004  00512  00003  00513  00003  00512
00000080  00003  00512  00003  00512  00003  00512  00003  00512
00000090  00003  00512  00003  00513  00004  00512  00003  00512

```

If you attached a dummy input as instructed above, you should see values like the ones here: interleaved samples from the two channels, with input 0 near 0, and input 4 near 512.

If the hexdump command hangs for a long time, double check that you have a clock jumper installed on J1.

## Option 2: Try our sample code

Most users should use BeagleLogic's PRUDAQ driver (option 1), but our sample code is easy to hack on and easy to build from a stock BeagleBone distro.

The BeagleBone Green doesn't come with HDMI. If you have BeagleBone Black and you want to use our sample code, you'll have to disable HDMI to free up some pins needed by PRUDAQ. (If you use Option 1 above, the BeagleLogic image already has HDMI disabled). SSH in and carefully edit `/boot/u-boot/uEnv.txt` as root to uncomment this line, then reboot:

```
cape_disable=capemgr.disable_partno=BB-BONELT-HDMI,BB-BONELT-HDMIN
```

If you don't see `/boot/u-boot/uEnv.txt`, you may have to mount `/dev/mmcblk0p1` somewhere first. (There are lots of guides online talking about disabling BeagleBone HDMI).

Caution: there may be another `cape_disable` line that disables HDMI *and* eMMC. So make sure you're uncommenting the right line.

Caution: you may be tempted to edit `uEnv.txt` on your host PC, since it's one of the files that pops up in the USB storage that appears when you boot the BeagleBone. But if you use the wrong editor, it may not use the right line endings, and this could make your BeagleBone unable to boot.

When you've successfully disabled HDMI, you won't see an "L" in the last status column in the slots file for the lines mentioning HDMI:

```

# cat /sys/devices/bone_capemgr.*/slots
0: 54:PF---
1: 55:PF---

```

```

2: 56:PF---
3: 57:PF---
4: ff:P-O-L Bone-LT-eMMC-2G,00A0,Texas Instrument,BB-BONE-EMMC-2G
5: ff:P-O-- Bone-Black-HDMI,00A0,Texas Instrument,BB-BONELT-HDMI
6: ff:P-O-- Bone-Black-HDMIN,00A0,Texas Instrument,BB-BONELT-HDMIN
# ##### ^ dash here instead of L in the two lines above means HDMI is disabled.

```

First we'll clone this repo onto your host PC, then copy it over to the home directory on the Beaglebone. (You could also clone the repo directly from your BeagleBone if you've connected it to the internet via Ethernet or a USB wifi adapter).

If your host PC runs GNU/Linux, you can clone this repo with:

```
$ git clone https://github.com/google/prudaq.git
```

That should create a subdirectory named `prudaq`. Now copy that whole directory to your BeagleBone:

```
scp -r prudaq debian@192.168.7.2:~
```

*Note: The default password for the debian user is: `temppwd`*

Then ssh into the Beaglebone to build and install the code:

```

user@host-pc$ ssh debian@192.168.7.2

debian@beaglebone$ cd ~/prudaq/src
debian@beaglebone$ make
debian@beaglebone$ sudo make install # This just copies the .dtbo file to
/lib/firmware
debian@beaglebone$ sudo reboot      # Reboot just to be safe, so it notices the .dtbo
[ Wait for reboot then ssh in again ]
debian@beaglebone$ cd ~/prudaq/src
debian@beaglebone$ sudo ./setup.sh  # Init script that needs to be run once every
time beaglebone is rebooted

```

Running `make` builds the `prudaq_capture` example program and assembles the firmware for the two realtime units. `prudaq_capture` enables the ADC, loads the firmware into the PRUs, then reads binary sample data from the shared buffer and writes it to stdout.

```
$ sudo ./prudaq_capture
```

```
Usage: prudaq_capture [flags] pru0_code.bin pru1_code.bin
```

```

-f freq          gpio based clock frequency (default: 1000)
-i [0-3]        channel 0 input select

```

```
-q [4-7]      channel 1 input select
-o output    output filename (default: stdout)
```

Let's turn up the clock to 2kHz and specify inputs 0 and 4 explicitly (even though they're the defaults), then pipe the binary data into hexdump so it's easy to read:

```
$ sudo ./prudaq_capture -i 0 -q 4 -f 2000 pru0.bin pru1.bin | hexdump -d -v | head
2097152B of shared DDR available.
Physical (PRU-side) address:91800000
Virtual (linux-side) address: 0xb6b9a000
```

```
Actual GPIO clock speed is 2000.00Hz
0000000  00000  00000  00001  00513  00001  00513  00001  00513
0000010  00001  00513  00001  00513  00001  00513  00001  00513
0000020  00001  00513  00001  00513  00001  00513  00001  00513
0000030  00001  00513  00001  00513  00001  00513  00001  00513
0000040  00001  00513  00001  00513  00001  00513  00001  00514
0000050  00001  00513  00001  00513  00001  00513  00001  00513
0000060  00001  00513  00001  00513  00001  00513  00001  00513
0000070  00001  00513  00001  00513  00001  00513  00001  00513
0000080  00001  00513  00001  00513  00001  00513  00001  00513
0000090  00001  00513  00001  00513  00001  00513  00001  00513
      5256 bytes / second. 5256B written, 5256B read.
```

The numbers come from hexdump, while the other messages come from `prudaq_capture` (and technically were written to `stderr` instead of `stdout`). The first column of numbers is the offset, followed by decimal readouts in 16-bit chunks, which happen to be exactly how far we pad out our 10-bit samples. You can see that the first two values are 0 (due to the way the samples are read by the PRU, the first sample should be ignored). Then we get alternating values of 1 and 513, which is just what we expected: channel 0 is connected to ground, while channel 1 is about midscale between 0 and 1023.

Troubleshooting: If you only see the initialization output but no data after:

```
2097152B of shared DDR available.
Physical (PRU-side) address:9f5c0000
Virtual (linux-side) address: 0xb6da4000
```

This is probably because the clock signal isn't being received, so no samples are being captured. Check to make sure a jumper is installed on J1 to select the GPIO clock or onboard clock.

## Where to go next

---

The [main documentation page](#) has pointers to more in-depth docs.

You can also join the [prudaq-users](#) email list and tell us what you think.

|                                             |
|---------------------------------------------|
| ▼ Pages 6                                   |
| <input type="text" value="Find a Page..."/> |
| <a href="#">Home</a>                        |
| <a href="#">BoardModification</a>           |
| <a href="#">CircuitDescription</a>          |
| <a href="#">InputOutput</a>                 |
| <a href="#">Performance</a>                 |
| <a href="#">QuickStart</a>                  |

Clone this wiki locally

|                                                        |                                                                                     |
|--------------------------------------------------------|-------------------------------------------------------------------------------------|
| <code>https://github.com/google/prudaq/wiki.git</code> |  |
|--------------------------------------------------------|-------------------------------------------------------------------------------------|