



# Azure Sphere MT3620 Starter Kit Hardware User Guide

v1.5 – August 05, 2019



## **1 Document Control**

Document Version:	v1.5
Document Date:	08/05/2019
Document Author:	Peter Fenn
Document Classification:	Public
Document Distribution:	Public

## 2 Version History

Version	Date	Comment
1.0	03/31/2019	Initial draft release
1.1	04/02/2019	Click socket pinouts corrected (p19) Module pinout assignments on SK board corrected (p36)
1.2	04/26/2019	Public Release version, updated images and content corrections
1.3	04/29/2019	Updated Starter Kit block diagram and module pinout diagrams
1.4	05/03/2019	Updated Module block diagram
1.5	08/05/2019	Corrections



## Contents

1	D	)oc	cument Control	2
2	V	/er	rsion History	2
3	Н	lar	rdware Checklist	6
4	S	Soft	ftware Checklist	6
6	Ir	ntro	roduction	7
	6.1		Azure Sphere MT3620 Starter Kit Info	8
	6.2		Items Included in the Starter Kit	9
	6.3		Important Reference Documents	9
7	S	star	arter Kit Architecture and Features	10
	7.1		List of Features	10
	7.2		Block Diagram - Avnet Azure Sphere MT3620 Starter Kit	11
	7.3		Block Diagram - Azure Sphere MT3620 Module	12
	7.4		Hardware Expansion Options	13
8	н	lar	Irdware Functional Description	14
	8.1		Avnet Azure Sphere MT3620 module	14
	8.2		USB to Serial 4-port Host Interface (FT4232HQ)	14
	8.3		Configuration Jumpers, Status LEDs and Switches	15
	8.	.3.1	.1 Setting the H/W Configuration Jumpers	15
	8.	.3.2	.2 Push Button Switches	15
	8.	.3.3	.3 Status / Indicator LEDs	16
	8.4		Onboard sensors	17
	8.	.4.1	.1 3D Accelerometer, 3D Gyro and Temperature (LSM6DSO)	17
	8.	.4.2	.2 Barometric Pressure (LPS22HH)	17
	8.	.4.3	.3 Ambient Light Sensor (ALS-PT19)	17
	8.5		Peripheral Expansion Interfaces	18
	8.	.5.1	.1 MikroE Click Sockets	18
	8.	.5.2	.2 UART/BLE Connector	20
	8.	.5.3	.3 GROVE Connector	21
	8.	.5.4	.4 OLED Display Interface	22
	8.6		Power Interfaces, Regulation and Protection	24
	8.	.6.1	.1 USB Host PC Interface	24
	8.	.6.2	.2 AUX 5V DC and VBAT Terminal Connectors	24
8.6.3 ADC VREF Header (J6)		.3 ADC VREF Header (J6)	24	

# **XVNET**<sup>®</sup> Reach Further<sup>™</sup>

8.6	6.4	Power Protection	25
8.6	6.5	Power: 3.3V Regulation	25
8.6	6.6	Power LED and Testpoints	26
8.6	6.7	Measuring Power Consumption	26
9 So	oftwar	e Development Environment Preparation	27
9.1	Mic	rosoft Installation Instructions	27
9.2	Ver	ify Windows 10 Version	27
9.3	Inst	all Azure Sphere SDK	27
9.4	Win	ndows FTDI USB Drivers	28
9.4	4.1	Windows FTDI USB Driver Installation	28
9.4	4.2	Windows to FTDI Interfaces Verification	28
9.5	DE	BUG Interface	30
9.6	SEF	RVICE interface	30
9.7	RE	COVERY Interface	31
10 W	/i-Fi C	onnectivity	32
10.1	1 Sca	an for Wi-Fi Access Points	32
10.2	2 Cor	nfiguring the Wi-Fi Network Settings	32
11 C	ontact	Info and Technical Support	33
12 Di	isclain	ner	34
13 Sa	afety \	Narnings	34
14 Ap	ppend	lix-A: Azure Sphere Module Pinout Detail	35
15 Ap	ppend	lix-B: Running Pre-Compiled Example Applications	38
15.1	1 GP	IO Test Application	38
15.2	2 iPei	rf3 Test Application to Check Wi-Fi Performance	39
15.3	3 Azu	ire IoT Central - Sphere Starter Kit Out-of-Box Demo	41



## **Figures**

Figure 1 – Avnet Azure Sphere MT3620 Module (Chip Antenna version)	7
Figure 2 – Avnet Azure Sphere MT3620 Starter Kit	8
Figure 3 – Starter Kit Fitted with Click, Grove and OLED Expansion Boards	. 13
Figure 4 – RESET and USER Push Button Switches	. 15
Figure 5 – Location of the Status / Indicator LEDs	. 16
Figure 6 – Location of Ambient Light Sensor (U3)	. 17
Figure 7 – UART/BLE Female Right-Angle 2x6 Connector	. 20
Figure 8 – UART/BLE Female Connector (viewed from board edge)	. 20
Figure 9 – GROVE Connector (viewed from board edge)	.21
Figure 10 – OLED Display Connector (viewed from board edge)	. 23
Figure 11 – Recommended 3V3 and GND Test Points	. 26
Figure 12 – Current-measurement USB dongle	. 26
Figure 13 – Azure Sphere Module Pinout	. 35



## 3 Hardware Checklist

Hardware items recommended for application development are the following

#	Item Description
1	Development Computer with Windows-10 Operating System
2	Avnet Azure Sphere MT3620 Starter Kit and USB cable http://avnet.me/mt3620-kit
3	USB current monitor dongle (optional)
4	MikroE Click "Tester" boards (optional, available from Avnet) https://www.mikroe.com/tester-click

## 4 Software Checklist

Listed below are the software items mentioned in this document

#	Item Description
1	Visual Studio 2017 (Enterprise, Professional or Community edition, v15.7 or later), <u>or</u> Visual Studio 2019 (Enterprise, Professional or Community edition) downloadable from: <u>https://visualstudio.microsoft.com/</u>
2	Microsoft Azure Sphere SDK for Visual Studio Preview (Windows console application) downloadable from: <u>http://aka.ms/AzureSphereSDK</u> Azure_Sphere_SDK_Preview_for_Visual_Studio.exe
3	iPerf3 Server Application (Windows console application) iperf-3.1.3-win64.zip
4	Module: iPerf3 Test application (production-signed) iperf3_ps.imagepackage
5	Module: GPIO Test application (production-signed) AvnetDevBoardTestApp_ps.imagepackage
6	Module: Azure IoT Hub, IoT Central Out-of-Box Reference Design application https://github.com/Avnet/AvnetAzureSphereStarterKitReferenceDesign



## 6 Introduction

The **Azure Sphere MT3620 Starter Kit** supports rapid prototyping using Avnet's certified Azure Sphere module, based on the Microsoft MT3620AN device. The board features multiple expansion interfaces, including two MikroE Click sockets plus an I2C Grove connector, to enable easy hardware customization with a wide range of sensors and interfaces via the addition of custom or off-the-shelf plug-in boards.

The MT3620 is the first Azure Sphere certified "microcontroller", a completely new class of connected SoC IoT device that features "end-to-end security". User applications can target it's 500 MHz ARM Cortex-A7 core as well as two general purpose 200 MHz ARM Cortex-M4F I/O subsystem cores designed to support real-time requirements. The on-chip peripherals (GPIO, UART, I2C, SPI, I2S, PWM and ADC) can be mapped to any of these three user-accessible cores.

Additional differentiators of the MT3620 device are the built-in Pluton security subsystem (with dedicated CM4F core) for secure boot and secure system operation, its dual-band 802.11 a/b/g/n Wi-Fi connectivity, as well as integration of on-chip PMU, RTC plus FLASH and SRAM memory. Wi-Fi based OTA firmware and user application updates (using strict certificate-based authentication) are hosted by Microsoft for the lifetime of the MT3620 device

The Cortex-A7 application processor runs Microsoft's Azure Sphere Secure OS. Custom user applications are developed in C using the Microsoft Visual Studio IDE, which includes debugging features such as single-step execution, breakpoints and watch-points (supported via dedicated Azure Sphere service UART)

Online authentication and firmware updates are supported for the MT3620 device lifetime.

To facilitate maximum utility of standalone application exercises, the Starter Kit integrates an on-board set of sensors (3D accelerometer, 3D Gyro, temperature sensor, ambient light sensor) plus support for optional low-cost, OLED 128x64 graphical display. Further system customization is facilitated via a wide range of (over 540) different Click boards as well as I2C Grove connected peripheral boards

The Starter Kit is fitted with Avnet's dual-band chip-antenna version Azure Sphere module (which is also footprint and function compatible with a higher specification U.FL Azure Sphere module, which features full TX and RX antenna diversity via two external dual-band antennas



Figure 1 – Avnet Azure Sphere MT3620 Module (Chip Antenna version)





Figure 2 – Avnet Azure Sphere MT3620 Starter Kit

## 6.1 Azure Sphere MT3620 Starter Kit Info

- Part Number: AES-MS-MT3620-SK-G
- Kit URL: <u>http://avnet.me/mt3620-kit</u>



## 6.2 Items Included in the Starter Kit

- Azure Sphere MT3620 Starter Kit Board
- Azure Sphere MT3620 Starter Kit QuickStart Card
- USB cable (type-A to microUSB)
- Downloadable examples, reference designs and documentation

## 6.3 Important Reference Documents

- Azure Sphere MT3620 Starter Kit QuickStart Card
- Azure Sphere MT3620 Starter Kit Product Brief
- Azure Sphere MT3620 Starter Kit Hardware User Guide
- Azure Sphere MT3620 Starter Kit Schematic
- Azure Sphere MT3620 Starter Kit Bill of Materials
- Azure Sphere MT3620 Module Product Brief
- Azure Sphere MT3620 Module Datasheet & Integration Guide
- MediatTek MT3620 Product Brief Nov2018
- <u>Microsoft Azure Sphere Installation Instructions</u>
- <u>Microsoft Azure Sphere Detailed Documentation</u>





## 7 Starter Kit Architecture and Features

## 7.1 List of Features

#### Azure Sphere MT3620 Starter Kit

- Azure Sphere MT3620 module
  - Onboard Chip Antenna (for 2.4GHz and 5GHz Wi-Fi operation)
- USB to serial 4-port interface (FT4232HQ)
  - Debug, Service, Recovery and SWD interfaces
- Onboard sensors:
  - o Ambient Light, 3-axis Accelerometer, 3-axis Gyro, Temperature, Barometric Pressure
- Multiple hardware expansion interfaces:
  - MikroE Click Board Expansion Sockets (two sockets. I2C,SPI,UART,ADC,etc interfaces)
  - o UART/BLE connector (2x6 pin R/A connector, compatible with a subset of Pmod boards)
  - Grove expansion connector (I2C)
  - Interface for optional OLED 128x64 display (I2C)
  - o Battery backup interface (2-pin VBAT compact terminal, not fitted)
  - +5V DC Aux interface (2-pin compact terminal, not fitted)
- Push-button switches (3) and Status LEDs (7)
- 5V to 3.3V DC power regulation (with over/under voltage protection) and power interfaces for:
  - USB 5V DC from host computer
  - AUX 5V DC (option to fit compact terminals)
  - VBAT (option to fit compact terminals)
  - ADC VREF external reference input (2-pin header)
- Operating Temperature: -30~85°C
- Dimensions: 75mm x 55mm
- Certification: FCC, IC, CE, MIC (pending), RoHS

#### Chip-Antenna Version Azure Sphere Module (Included on Starter Kit)

MT3620AN based module with the following features pinned-out:

- 1x 500MHz ARM Cortex A7, 4MB SRAM
- 2x 200MHz ARM Cortex M4F cores, 64KB SRAM
- OS: Azure Sphere Operating System for end-to-end security
- Programming & recovery Interface:
- 3x ISU interfaces, pre-configured for UART, SPI, I2C
- (max interface rates are: UART=3Mbps, SPI=40MHz, I2C=1MHz)
- ADC/GPIO: 3x 12bit ADC inputs (or can be used as GPIOs)
- PWM/GPIO: 9x PWM outputs, or can be used as GPIOs (for a total of up to 24 GPIOs)
- RTC : On-chip, requires VBAT supply
- Wi-Fi: Dual-band 2.4/5GHz 802.11 a/b/g/n
- Antenna: Single onboard dual-band 2.4/5GHz chip antenna (Pulse W3006)
- Operating Temperature: -30~85°C
- Dimensions: 33mm x 22mm x 3.68mm
- Certification: FCC, IC, CE, MIC (pending), RoHS

<u>UFL Version Azure Sphere Module</u> (\*\*\* Not on Starter Kit, but differences listed below, are of the higher specification Azure Sphere module version that is also available for OEM end-products, with identical footprint and functionality)

- MT3620AN features as listed above
- RF front-end: Facilitates RX and TX antenna diversity (added Diplexer and DPDT RF switch)
- Antennas: Two U.FL connectors for external 2.4/5GHz flex antennas
- Operating Temperature: Full -40C~85°C industrial rating (has 26 MHz TCXO)





## 7.2 Block Diagram - Avnet Azure Sphere MT3620 Starter Kit

Page 11



## 7.3 Block Diagram - Azure Sphere MT3620 Module



Note: Avnet's Sphere Starter Kit is fitted with the "chip antenna" version Azure Sphere MT3620 module



## 7.4 Hardware Expansion Options

Beyond the readily accessible onboard sensors (**Ambient Light, 3D Accelerometer, 3D Gyro, Temperature, Barometric Pressure**), a key differentiating feature of this Azure Sphere Starter Kit is the availability of multiple hardware expansion interfaces:

- MikroE Click Board expansion sockets (two sockets, I2C,SPI,UART,ADC,etc interfaces)
- UART/BLE connector (2x6 pin r/a connector compatible with some Pmod boards, not fitted)
- Grove Expansion Connector (I2C)
- OLED Interface for optional 128x64 display (I2C, not fitted)
- VBAT battery connector (option <u>not fitted</u>)
- AUX 5V DC (option not fitted)
- ADC VREF external reference input



Figure 3 – Starter Kit Fitted with Click, Grove and OLED Expansion Boards



## 8 Hardware Functional Description

## 8.1 Avnet Azure Sphere MT3620 module

The module pins-out a subset of the MT3620 SoC device functionality, via 66 castellated "stamp-hole" pads along three edges of it's compact 33mm x 22mm form-factor.

Refer to the following documents for detailed information on Avnet's certified Azure Sphere MT3620 module as well as the MT3620 Azure Sphere SoC device that this is based on

- Azure Sphere MT3620 Module Product Brief
- Azure Sphere MT3620 Module Datasheet & Integration Guide
- Media Tek MT3620 Product Brief Nov2018

## 8.2 USB to Serial 4-port Host Interface (FT4232HQ)

A significant part of this Starter Kit is the implementation of the Microsoft-specified 4-port USB to Serial bridge implementation for the RECOVERY, SERVICE, DEBUG and SWD interfaces.

A simplified block diagram of this 4-port USB to Serial bridge circuit is shown below:



See **section 9.4** of this document (Windows FTDI USB Driver Installation and Verification) for in-depth detail on driver installation and the use of these four interfaces



## 8.3 Configuration Jumpers, Status LEDs and Switches

#### 8.3.1 Setting the H/W Configuration Jumpers

The following two 3-pin jumpers <u>are factory-configured</u> as tabled below Note: The board will not boot-up if **J9** (RTC\_PWR) is configured for an invalid power source!

#	MT3620 Pin Name	Jumper Position	Setting Description
J6	ADC_VREF	Bridge pins 1-2	ADC range = 2V5 from MT3620
J9	RTC_PWR	Bridge pins <b>1-2</b>	RTC_PWR = 3V3 from supply rail

### 8.3.2 Push Button Switches

Three pushbuttons are located on the lower edge of the Starter Kit

Notes:

- RESET is located nearest the Sphere module
- Button A and Button B functions are software-defined (defined by the User application)

Tabled here are the MT3620 GPIO assignments for the push button switches

Button Switch	MT3620 GPIO	MT3620 Pin	MT3620 Function
USER-A	GPIO12	27	INT-capable GPIO
USER-B	GPIO13	28	INT-capable GPIO
RESET	SYSRST_N	125	System Reset, active low



Figure 4 – RESET and USER Push Button Switches



### 8.3.3 Status / Indicator LEDs

All LEDs are located along the board-edge between the USB connector and Button-B

Notes:

- LED3, LED4 and LED5 (RGB LED) functions are defined by the User application software

- LED3 and LED4 preferred functions are shown
- LED3, LED4 and LED5 (RGB LED) intensity can be varied via MT3620 PWM settings

Tabled here are the MT3620 GPIO assignments for the LEDs

Status LEDs	Color	Ref. Des.	MT3620 GPIO	MT3620 Pin	MT3620 Function
PWR 3V3 Status	Green	LED1	-	-	-
USB Activity	Yellow	LED2	-	-	-
APP. Status	Yellow	LED3	GPIO4	17	GPIO / PWM
WLAN Status	Yellow	LED4	GPIO5	18	GPIO / PWM
	Red	LED5	GPIO8	21	GPIO / PWM
USER RGB LED	Green	LED5	GPIO9	22	GPIO / PWM
	Blue	LED5	GPIO10	25	GPIO / PWM



Figure 5 – Location of the Status / Indicator LEDs



#### 8.4 Onboard sensors

#### 8.4.1 3D Accelerometer, 3D Gyro and Temperature (LSM6DSO)

The combo **LSM6DSO** iNemo device (from ST MicroElectronics) provides these three sensor functions. Measurements are accessed via the I2C bus

#### 8.4.2 Barometric Pressure (LPS22HH)

The **LPS22HH** device (from ST MicroElectronics) provides digital pressure output. Measurements are accessed via the LSM6DSO interface to the I2C bus.

The LSM6DSO acts as a sensor hub and is the I2C master on the secondary I2C bus to which the LPS22HH pressure sensor device is attached.

#### 8.4.3 Ambient Light Sensor (ALS-PT19)

The **ALS-PT19-315C/L177/TR8** (from Everlight) ambient light sensor provides analog-output light sensing. This sensor (**U3**) is located towards lower edge of the PCB, between the Sphere module and the large FTDI device



Figure 6 – Location of Ambient Light Sensor (U3)

Notes:

- U3 analog output is connected directly to ADC0 input of the MT3620
- Power to this light sensor is from the VOUT\_2V5 output of the MT3620
- The ADC function is not yet supported in Azure Sphere OS 19.02



## 8.5 Peripheral Expansion Interfaces

### 8.5.1 MikroE Click Sockets

Two Mikrobus Click sockets are available on the Sphere Starter Kit. Functionality of the Starter Kit hardware can be customised by choosing from **over 600** different Click Boards now listed in MikroE's user-friendly parametric search tool at <u>https://www.mikroe.com/click</u>

Purchase of Click boards from Avnet is assisted by entering applicable MikroE part# in the searchbox at the following page: <u>https://www.avnet.com/shop/us/m/mikroelektronika/</u>







#### Notes:

- The UART, I2C and SPI allocated ISU interfaces are common to both Click sockets
- The INT signal is common to both Click sockets (GPIO\_PWM2)
- The CS pin of the SPI interface is different on each Click socket (CSA and CSB)
- The AN, RST, CS and PWM signals are different on the two Click sockets
- All signalling on the Click sockets is at 3.3V levels

Tabled below is a listing of the MT3620 pinout to the two Click sockets:

Click1 Pin	Module Signal Name	Click1 Pin	Module Signal Name
AN	GPIO42_ADC1	PWM	GPIO0_PWM0
RST	GPIO16	INT	GPIO2_PWM2
CS	GPIO34_CSA1_CTS1	RX	GPIO28_MISO0_RXD0_SDA0
SCK	GPIO31_ <b>SCLK1</b> _TX1	ΤХ	GPIO26_SCLK0_TXD0
MISO	GPIO33_MISO1_RX1_DATA1	SCL	GPIO37_MOSI2_RTS2_SCL2
MOSI	GPIO32_MOSI1_RTS1_CLK1	SDA	GPIO38_MISO2_RXD2_SDA2
+3.3V	3V3	+5V	5V
GND	GND	GND	GND

#### Click Socket #1

## Click Socket #2

Click2 Pin	Module Signal Name	Click2 Pin	Module Signal Name
AN	GPIO43_ADC2	PWM	GPIO1_PWM1
RST	GPIO17	INT	GPIO2_PWM2
CS	GPIO35_ <b>CSB0</b>	RX	GPIO28_MISO0_RXD0_SDA0
SCK	GPIO31_ <b>SCLK1</b> _TX1	ТΧ	GPIO26_SCLK0_TXD0
MISO	GPIO33_MISO1_RX1_DATA1	SCL	GPIO37_MOSI2_RTS2_SCL2
MOSI	GPIO32_MOSI1_RTS1_CLK1	SDA	GPIO38_MISO2_RXD2_SDA2
+3.3V	3V3	+5V	5V
GND	GND	GND	GND



### 8.5.2 UART/BLE Connector

An unpopulated 2x6 connector site is located under Click Socket #2. The pinout of this footprint was designed to accommodate a 2x6 right-angle female socket, compatible with a subset of PMOD peripheral boards available from Digilent and others

Notes:

- The four UART pins and GPIO2 are shared with both Click sockets

Tabled below is a listing of the MT3620 pinout to this 2x6 socket:

- GPIO1 and GPIO17 are shared only with Click socket #2
- The WAKEUP input pin allows an external device to wake-up the MT3620 SoC
- All signalling on this socket is at 3.3V levels

**Pmod Pmod Signal Name Signal Name** Pin # Pin # 1 GPIO29 CSA0 CTS0 7 GPIO2 PWM2 2 GPIO26\_SCLK0\_TXD0 8 GPIO17 3 GPIO28 MISO0 RXD0 SDA0 9 GPIO1 PWM1 GPIO27\_MOSI0\_RTS0\_CLK0 WAKEUP 4 10 5 GND GND 11 6 3V3 12 3V3



Figure 7 – UART/BLE Female Right-Angle 2x6 Connector



Figure 8 – UART/BLE Female Connector (viewed from board edge)

Page 20



### 8.5.3 GROVE Connector

A GROVE connector is provided to facilitate system expansion using <u>GROVE modules</u> (sensors, actuators, etc.) - Go <u>here</u> for a listing of available functions

Notes:

- Only I2C and GPIO GROVE modules are supported
- The I2C interface is shared with the LSM6DSO sensor, Click sockets and OLED display (attention must be paid to the capacitive loading and clock-rate used on this I2C bus)

The pinout of the GROVE connector is tabled below:

GROVE Pin #	Signal Name	Signal Name
1	SCL	GPIO37_MOSI2_RTS2_SCL2
2	SDA	GPIO38_MISO2_RXD2_SDA2
3	3V3	3V3
4	GND	GND



Figure 9 – GROVE Connector (viewed from board edge)



### 8.5.4 OLED Display Interface

Low-cost (under \$10) 0.96" OLED 128x64 displays (I2C) are available from multiple sources <u>https://www.amazon.com/s?k=OLED+128+x+64+display</u>

Caution!

- The pinout numbering (and sequence of the I2C pins) for the 4-pin DISPLAY connector (J7) is different from that of 4-pin GROVE connector (J5)
- Make sure to select an OLED display with <u>GND and VCC in the order shown below</u> !!! (Some low-cost OLED displays reverse the sequence of the GND and VCC pins!)
- Two example OLED displays (based on SSD1306 display driver) with GND and VCC in the correct sequence are shown below:



by UCTRONICS

UCTRONICS 0.96 Inch OLED Module 12864 128x64 Yellow Blue SSD1306 Driver I2C Serial Self-Luminous Display Board for Arduino Raspberry PI

★★★★★ 21 customer reviews | 9 answered questions

Price: \$6.99 **vprime** 

New (2) from \$6.99 **√prime** 

#### Specifications for this item

Brand Name	UCTRONICS
Item Weight	0.012 ounces
Model Number	U602602
Part Number	U602602
Size	IIC/I2C Interface

Roll over image to zoom in

MakerFocus 2pcs I2C OLED Display Module 0.91 Inch I2C SSD1306 OLED Display Module Blue I2C OLED Screen Driver DC 3.3V~5V for Arduino



by MakerFocus 67 customer reviews 25 answered questions Amazon's Choice for "arduino oled"

Price: \$10.99 **vprime** 



The pinout of the OLED DISPLAY connector on this Starter Kit is tabled below:

GROVE Pin #	Signal Name	Signal Name
1	GND	GND
2	3V3	3V3
3	SCL	GPIO37_MOSI2_RTS2_SCL2
4	SDA	GPIO38_MISO2_RXD2_SDA2



Figure 10 – OLED Display Connector (viewed from board edge)



## 8.6 Power Interfaces, Regulation and Protection

#### 8.6.1 USB Host PC Interface

The MicroUSB connector interface provides the following functions:

- a) Combo serial over USB communication for the: RECOVERY, SERVICE, DEBUG and SWD interfaces.
- b) +5V power from the host PC (or powered USB hub) to the Starter Kit

#### 8.6.2 AUX 5V DC and VBAT Terminal Connectors

Connection points are provided via unpopulated footprints for two mini-terminal blocks located in top right corner of the board, for the following two external power sources, :

- a) **AUX 5V DC** input (nominal 5.0V, max 6.0V)
- b) **VBAT DC** input (min 2.50 V, max 3.63V). This is the RTC battery-backup voltage



#### 8.6.3 ADC VREF Header (J6)

The voltage reference input (J6 pin 2) for the 12bit A/D Convertor on the MT3620 device, must be powered. This reference voltage can be from one of two sources:

- a) VOUT\_2V5, the 2.5V LDO output from the MT3620 (bridge J6 pins 1 and 2), or
- b) External Vref (min 1.8V, max 2.5V), applied directly to J6 pin 2 (remove shorting link!)



#### ADC VREF



#### 8.6.4 Power Protection

An "Ideal Diode" circuit protects the USB VBUS 5V DC source from the AUX 5V DC input

An active "Over/Under Voltage Protection" circuit provides input voltage protection to the DC/DC regulator (MP5018GD input voltage max = 6.0V)

#### Ideal Diode



### 8.6.5 Power: 3.3V Regulation

A 5V to 3.3V buck convertor (rated for **2A max**) regulates the VCC rail voltage

EXT\_PMU\_EN is strapped via a weak pull-up (and is also routed to a test-point "EPEN")

#### **3V3 Buck Converter**





### 8.6.6 Power LED and Testpoints

The Starter Kit is powered by connecting one of two possible power sources:

- a) +5V via the provided USB cable, connected to the development computer
- b) +5V via the AUX 5V DC two-pin terminal block (this option <u>not fitted</u>), connected to an external +5V DC power adaptor, rated to deliver at least 1.5 A

#	Description	Desired Results / Comment
LED1	3V3 Power LED	LED1 illuminates Green when board is powered
3V3	3V3 Test Points	<ul> <li>Easiest probe access to 3.3V and GND is at the:</li> <li>DISPLAY connector</li> <li>GROVE Connector</li> <li>UART/BLE Connector</li> </ul>



Figure 11 – Recommended 3V3 and GND Test Points

#### 8.6.7 Measuring Power Consumption

It is suggested that a current-measurement USB "dongle" be used in-line with the USB connection to the host computer for monitoring the current drawn (at 5V)



Figure 12 – Current-measurement USB dongle Page 26



## **9** Software Development Environment Preparation

9.1 Microsoft Installation Instructions

Detailed guidance is provided at: https://docs.microsoft.com/en-us/azure-sphere/install/install

### 9.2 Verify Windows 10 Version

- 1) Before commencing software installation, verify the version of Windows 10 Operating System meets requirements. In the Windows search box (**Windows key + R**), enter **winver** to check...
- 2) The version reported must be **1607** or later... https://en.wikipedia.org/wiki/Windows\_10\_version\_history

About Windo	WS	Х
	Windows 10	
[	Microsoft Windows Version 1703 (OS Build 15063.1631)	
	C 2017 Microsoft Corporation. All rights reserved. The Windows 10 Enterprise operating system and its user interface are protected by trademark and other pending or existing intellectual property rights in the United States and other countries/regions.	

### 9.3 Install Azure Sphere SDK

- 1) Download and unzip the latest Microsoft Azure Sphere SDK from: <u>http://aka.ms/AzureSphereSDK</u>
- Install this SDK on a Windows 10 computer, using the instructions located at: <u>http://avnet.me/ms\_sphere\_docs</u>
- Once installed, launch the application and at the Azsphere command prompt, enter this command to confirm the Sphere SDK version:
   azsphere show-version
   The version reported should be 19.02 or later
   (Note: Connection to Sphere Starter Kit hardware is <u>not</u> required for this test)



### 9.4 Windows FTDI USB Drivers

#### 9.4.1 Windows FTDI USB Driver Installation

- 1) Plug-in the provided USB cable from the Azure Sphere Starter Kit, to the Windows 10 development computer
- 2) On first-time connection of a Starter Kit, the USB drivers should automatically download and install (this can be slow). If drivers do not install automatically, right-click on the device name in Windows Device Manager and select Update driver. Alternatively, download the drivers from Future Technology Devices International (FTDI), choose the driver that matches your Windows 10 installation (32- or 64-bit). Additional assistance on this aspect is available at: https://docs.microsoft.com/en-us/azure-sphere/install/install#connect-the-board

#### 9.4.2 Windows to FTDI Interfaces Verification

3) Open Windows Device Manager and confirm the following are listed:
 - three new COM ports (under Ports COM & LPT)
 - a TAP-Windows Adaptor V9 (under Network Adaptors)

🛃 Device Manager	_	×
File Action View Help		
<ul> <li>Network adapters</li> <li>Ports (COM &amp; LPT)</li> <li>Intel(R) Active Management Technology - SOL (COM3)</li> <li>USB Serial Port (COM64) Recovery UART</li> <li>USB Serial Port (COM66) Service UART</li> <li>USB Serial Port (COM67) Debug UART</li> </ul>		^
■ Device Manager           □ ×         File Action View Help		
<ul> <li>Network adapters</li> <li>Bluetooth Device (Personal Area Network)</li> <li>Bluetooth Device (RFCOMM Protocol TDI)</li> <li>Broadcom NetXtreme Gigabit Ethernet</li> <li>Cisco AnyConnect Secure Mobility Client Virtuz</li> <li>Intel(R) Dual Band Wireless-AC 8260</li> <li>Intel(R) Ethernet Connection (2) I219-LM</li> <li>TAP-Windows Adapter V9</li> </ul>		



- The steps on this page are only required if the FTDI <u>SERVICE interface fails</u> during first-time connection to the Azure Sphere Starter Kit
- 5) Open Windows network adapter settings
   ie. Windows search box (Windows key + R) then enter ncpa.cpl
- 6) Right-click on **Azure Sphere** TAP-Windows Adapter V9. Check it's properties are as shown below:

Network Connections			- 🗆 X
🗧 🔶 🕤 🛧 🔄 > Control Panel >	All Control Panel Items > Networ	rk Connections v 🖸 Search Netwo	ork Connections 🔎
Organize   Disable this network de	vice Diagnose this connection	Rename this connection »	!≡ - □ ?
Name	Status	Device Name	Connectivity
ഷ്പ് Wi-Fi	2WIRE872_5G	Intel(R) Dual Band Wireless-AC 8260	Internet access
🏺 VirtualBox Host-Only Network	Enabled	VirtualBox Host-Only Ethernet Adapter	
💭 Ethernet 4	Network cable unplugged	TAP-Windows Adapter V9 #2	
💭 Ethernet	Network cable unplugged	Intel(R) Ethernet Connection (2) I219-LM	
🟺 Cisco AnyConnect Secure Mobilit	AVNET.COM	Cisco AnyConnect Secure Mobility Client Virtual Mi	Internet access
Bluetooth Network Connection	Not connected	Bluetooth Device (Personal Area Network)	
🖗 Azure Sphere	Unidentified network	TAP-Windows Adapter V9	No network access
Diagnose Bridge Connections Create Shortcut Delete Rename Properties	This connection uses the for This connection uses the for Client for Microsoft File and Printer Sh Gravitation Virtual Box NDIS6 Gravitation Connection Client for Microsoft File and Printer Sh Client for Microsoft File and Printer Sh File and Printer Sh	ollowing items: t Networks aring for Microsoft Networks Bridged Networking Driver sduler t Network Access Manager Filter Driv	
7 items 1 item selected	Microsoft Network	Adapter Multiplexor Protocol      IP address:      Subnet mask:      Uninstall      Properues	Idress: 192 . 168 . 3 255 . 255 . 2 



### 9.5 DEBUG Interface

- 1) The DEBUG UART is typically the <u>highest numbered COM port</u> (of the three new COM ports) reported by Windows Device Manager, for the Starter Kit's FTDI USB interface
- 2) To view the output of this serial port, open Tera Term (or other serial console application) and configure it for the noted COM number, with UART set for 115200 8N1 communication rate
- 3) Connect the Tera Term terminal then press the **RESET button** on the Starter Kit. Startup debug text similar to the following should appear on the terminal screen



4) <u>Note!</u> Terminal connection to the Debug Interface must be closed before attempting to use the RECOVERY interface!

## 9.6 SERVICE interface

1) Open the Azure Sphere Developer Command-Line tool... (Sphere CLI)



2) Plug-in the USB cable from Starter Kit to the PC, then enter the following Sphere CLI command:

#### azsphere device show-attached

3) The board will report it's unique Azure Sphere Device ID... C:\TEST>azsphere device show-attached Device ID: DCED354379F883891026A30CC2C38F09928021FED3EC3428 9215331CF886F9FE642

Command completed successfully in 00:00:01.3812178.



## 9.7 RECOVERY Interface

This interface is for reloading/updating the Azure Sphere OS via a wired UART interface (typically for factory reprogramming of the MT3620 device) and will not be required by most developers.

Once an Azure Sphere Starter Kit is connected to the internet, Sphere OS updates are initiated automatically (or on demand) via the Over-The-Air (OTA) Wi-Fi interface

Notes:

a) The Sphere OS installed on the Azure Sphere module should be version 19.02 (or later) - Verify this by entering the following command at the SDK prompt:

azsphere device show-ota-status

C:\TEST<mark>azsphere device show-ota-status</mark> Your device is running Azure Sphere OS version 19.03. The Azure Sphere Security Service is targeting this device with Azure Sphere OS version 19.03 Your device has the expected version of the Azure Sphere OS: 19.03

b) Should manual recovery of the OS need to be done from local files rather than via Wi-Fi, the following command is used:

azsphere device recover --images <path to OS Recovery Images>

c) This takes approximately **2 min 43 seconds**. All contents of flash memory (Sphere OS, application software, Wi-Fi credentials and other config data) are erased during RECOVERY



## **10 Wi-Fi Connectivity**

### 10.1 Scan for Wi-Fi Access Points

A quick-check of Wi-Fi reception can be done by entering the following Sphere CLI command:

#### azsphere device wifi scan

After 10 seconds or so, a scan report displays detected SSIDs, signal-levels, etc in the format shown below:

Scan results:

SSID	: 2WIRE872_5G
Security state	: psk
BSSID	: 2c:56:dc:d6:fc:84
Signal level	: -46
Frequency	: 5180
SSID	: 2WIRE872
Security state	: psk
BSSID	: 2c:56:dc:d6:fc:80
Signal level	: -27
Frequency	: 2457
• • •	

## 10.2 Configuring the Wi-Fi Network Settings

Use the following command to configure the Wi-Fi settings (replace ????? with the applicable credentials)

azsphere device wifi add --ssid ?????? --key ??????

or abbreviated to: azsphere device wifi add -s ?????? -k ??????

Verify the present Wi-Fi connectivity status by entering: azsphere device wifi show-status

Other useful Wi-Fi commands are: azsphere device wifi list

azsphere device wifi enable

azsphere device wifi disable

azsphere device wifi delete

<u>Note</u>: Appendix-B in this document includes instructions for running a pre-compiled copy of the iPerf3 test application, to check Wi-Fi bit-rate performance with the currently selected Wi-Fi Access Point



## **11 Contact Info and Technical Support**

Documentation and reference designs are available for download from the product page: <u>http://avnet.me/mt3620-kit</u>

Links to instructional blogs are available at: <a href="http://avnet.me/mt3620-kit">http://avnet.me/mt3620-kit</a>

For further info on Avnet-designed Starter Kits, contact your local Avnet representative at:

Region	Organization	Email	Address & Phone
North America	Avnet Americas	eval.kits@avnet.com	AVNET - Americas 2211 South 47th Street Phoenix, AZ 85034, USA Phone: +1-800-585-1602
Europe	Avnet Silica	Microsoft@silica.com	Avnet Silica Gruber Str. 60c 85586 Poing, Germany Phone: +49-8121-77702



## **12 Disclaimer**

The Azure Sphere MT3620 Starter Kit is a development board designed to facilitate product evaluation and system-level prototyping.

This board is not intended for use as part of an end-product without additional steps being performed to ensure regional certification compliance.

Avnet assumes no liability for modifications that a user chooses to make to this Starter Kit.

## **13 Safety Warnings**





## 14 Appendix-A: Azure Sphere Module Pinout Detail



Figure 13 – Azure Sphere Module Pinout



### Azure Sphere Module Pinout Detail

Module Pad	MT3620 Pad	MT3620 Net Name	I/O	Pin Function	Pre-Assigned Starter Kit Eurotion=BLUE
1	1 44	GND	GND		
2	2.3	3V3	Power		
3	2.3	3V3	Power		
4	_,-		GND		
5	13	GPIO0 PWM0	1/0	GPIO / INT in / PWM out	PWM CLICK1
6	14	GPIO1 PWM1	I/O	GPIO / INT in / PWM out	PWM CLICK2
7	15	GPIO2 PWM2	I/O	GPIO / INT in / PWM out	INT_CLICK
8	17	GPIO4 PWM4	I/O	GPIO / INT in / PWM out	GPIO4_LED_APP
9	18	GPIO5 PWM5	I/O	GPIO / INT in / PWM out	GPIO5 LED WIFI
10	19	GPIO6_PWM6	I/O	GPIO / INT in / PWM out	INT_LSM6DSO
11	21	GPIO8_PWM8	I/O	GPIO / INT in / PWM out	GPIO8_LED_USER_RED
12	22	GPIO9_PWM9	I/O	GPIO / INT in / PWM out	GPIO9_LED_USER_GRN
13	25	GPIO10_PWM10	I/O	GPIO / INT in / PWM out	GPIO10_LED_USER_BLU
14	27	GPIO12	I/O	GPIO / INT in	GPIO12_SW_A
15	28	GPIO13	I/O	GPIO / INT in	GPIO13_SW_B
16	31	GPIO16	I/O	GPIO / INT in	RST CLICK1
17	32	GPIO17	I/O	GPIO / INT in	RST CLICK2
18	39	GPIO26_SCLK0_TXD0	I/O	GPIO / ISU0	UART TXD
19	40	GPIO27_MOSI0_RTS0_SCL0	I/O	GPIO / ISU0	UART RTS / I2C0
20	42	GPIO28_MISO0_RXD0_SDA0	I/O	GPIO / ISU0	UART RXD / I2C0
21	43	GPIO29_CSA0_CTS0	I/O	GPIO / ISU0	UART CTS
22	46	GPIO31_SCLK1_TXD1	I/O	GPIO / ISU1	SPI SCLK / UART1
23	47	GPIO32_MOSI1_RTS1_SCL1	I/O	GPIO / ISU1	SPI MOSI / UART1 / I2C1
24	48	GPIO33_MISO1_RXD1_SDA1	I/O	GPIO / ISU1	SPI MISO / UART1 / I2C1
25	49	GPIO34_CSA1_CTS1	I/O	GPIO / ISU1	SPI CS #1 / UART1
26	50	GPIO35_CSB1	I/O	GPIO / ISU1	SPI CS #2
27	52	GPIO37_MOSI2_RTS2_SCL2	I/O	GPIO / ISU2	12C
28	53	GPIO38_MISO2_RXD2_SDA2	I/O	GPIO / ISU2	12C
29	58	GPIO41_ADC0	I/O	GPIO / ADC in	AMBIENT LIGHT SENSOR
30	59	GPIO42_ADC1	I/O	GPIO / ADC in	AN CLICK1
31	60	GPIO43_ADC2	I/O	GPIO / ADC in	AN CLICK2
32	66	VOUT_2V5	AO		
33	67	VREF_ADC	AI		min 1.8V, max 2.5V
34	81	PMU_EN	I		pull-up on module
35	70	WAKEUP	I	Ext. Wakeup Input	pull-up on module
36	69	EXT_PMU_EN	0	Ext. 3V3 regulator enable	
37		GND	GND		



### Module Pinout (continued)

Module Pad	MT3620 Pad	MT3620 Net Name	I/O	Pin Function	Pre-Assigned Starter Kit Function=BLUE
38		GND	GND		
39	71	3V3_RTC	Power		min 2.50 V, max 3.63V
40		GND	GND		
41		GND	GND		
42	88,89	3V3	Power		
43	88,89	3V3	Power		
44	94	DEBUG_RXD	I	Debug UART	DEBUG_RXD
45	96	DEBUG_RTS	0	Debug UART (pulled-down / FTDI controlled strapping state on Starter Kit)	DEBUG_RTS
46	95	DEBUG_TXD	0	Debug UART (pulled-down on module)	DEBUG_TXD
47	97	DEBUG_CTS	I	Debug UART	DEBUG_CTS
48	98	SWD_DIO	I/O	CM4F SWD	SWD_DIO
49	99	SWD_CLK	I	CM4F SWD	SWD_CLK
50	100	SWO	0	CM4F SWD	SWO
51	125	SYSRST_N	I		SYSRST_N
52	127	SERVICE_TXD	0	Service UART	SERVICE_TXD
53	129	SERVICE_RXD	I	Service UART	SERVICE_RXD
54	128	SERVICE_RTS	0	Service UART	SERVICE_RTS
55	130	SERVICE_CTS	I	Service UART	SERVICE_CTS
56	134	RECOVERY_RXD	I	Recovery UART	RECOVERY_RXD
57	135	RECOVERY_TXD	0	Recovery UART (PU on module)	RECOVERY_TXD
58	136	RECOVERY_RTS	0	Recovery UART (pulled-down on module)	RECOVERY_RTS
59	137	RECOVERY_CTS	I	Recovery UART	RECOVERY_CTS
60	139	IO0_GPIO86/IO0_TXD	0	IO0_GPIO / IO0_TXD (pulled-down on module)	IO0_TXD
61	143	IO1_GPIO90/IO1_TXD	0	IO1_GPIO / IO1_TXD (pulled-down on module)	IO1_TXD
62 - 66		GND	GND	GND pour	
67		PADGND	GND	Thermal pad for MT3620	



## 15 Appendix-B: Running Pre-Compiled Example Applications

Pre-compiled, production-signed applications can be <u>side-loaded</u> to the MT3620 from **Azure Sphere SDK** <u>without</u> need to rebuild, sign and download the executable file from Microsoft Visual Studio.

## 15.1 GPIO Test Application

<u>Note</u>! For best results this application should be run with "Tester" Click boards fitted to Click sockets #1 and #2 (The application if run without these Click boards, will only sequnce the onboard LEDs)

Using Windows Explorer, copy the following "production-signed" application executable file into your **C:\TEST** folder

AvnetDevBoardTestApp\_ps.imagepackage

Launch the Azure Sphere Developer Command Prompt, then cut + paste the following command to change directories to this C:\TEST folder cd C:\TEST

At the Azure Sphere prompt, cut + paste the following command to side-load (via USB) this application onto the MT3620 device:

azsphere device sideload deploy -p AvnetDevBoardTestApp\_ps.imagepackage

The GPIO test application configures all MT3620 I/O ports to be GPIO outputs and walks a '1" value across these outputs. The resulting test pattern sequences the GPIOs as follows:

- 1) down the pins of socket #1 left-side
- 2) down the pins of socket #1 right-side
- 3) down the pins of **socket #2 left-side**
- 4) down the pins of socket #2 right-side
- 5) APP LED, WLAN LED, RGB-Red, RGB-Green, RGB-Blue



#### Notes:

- Socket #1 and socket #2 share some GPIOs (SCK, MISO, MOSI, INT, RX, TX, SCL, SDA)
- LEDs for these GPIOs will illuminate at the same time on both Click sockets.
- The test sequence can be repeated by pressing the A or B buttons
- When finished this test, delete this side-loaded app from the device:

#### azsphere device sideload delete



## 15.2 iPerf3 Test Application to Check Wi-Fi Performance

Using Windows Explorer, create a C:\TEST folder, then copy the following "production-signed" application executable file into this folder

iperf3 ps.imagepackage

Change directories to this C:\TEST folder using the following command

#### cd C:\TEST

Side-load (via USB) the production signed image onto the MT3620 device using the following command (the device does *not* need to be in debug mode!)

azsphere device sideload deploy -p iperf3 ps.imagepackage

#### iPerf3 Server:

On the development computer, do the following:

- 1) Download and unzip the iPerf 3.1.3 Windows application from https://iperf.fr/iperf-download.php
- 2) Unzip iperf-3.1.3-win64.zip to C:\Test
- 3) Turn-off Wi-Fi on the development computer



5) Configure the ethernet adaptor to have static IP address of **192.168.1.35** (plus the other highlighted settings shown below...)

Ethernet 3 P	operties	×	Internet Protocol Version 4 (TCP	P/IPv4) Properties	
tworking Sh	aring		General		
Connect using:	n Net Xtreme Gioabit Ethemet		You can get IP settings assigned this capability. Otherwise, you n for the appropriate IP settings.	d automatically if your network supports need to ask your network administrator	
-			Obtain an IP address autor	matically	
	Configure		• Use the following IP addres	ss:	
his connection	n uses the following items:		IP address:	192.168.1.35	
his connection	n uses the following items: for Microsoft Networks	^	IP address: Subnet mask:	192 . 168 . 1 . 35 255 . 255 . 255 . 0	
his connection           Image: Client state           Image: Client state	n uses the following items: for Microsoft Networks Id Printer Sharing for Microsoft Networks Box NDIS6 Bridged Networking Driver	^	IP address: Subnet mask: Default gateway:	192 . 168 . 1 . 35         255 . 255 . 255 . 0         192 . 168 . 1 . 1	
his connection	n uses the following items: for Microsoft Networks id Printer Sharing for Microsoft Networks Box NDIS6 Bridged Networking Driver acket Scheduler	^	IP address: Subnet mask: Default gateway:	192 . 168 . 1 . 35         255 . 255 . 255 . 0         192 . 168 . 1 . 1         sautomatically	
his connection	n uses the following items: for Microsoft Networks d Printer Sharing for Microsoft Networks Box NDIS6 Bridged Networking Driver acket Scheduler AnyConnect Network Access Manager Filter D at Protocol Version 4 (TCP/IPv4)	ńv	IP address: Subnet mask: Default gateway: Obtain DNS server address Obtain DNS server address	192 . 168 . 1 . 35         255 . 255 . 255 . 0         192 . 168 . 1 . 1         s automatically         rer addresses:	
his connection	n uses the following items: for Microsoft Networks id Printer Sharing for Microsoft Networks Box NDIS6 Bridged Networking Driver lacket Scheduler AnyConnect Network Access Manager Filter D et Protocol Version 4 (TCP/IPv4) oft Network Adapter Multiplexor Protocol	riv	IP address: Subnet mask: Default gateway: Obtain DNS server address © Use the following DNS serv Preferred DNS server:	192.168.1.35         255.255.255.0         192.168.1.1         s automatically         rer addresses:         192.168.1.1	

Now launch the **iperf3 server** on this test computer using the following command: iperf3 -s





#### iPerf3 Client:

Use the following command to configure the Wi-Fi settings: (replace **?????** with the applicable credentials)

#### azsphere device wifi add -ssid ?????? -key ??????

Note: The DUT Sphere module must connect to the same subnet as the test computer!

After Wi-Fi connection is established, reported iPerf bitrates should start appearing in the console window

***************************************											
* Starting iPerf3 Server on the Test Computer *											
***************************************											
Server listening on 5201											
Ad	ccep	ted connection	from	192.1	168.1.20	0, poi	rt 47070				
Г	5]	local 192.168.	1.35	port	5201 cor	nnecte	ed to 192.10	58.1.200	port 4	47072	
Ē	ID]	Interval		Trans	fer	Band	width				
[	5]	0.00-1.00	sec	4.85	MBytes	40.7	Mbits/sec				
[	5]	1.00-2.00	sec	5.25	MBytes	44.0	Mbits/sec				
[	5]	2.00-3.00	sec	5.36	MBytes	45.0	Mbits/sec				
[	5]	3.00-4.00	sec	5.33	MBytes	44.6	Mbits/sec				
[	5]	4.00-5.00	sec	5.31	MBytes	44.6	Mbits/sec				
[	5]	5.00-6.00	sec	5.31	MBytes	44.6	Mbits/sec				
[	5]	6.00-7.00	sec	5.16	MBytes	43.3	Mbits/sec				
[	5]	7.00-8.00	sec	5.18	MBytes	43.5	Mbits/sec				
[	5]	8.00-9.00	sec	5.15	MBytes	43.2	Mbits/sec				
[	5]	9.00-10.00	sec	5.22	MBytes	43.8	Mbits/sec				
[	5]	10.00-10.02	sec	78.8	KBytes	39.0	Mbits/sec				
-											
Ļ	ID	Interval		Trans	sfer	Band	width				
Ļ	5]	0.00-10.02	sec	0.00	Bytes (	0.00 l	bits/sec	1		sender	
L	5]	0.00-10.02	sec	52.2	MBytes	43.7	Mbits/sec			receive	r
•			•	••• >	г ,	-					
R€	Restart iPerts lest or Quit ? [ r / q ]										
Type input:											

Notes:

The iPerf3 Client and iPerf3 Server <u>must</u> both be on the same network sub-net ie, connected via same network router

If the reported bandwith (bitrate) is zero, use: **CTL+C** to stop the iPerf3 application, then

**iperf3** -s to restart the iPerf3 Server application (on the development computer)



## 15.3 Azure IoT Central - Sphere Starter Kit Out-of-Box Demo

<u>Note!</u> The procedure for this reference design is detailed in a three-part blog located at: <u>http://avnet.me/mt3620-kit-OOB-ref-design-blog</u>

The "Out-of-Box" Azure IoT Central application performs the following functions:

- The MT3620 application periodically samples XYZ Accelerometer, XYZ Gyro and temperature measurements (via the main I2C bus) from the STMicro LSM6DSO iNemo combo sensor, as well as barometric pressure and temperature measurements from the LPS22HH sensor (a secondary I2C bus exists between the LPS22HH sensor and the LSM6DSO, which acts as a sensor hub that samples and buffers measurements from sensors on the secondary I2C bus independently of the MT3620 SoC)
- 2) The MT3620 application reports the current state of the User-A and User-B pushbutton switches
- The MT3620 application periodically samples the network-related status (Wi-Fi SSID, BSSID and Wi-Fi frequency / channel)
- 4) The MT3620 application reports the multiple sensor measurements and status information:
  - a) via GDB to local console output in Visual Studio

Opening Starter Kit Button A as input *(GPIO12)* Opening Starter Kit Button B as input *(GPIO13)* SSID: AvnetIOTDEMO Frequency: 2462MHz bssid: 00:15:ff:7d:a8:5f

LSM6DSO: Acceleration [mg] : 62.8300, -36.9660, 1002.7180 LSM6DSO: Angular rate [dps] : 0.00, 0.00, 0.00 LSM6DSO: Temperature [degC]: 24.11 LPS22HH: Pressure [hPa] : 1063.18 LPS22HH: Temperature [degC]: 23.08

- b) via Wi-Fi over a secure internet connection to Azure IoT, from where these measurements:
   can be inspected in the chart visualization provided by Azure Time Series Insights
   are displayed in the visualization dashboard provided by Azure IoT Central
- 5) The Azure IoT Central application also provides a simple user-interface for remote control of selected MT3620 GPIOs on the Starter Kit:
  - USER RGB : Red, Green and Blue LEDs (GPI08, GPI09, GPI010)
  - APP LED : Yellow LED (GPIO4)
  - WLAN LED : Yellow LED (GPIO5)
  - CLICK SKT #1 : Relay #1 and Relay #2 outputs (GPIO34, GPIO0)
- A sampling of screen-shots are shown on the next two pages....
   Please refer to the 3-part blog for full instructions: <u>http://avnet.me/mt3620-kit-OOB-ref-design-blog</u>







Page 42





Device	Device ₽ BI AvnetStarterKit - Device 1						
🔄 🔂 AvnetStart							
Measurements Setting	s Properties Commands Rules Dashboard	Status					
믒 Update							
User RGB LED Controls	Application Status LED Controls	Click Module 1 Relay Control					
Red LED	WLAN LED	Relay #1					
OFF OFF	OFF	OFF OFF					
Green LED	APP LED	Relay #2					
OFF OFF	OFF	OFF OFF					
Blue LED							
OFF OFF							
✓ synced since 28 minutes ago							



