



Quick Start Guide

USB 3.0 Multi-Card Reader / Writer

GFR381
PART NO. Q1338

Package Contents

- 1 x USB 3.0 Multi-Card Reader / Writer
- 1 x USB 3.0 Cable (Micro-B to standard A)
- 1 x Quick Start Guide
- 1 x Warranty Card

If any of the items is missing or damaged, please contact us immediately.

System Requirements

PC


- Windows XP, Windows Vista, and Windows 7
- Available USB port (USB 3.0 port for Hi-Speed mode)

Mac

- Works with USB 2.0 and 1.1

Introduction

Start Here!



1. Micro SD

- Micro SD
- Micro SDXC
- T-Flash



2. MMC/SD*

- SD
- SDHC
- SDXC
- SD-Pro
- SD-Pleomax
- SD-Pro C
- SD-Ultra II
- SD-Ultra II Plus
- SD-Extreme III
- SD-Ultra X
- SD-Turbo
- SD-Supper
- SD Max
- Mini SD* **
- Mini SD-Pro* **
- Mini SD-Pleomax* **
- MMC
- MMC-Pleomax
- MMC Pro
- HS-MMC
- MMC Plus
- MMC-Plus Turbo
- RS MMC
- RS MMC-Pleomax
- RS MMC-Speed
- RS MMC-Max
- MMC Mobile
- MMC Mobile-ProC
- MMC Mobile-Pocketnet
- MMC Micro***

3. Memory Stick

- MS
 - MS-XC
 - MS-Magic Gate
 - MS-PRO Magic Gate
 - HS-MS-PRO Magic Gate
 - MS-DUO
 - MS DUO Magic Gate
 - MS-PRO Duo
 - HS-MS-PRO Duo
 - HS-MS-PRO Duo Magic Gate
 - MS-PRO Duo-PSP
 - MS-PRO Duo-Gaming
- Memory Stick

4. M2

- Memory Stick Micro (M2)**

5. Compact Flash/Micro Drive

- CF-Type I
- CF-Type II
- CF-Ultra II
- Micro Drive
- CF-Pro II
- CF-Extreme
- CF-Extreme III
- CF-PSP II
- CF-Supper
- CF-Ultra X

6. Olympus DC Card

- Olympus DC Card**
- Olympus DC Card(M)**
- Olympus DC Card (H)**

7. SuperSpeed USB 3.0 Type mini-B port (Female)

*Insert Mini SD into the left side of slot 2

**Insert cards with contacts facing up

*** Adapter required

Hardware Installation

Note: Before you begin, please make sure that the power to the device and your computer has been turned off.

Step 1.

Plug the USB 3.0 Micro-B connector into the Multi-Card Reader / Writer's USB 3.0 Type mini-B port



Step 2.

Plug the USB 3.0 standard A connector into the computer's USB 3.0 port.





Step 3.

Turn on the computer

Step 4.

Once the computer has finished booting up, insert the desired media card.

Step 5.

To view stored information / images on your memory cards, go to “My Computer.”

Remember, you may view the contents of more than one memory card at a time. However, MMC/SD **2** and Micro SD **1** slots will show as one Removable Disk; M2 **4** and MS **3** slots will show as one Removable Disk. Users cannot use both slots at the same time.

Warning: Formatting your card will permanently erase all your data/images

Note: Properly insert your media card into the Multi-Card Reader / Writer. The GFR381 is designed to accept media cards in a specific position. If you insert the media card and it does not easily slide all the way into the media slot, remove and rotate the card to properly fit into the slot.

Warranty

WE'RE HERE TO HELP YOU! NEED ASSISTANCE SETTING UP THIS PRODUCT?

Make sure you:

1. Use the live chat at www.iogear.com to try and solve any issues you may be having with the product
2. Visit the Tech Info Library/FAQ on www.iogear.com (under the Support tab)
3. Call tech support line at 1-866-946-4327 (U.S. only) or 949-453-8782

Warranty Information

This product carries a 3 Year Limited Warranty. For the terms and conditions of this warranty, please go to <http://www.iogear.com/support/warranty> or call 1-866-946-4327

Register online at <http://www.iogear.com/register>

Important Product Information

Product Model _____

Serial Number _____

Contact

Toll Free 866-9-IOGEAR (USA)

Phone: 949-453-8782

19641 Da Vinci, Foothill Ranch, CA92610

www.iogear.com

support@iogear.com

About Us



FUN

IOGEAR offers connectivity solutions that are innovative, fun, and stylish, helping people enjoy daily life using our high technology products.



GREEN

IOGEAR is an environmentally conscious company that emphasizes the importance of conserving natural resources. The use of our technology solutions helps reduce electronic waste.