Grove - 2 Channel Inductive Sensor (LDC1612)



The Grove - 2-Channel Inductive Sensor is based on Texas Instruments(TI) LDC1612, a 28-bit inductance to digital converter(LDC) for inductive sensing solutions. With multiple channels and support for remote sensing, the LDC1612 enables the performance and reliability benefits of inductive sensing to be realized at minimal cost and power. Inductance is an effect caused by the magnetic field of a current-carrying conductor acting back on the conductor. So by sensing the inductance, this sensor can detect the proximity of conductors especially metal nearby.

Get One Now 📜

[https://www.seeedstudio.com/Grove-2-Channel-Inductive-Sensor-%28LDC1612%29-p-3223.html]

Feature

- 2 Channels With Matched Sensor Drive
- Easy-to-Use: Minimal Configuration Required
- Multiple Channels Support Environmental and Aging Compensation
- Remote Sensor Position of >20 cm Supports Operation In Harsh Environments
- Coil Parameter: Diameter: 16mm/ Turns: 20

Specification

| Item | Value |
|----------------------------------|------------------------------------|
| Supply Voltage | 3.3V / 5V |
| Junction Temperature | -55~150°C |
| Supported Sensor Frequency Range | 1kHz~10MHz |
| Best Detecting Range | 15mm |
| Interface | I2C |
| I2C address | 0x2B(defult) 0x2A(configurable) |
| Package size | L: 140mm W: 90mm H: 10mm |
| Gross Weight | 12g |

When the ADDR pin is set low, the LDC I2C address is 0x2A; when the ADDR pin is set high, the LDC I2C address is 0x2B.

Typical applications

- · Knobs in consumer, appliances, and automotive
- Linear and rotational encoders
- Buttons in home electronics, wearables, manufacturing, and automotive
- Keypads in manufacturing and appliances
- Slider buttons in consumer products
- Metal detection in industrial and automotive
- POS and EPOS
- Flow meters in consumer and appliances

Hardware Overview

Pin Out



Notice

1. Set the Rb(resistance unit-kom), L(inductance unit-uH), C(capacitance unit-pf) by the APIs if you don't use the Coil Inductance we provided. Used to calculate and set the corresponding frequency register of the sensor. **2.** There is an INT-pad on the sensor board, It turns to the low level when the conversion is complete, overwise stays high, but you should configure the corresponding register of the sensor.

Working Principle

LDC1612 works based on measuring the parameters of the LC oscillator, formed by the PCB copper trace and the capacitor.

LDC1612 is able to measure the amount of energy it needs to provide to maintain the LC oscillation when a conductive object which is magnetically coupled with the LC oscillator approach. As the power loss of the oscillator circuit is proportional to the impedance of the conducting object, and the impedance value is affected by the distance of the object, it can then be used to determine the distance between the object and the LC oscillator. In this case, the PCB copper trace can be seen as an impedance sensor.

Platforms Supported



Caution

The platforms mentioned above as supported is/are an indication of the module's software or theoritical compatibility. We only provide software library or code examples for Arduino platform in most cases. It is not possible to provide software library / demo code for all possible MCU platforms. Hence, users have to write their own software library.

Getting Started

Play With Arduino

Hardware

Materials required

| Seeeduino V4.2 | Base Shield | Grove - |
|-----------------------------------------------------------------------------|-----------------------------------------------------------------------------|---------------------------------------|
| | - HILLING | |
| Get ONE Now [https://www.seeedstudio.com/Seeeduino- V4.2-p-2517.html] | Get ONE Now [https://www.seeedstudio.com/Base- Shield-V2-p-1378.html] | Get ON [https:/ 2-Chan %28LD |

Note

1 Please plug the USB cable gently, otherwise you may damage the port. Please use the USB cable with 4 wires inside, the 2 wires cable can't transfer data. If you are not sure about the wire you have, you can click here [https://www.seeedstudio.com/Micro-USB-Cable-48cm-p-1475.html] to buy.

2 Each Grove module comes with a Grove cable when you buy. In case you lose the Grove cable, you can click here [https://www.seeedstudio.com/Grove-Universal-4-Pin-Buckled-20cm-Cable-%285-PCs-pack%29-p-936.html] to buy.

- Step 1. Connect the Grove 2-Channel Inductive Sensor(LDC1612) to port I²C of Grove-Base Shield.
- Step 2. Plug Grove Base Shield into Seeeduino.
- Step 3. Connect Seeeduino to PC via a USB cable.



Now, we will demonstrate you how to run the code for coin distance detection, similar procedure if you wish to run other programs.

Software



If this is the first time you work with Arduino, we strongly recommend you to see Getting Started with Arduino [https://wiki.seeedstudio.com/Getting_Started_with_Arduino/] before the start.

- **Step 1.** Download the Grove-2-Channel_Inductive_Sensor-LDC1612 [https://github.com/Seeed-Studio/Seeed_LDC1612] Library from Github.
- Step 2. Refer to How to install library
 [https://wiki.seeedstudio.com/How_to_install_Arduino_Library] to install
 library for Arduino.
- **Step 3.** Restart the Arduino IDE. Open the example, you can open it in the following three ways:

- Sketch File Edit Tools Help 🔞 🕭 99+ 🖉 🎭 ЖN New Open... жo 01.Basics 02.Digital **Open Recent** 03.Analog Sketchbook ► 04.Communication Examples sketch_dec03a | 05.Control Close жw 06.Sensors Save ЖS 07.Display Save As... <mark>ሰ</mark> <mark>ස</mark>S 08.Strings Page Setup 企器P 09.USB here, to run once: Print ЖP 10.StarterKit_BasicKit 11 ArduinalSD **Examples for Arduino/Genuino Uno** EEPROM SoftwareSerial SPI Wire basic_demo Examples from Custom Libraries coin_test_demo muti_channel_demo Seeed Inductive Sensor LDC1612
- a. Open it directly in the Arduino IDE via the path: File \rightarrow Examples

\rightarrow Seeed Inductive Sensor LDC1612 \rightarrow coin_test_demo.

b. Open it in your computer by click the **basic_demo.ino** which you can find in the folder

XXXX\Arduino\libraries\examples\coin_test_demo\coin_test_demo.ino,

XXXX is the location you installed the Arduino IDE.

| 📃 doc | basic_demo | 🕨 處 coin_test_demo.ino |
|--------------|---------------------|------------------------|
| 📃 examples | coin_test_demo | |
| keywords.txt | 🔲 muti_channel_demo | ▶ |

c. Or, you can just click the icon 🔟 in upper right corner of the code block to copy the following code into a new sketch in the Arduino IDE.

Coin demo This program allows user to detect the distance from the coin to the copper trace.



```
10
11
    void setup()
12
13
        Serial.begin(115200);
14
        delay(100);
15
        Serial.println("start!");
16
17
        sensor.init();
18
19
        if(sensor.single_channel_config(CHANNEL_0))
20
21
            Serial.println("can't detect sensor!");
            while(1);
22
23
24
25
26
27
28
29
   void loop()
30
31
        u32 result channel1=0;
        u32 result_channel2=0;
32
33
34
35
36
37
38
        sensor.get_channel_result(CHANNEL_0,&result_channel1);
39
40
41
42
43
        if(0!=result_channel1)
44
45
            if(result channel1<DISTANCE 00)</pre>
46
47
                Serial.println("There is no coin here!");
48
49
50
            if(result channel1>=DISTANCE 00 01)
51
52
                Serial.println("The distance between the COIN is 0~1mm"
53
54
55
            if(result_channel1<DISTANCE_00_01&&result_channel1>=DISTANC
56
```

| 57 | Serial.println("The distance between the COIN is 1~5mm" |
|------|----------------------------------------------------------------------------------------------------------|
| 58 | } |
| 59 | |
| 60 | <pre>if(result_channel1<distance_01_05&&result_channel1>=DISTANC</distance_01_05&&result_channel1></pre> |
| 61 | { |
| 62 | Serial.println("The distance between the COIN is 5~10mm |
| 63 | } |
| 64 | |
| 65 | <pre>if(result_channel1<distance_05_10&&result_channel1>=DISTANC</distance_05_10&&result_channel1></pre> |
| 66 | { |
| 67 | Serial.println("The distance between the COIN is 10~15m |
| 68 | } |
| 69 | |
| 70 | <pre>if(result_channel1<distance_10_15&&result_channel1>=DISTANC</distance_10_15&&result_channel1></pre> |
| 71 | { |
| 72 | Serial.println("The distance between the COIN is 15~20m |
| 73 | } |
| 74 | |
| 75 | <pre>if(result_channel1<distance_15_20&&result_channel1>=DISTANC</distance_15_20&&result_channel1></pre> |
| 76 | { |
| 77 | Serial.println("The distance between the COIN is more t |
| 78 | } |
| 79 | |
| 80 | } |
| 81 | |
| 82 | delay(1000); |
| 83 } | |
| | |

Attention

The library file may be updated. This code may not be applicable to the updated library file, so we recommend that you use the first two methods.

Success

If everything goes well, you will see the following result

The distance between the COIN is 5~10mm
 The distance between the COIN is 5~10mm
 There is no coin here!
 The distance between the COIN is 10~15mm
 The distance between the COIN is 5~10mm
 The distance between the COIN is 1~5mm
 The distance between the COIN is 5~10mm
 The distance between the COIN is 5~10mm

Ū

8 The distance between the COIN is 5~10mm

Basic demo

Code for basic_demo.ino

```
Ē
    #include "Seeed_LDC1612.h"
1
2
   LDC1612 sensor;
4
6
   void setup()
8
        Serial.begin(115200);
9
        delay(100);
10
        Serial.println("start!");
11
12
        sensor.init();
13
        if(sensor.single_channel_config(CHANNEL_0))
14
15
16
            Serial.println("can't detect sensor!");
            while(1);
17
18
19
20
21
22
23
24 void loop()
25
26
        u32 result channel1=0;
27
        u32 result channel2=0;
28
29
30
31
32
33
        sensor.get_channel_result(CHANNEL_0,&result_channel1);
34
35
36
        if(0!=result channel1)
37
            Serial.print("result_channel0 is ");
38
            Serial.println(result_channel1);
39
```



Multi-Channel demo

This example shows multiple channels measurement and note LDC1612 support two channels.

You may connect coil 1 as shown below:



Code for muti_channel_demo.ino



```
22
23
24
25
26
   void loop()
27
28
        u32 result_channel0=0;
29
        u32 result_channel1=0;
30
31
32
33
34
35
        sensor.get_channel_result(0,&result_channel0);
36
        sensor.get_channel_result(1,&result_channel1);
37
38
        if(0!=result_channel0)
39
            Serial.print("result channel0 is ");
40
41
            Serial.println(result_channel0);
42
43
        if(0!=result_channel1)
44
45
            Serial.print("result_channel1 is ");
46
            Serial.println(result channel1);
47
48
        delay(1000);
49
```

Success

If everything goes well, you will see the following result

```
1
   start!
2 17:04:34.063 -> fsensor =3.74
  17:04:34.063 -> fsensor =3.74
3
   17:04:34.063 -> result_channel0 is 44399351
4
  17:04:34.063 -> result_channel1 is 43599310
6
   result channel0 is 44648052
   17:04:35.078 -> result_channel1 is 43803483
8 result_channel0 is 44786926
9 17:04:36.056 -> result_channel1 is 43990824
10 result channel0 is 44266733
11 17:04:37.069 -> result_channel1 is 43305067
12 result_channel0 is 44767222
```

ſ

```
13 17:04:38.092 -> result_channel1 is 43553768
14 result channel0 is 46081099
15 17:04:39.068 -> result_channel1 is 45089497
16 result channel0 is 44681202
17 17:04:40.083 -> result_channel1 is 43207588
18 can't detect coil Coil Inductance!!!
19 17:04:41.098 -> can't detect coil Coil Inductance!!!
20 can't detect coil Coil Inductance!!!
21 17:04:42.106 -> result_channel0 is 89478485
22 can't detect coil Coil Inductance!!!
23 17:04:43.081 -> result_channel0 is 49469095
24 result channel0 is 51374493
25 17:04:44.113 -> result_channel1 is 49895644
26 can't detect coil Coil Inductance!!!
27 17:04:45.090 -> can't detect coil Coil Inductance!!!
28 can't detect coil Coil Inductance!!!
```

Note

In basic_demo and muti_channel_demo examples, you may keep in mind that each output is corresponding to the intensity of inductance. There is the functional relationship between the output and the intensity of inductance, if you are interested in further information, you may want to refer to Datasheet LDC1612 [https://files.seeedstudio.com/wiki/Grove-2-Channel_Inductive_Sensor-LDC1612/res/LDC1612.pdf] provided by Texas Instrument(TI).

Schematic Online Viewer

Resources

- [Zip] Grove 2-Channel Inductive Sensor(LDC1612) Eagle Files [https://files.seeedstudio.com/wiki/Grove-2-Channel_Inductive_Sensor-LDC1612/res/Grove%20-%202-Channel%20Inductive%20Sensor%20(LDC1612).zip]
- [Zip] Grove 2-Channel Inductive Sensor(LDC1612) Software Library [https://github.com/Seeed-Studio/Seeed_LDC1612/archive/master.zip]
- **[PDF]** Datasheet LDC1612 [https://files.seeedstudio.com/wiki/Grove-2-Channel_Inductive_Sensor-LDC1612/res/LDC1612.pdf]

Tech Support

Please do not hesitate to submit the issue into our forum

[https://forum.seeedstudio.com/].



[https://www.seeedstudio.com/act-4.html? utm_source=wiki&utm_medium=wikibanner&utm_campaign=newproducts]