



IN-PROCESS 6

SLIDE PG-30-8 FORWARD AND SEAT AGAINST FLANGE ON SUB-MCR-8-12. SLIDE LW-30-8 FORWARD & LOOSELY THREAD PN-30-8 ONTO SUB-MCR-8-12 TO HOLD ITEMS IN PLACE




IN-PROCESS 7

REPEAT STEPS 2-6 FOR END 2, E-TEST CABLE, APPLY LABEL-ET & HDRL-11 TO BOTH ENDS, CUT CABLE IN HALF & TRIM BOTH ENDS TO FINISHED LENGTH.



RECOMMENDED PANEL OPENING (SEE NOTES 6 & 7)



PROPRIETARY NOTE

THIS DOCUMENT CONTAINS INFORMATION
CONFIDENTIAL AND PROPRIETARY TO
SAMIEC, INC. AND SHALL NOT BE REPRODUCED
OR TRANSFERRED TO OTHER DOCUMENTS OR
DISCLOSED TO OTHERS OR USED FOR ANY
PURPOSE OTHER THAN THAT WHICH IT WAS
OBTAINED WITHOUT THE EXPRESSED WRITTEN
CONSENT OF SAMIEC, INC.

DO NOT SCALE DRAWING

SHEET SCALE: 1:1



520 PARK EAST BLVD, NEW ALBANY, IN 47150 PHONE: 812-944-6733 FAX: 812-948-5047 e-Mail info@SAMTEC.com code 55322

DESCRIPTION:

MINI CIRC. PANEL ASSEMBLY

WG NO

MCR-8-02-X-XX.XX-X-XX

BY: J. BORGELT 4/11/2013 SHEET 2 OF 2