



Item	Description
VER-28334	Reztore Hand Lotion, 235ml

Description

Reztore™ ESD Hand Lotion is specially formulated for use in the electronic manufacturing environment. Per ESD Handbook ESD TR20.20 section 5.3.2.4.3 Test Procedure, "If the [wrist strap test] resistance is still too high, dry skin might be the problem. Dry skin conditions can be resolved by applying moisturizing lotion on the wrist and repeating the resistance test again. The moisturizing lotion should be one that is compatible with process requirements." The moisturizing hand lotion can be used to enhance the effectiveness of ESD control wrist straps, particularly for individuals with dry skin. It will absorb immediately into the skin without interfering with grip or dexterity. The lotion is free of chemicals that may adversely affect solderability or cause corrosion of electronic components.

Reztore™ Hand Lotion can also be used with ESD footwear. Per ESD Handbook ESD TR20.20 section 5.3.3.5 Common Testing Problems "Occasionally, footwear may indicate a high resistance. Outside of the shoe material itself being a contributor to high resistance, the wearer's skin (if dry), heavy or insulative socks, or the absence of a sweat layer due to differences in temperature between the inner surfaces of the shoes and the wearer's feet."

Specifications

Viscosity: 6000 Brookfield 20 Speed Spindle #4
Color: White
Odor: Pleasant
pH: $7.5 \pm .5$
Contaminants: No soap, lanolin, free-salts, silicones, or mineral oil
% Solids: $7.5 \pm 2\%$
Package: 235 ml plastic squeeze bottle
Freeze: Passes three freeze-thaw cycles



Made in the
United States of America

Vermason

Reztore™ Hand Lotion, 235mL

VERMASON
UNIT C, 4TH DIMENSION, FOURTH AVENUE, LETCHWORTH,
HERTS, SG6 2TD UK
PHONE: +44 (0) 1462-672005, FAX: +44 (0) 1462-670440
E-MAIL: Service@Vermason.co.uk, INTERNET: Vermason.co.uk

Drawing Number
VER-28334

DATE:
November
2015