
Order Number 200222-1400







FEATURES

This tool extracts Nano-Fit Plug crimped terminals from their housings


SCOPE


Products: Nano-Fit Plug Crimp Terminals, 24-26 AWG Wire.


Terminal Series No.	Terminal Order No.					Housing Series No.
201447	201447-1100	201447-1200	201447-1300	201447-1400	201447-1600	200277 and 201444

OPERATION

- 1. Position the extraction tool as shown in Figure 1.
- 2. Insert the extraction tool into the front of the connector housing. See Figure 2. The extraction tool should lightly rest on top of the nose of the terminal, as shown in Figure 3. Make sure that the terminal nose is straight in the housing.









Doc. No: 2002221400 Release Date: 10-26-21 **UNCONTROLLED COPY** Page 1 of 3 Revision Date: 10-26-21

Revision: B

3. The extraction tool arms will fit into grooves inside of the housing. See Figures 4 and 5.



- 4. Once the side arms of the extraction tool are seated in the housing grooves, continue pushing the extraction tool into the housing. Insert the extraction tool until it bottoms out on the front of the housing. Note: It may require more force once the extraction tool has been inserted past the thickness of the extractor.
- 5. There is a locking tab on the terminal that secures it inside the connector housing. When the extraction tool is fully seated in the connector housing, it will depress the locking tab. See Figure 6. Be sure to keep the extraction tool straight at all times.



Doc. No: 2002221400 Release Date: 10-26-21 UNCONTROLLED COPY Page 2 of 3

Revision: B Revision Date: 10-26-21

Extraction Tool for Nano-Fit Plug Crimp Terminals

6. Hold the connector housing and extraction tool with one hand and carefully remove the terminal from the housing. It may be necessary to gently pull on the wire to remove the terminal. See Figures 7 and 8.

EXTRACTION TOOL FULLY SEATED IN CONNECTOR HOUSING

Figure 7

EXTRACTION TOOL FULLY SEATED

Figure 8

CAUTION: This extraction tool should be used to extract the terminal only. Using it for unintended purposes may cause injury or damage to parts. Be careful not to deform the end of the terminal.

CAUTION: Molex specifications are valid only when used with Molex terminals, applicators and tooling.

Molex does not offer repair parts for extraction tools due to the inexpensive nature of these tools.

Application Tooling Support

Phone: (402) 458-TOOL (8665) **E-Mail:** applicationtooling@molex.com **Website:** www.molex.com/applicationtooling

Molex is a registered trademark of Molex, LLC in the United States of America and may be registered in other countries; all other trademarks listed herein belong to their respective owners.

Doc. No: 2002221400 Release Date: 10-26-21 UNCONTROLLED COPY Page 3 of 3

Revision: B Revision Date: 10-26-21