

Starrett®

Universal Dial Test Indicator Nos. 196 and 196M Important Instructions

Before using, unscrew contact button and remove the sleeve from center point or plunger, which is placed on all new or repaired indicators for protection in shipping.

Care should be taken in using the indicator, to keep oil of every kind from the center point, as oil gums and retards the movement. If the movement is slow and sluggish, the indicator should be cleaned.

No. 196R Adapter (sleeve threaded both ends) included with this indicator enables any contact point having an AGD 4-48 male thread to be used.

Do not attempt to repair your indicator. We will clean and repair it at factory cost of time and material. All repaired indicators are adjusted with as much care as we give to new ones. Many indicators are ruined by attempts at repairing, when cleaning only would be necessary.

**THE L.S. STARRETT COMPANY
Athol, Mass, USA**