

CHEMTRONICS

Technical Data Sheet

TDS Foamtips

Foamtips™

PRODUCT DESCRIPTION

The **Chemtronics® Foamtips™ Swabs** are constructed from medical grade foam which features the best open cell structure, providing excellent particle entrapment characteristics. The foam is thermally bonded to the swab handle without using adhesives. These swabs are ideal for general cleaning applications.

- Traps surface particles while cleaning
- High solvent capacity; holds solvent well
- Fiberless construction does not generate loose fibers or particles
- No adhesives or binders are used in the construction
- Economical for high quantity applications

TYPICAL APPLICATIONS

Chemtronics® Foamtips™ Swabs can be used to:

- Clean Excess Adhesives After Gluing
- Remove Contamination from Disk Drives
- Micro Mechanical Cleaning
- Maintenance and Care of Fax machines VCR's PC's Printers, and Copiers
- Remove Flux Residue from printed circuit boards
- Good for General Purpose Cleaning

COMPATIBILITY

Foam Heads are compatible with most common solvents such as isopropyl alcohol, and methanol. Not recommended for use with ketones such as acetone or methyl ethyl ketone.

Polypropylene Handles are generally compatible with all common solvents including most dilute or weak acids.

AVAILABILITY

- CF50** 6-1/8" swab with wood handle, foam over cotton head 50 swabs / bag
- CF1050** 5" round foamtip swab, polypropylene handle - 1" head 50 swabs / bag
- CF2050** 5" rectangular foamtip swab, polypropylene handle - 1" x 1/2" head 50 swabs / bag
- CF3050** 6" foamtip swab, polypropylene handle 3/4" x 1/4" head 50 swabs / bag
- CF4050** 2 7/8" foamtip swab, polypropylene handle - 1/2" x 3/16" head 50 swabs/bag

TECHNICAL AND APPLICATION ASSISTANCE

Chemtronics provides a technical hotline to answer your technical and application related questions.

The toll free number is: **1-800-TECH-401**.

Chemtronics® is a registered trademark of Chemtronics. All rights reserved. Foamtips™ is a trademark of Chemtronics. All rights reserved.

CHEMTRONICS
8125 Cobb Center Drive
Kennesaw, GA 30152
1-770-424-4888

REV. A (08/13)

DISTRIBUTED BY: