



Product Change Notification: BLAS-21SMFQ723

Date:

31-Oct-2024

Product Category:

16-Bit - Microcontrollers And Digital Signal Controllers, 8-Bit Microcontrollers, Analog to Digital Converters, Backlight LED Drivers, Battery Management and Fuel Gauges - Battery Chargers, CAN Controller, Capacitive Touch Sensors, Clock and Timing - Clock and Data Distribution, Clock and Timing - Clock Generation, Clock and Timing - High Speed Communication, CPU / System Supervisors, Digital Potentiometers, Digital Temperature Sensors, EL Backlight Driver ICs, Ethernet Controllers, Ethernet Phys, General Purpose LED Drivers, Instrumentation Amplifier, Interface- Serial Peripherals, LIN Transceiver With Vreg, Linear Comparators, Linear Op Amps, Linear Regulators, Memory, Motor Drivers, Power Management - PMIC, Power Management - Power Switches, Power Management - PWM Controllers, Power Management - Terminators, Power MOSFET Drivers, Switching Regulators, Wireless IC

Notification Subject:

CCB 6462 Initial Notice: Qualification of UNIG as a new assembly site for various products available in Tube, Tray and Tape & Reel packing media.

Affected CPNs:

[BLAS-21SMFQ723_Affected_CPN_10312024.pdf](#)

[BLAS-21SMFQ723_Affected_CPN_10312024.csv](#)

Notification Text:

PCN Status:Initial Notification

PCN Type:Manufacturing Change

Microchip Parts Affected:Please open one of the files found in the Affected CPNs section.

Note: For your convenience Microchip includes identical files in two formats (.pdf and .xls)

Description of Change:Qualification of UNIG as a new assembly site for various products available in Tube, Tray and Tape & Reel packing media.

Pre and Post Change Summary:

	Pre Change	Post Change
Assembly Site	Unisem (M) Berhad Perak, Malaysia (UNIS)	Unisem Gopeng (UNIG)
Wire Material	Au	Au
Die Attach Material	8290	8290
Molding Compound Material	G770HCD	G770HCD
Lead-Frame Material	A194ESH	A194ESH

Impacts to Data Sheet:None

Change Impact:None

Reason for Change:To improve on-time delivery performance by qualifying UNIG as a new assembly site.

Change Implementation Status:In Progress

Estimated Qualification Completion Date:October 2024

Note: Please be advised the qualification completion times may be extended because of unforeseen business conditions however implementation will not occur until after qualification has completed and a final PCN has been issued. The final PCN will include the qualification report and estimated first ship date. Also note that after the estimated first ship date guided in the final PCN customers may receive pre and post change parts.

Time Table Summary:

	November 2023					>	October 2024				
Workweek	44	45	46	47	48		40	41	42	43	44
Initial PCN Issue Date				x							
Qual Report Availability							x				

Final PCN Issue Date							X				
----------------------	--	--	--	--	--	--	---	--	--	--	--

Method to Identify Change:Traceability code

Qualification Plan:

Please open the attachments included with this PCN labeled as PCN_#_Qual_Plan.

Revision History:November 22, 2023: Issued initial notification.October 31, 2024: Re-issued initial notification. Updated the qualification plan to include High Temperature Storage Life (HTSL) test. Updated the affected CPN list to remove the EOL'd CPNs. Updated the estimated qualification completion date and the timetable summary from June 2024 to October 2024.

The change described in this PCN does not alter Microchip’s current regulatory compliance regarding the material content of the applicable products.

Attachments:

PCN_BLAS-21SMFQ723_Qual Plan.pdf

Please contact your local **Microchip sales office** with questions or concerns regarding this notification.

Terms and Conditions:

If you wish to receive Microchip PCNs via email please register for our PCN email service at our **PCN home page** select register then fill in the required fields. You will find instructions about registering for Microchips PCN email service in the **PCN FAQ** section.

If you wish to change your PCN profile, including opt out, please go to the **PCN home page** select login and sign into your myMicrochip account. Select a profile option from the left navigation bar and make the applicable selections.

Affected Catalog Part Numbers (CPN)

- PIC16F1827-I/ML
- PIC16F1827T-I/ML
- PIC16LF726-E/ML
- PIC16F1936-E/ML
- PIC16F1936-I/ML
- PIC16LF1826-I/ML
- PIC16LF1826T-I/ML
- PIC16LF1826-E/ML
- PIC18F24K20T-I/ML
- PIC16F1936T-I/ML
- PIC16F723A-E/ML
- PIC16F723A-I/ML
- PIC18LF2410-I/ML
- PIC18LF2321T-I/ML
- PIC16LF1936-E/ML
- PIC16LF1847-E/ML
- PIC16LF1933-E/ML
- PIC16LF1933-I/ML
- PIC24F16KL402-I/ML
- PIC16LF1933T-I/ML
- PIC24F08KL302-I/ML
- PIC18LF24K22-E/ML
- PIC18LF24K22-I/ML
- PIC18F23K22-E/ML
- PIC16LF1783-I/ML
- PIC16LF1783T-I/ML
- PIC16F722-I/ML
- PIC16F722T-I/ML
- PIC16F1847-I/ML
- PIC16F1847T-I/ML
- PIC18LF23K22-I/ML
- PIC18LF23K22T-I/ML
- PIC18LF2410T-I/ML
- PIC18LF1320T-I/ML
- PIC18F27J13T-I/ML
- PIC24F16KL402T-I/ML
- PIC18F26K20-E/ML
- PIC18F26J13-I/ML
- PIC18LF25K22-E/ML
- PIC18LF25K22-I/ML
- PIC18F24K22-E/ML
- PIC18F27J53T-I/ML
- PIC18F27J13-I/ML
- PIC18F27J53-I/ML
- PIC18F26J53-I/ML
- PIC16F1847-E/ML

PIC18F23K20-E/ML
PIC18LF25K22T-I/ML
PIC18F23K20-I/ML
PIC16LF1782-E/ML
MIC5333-PPYMT-TR
MIC5333-G4YMT-TR
MIC5333-J4YMT-TR
MIC5333-PMYMT-TR
MIC23155YMT-TR
MIC23155-GYMT-TR
PIC18F26K22T-I/ML
PIC24FJ64GA102-I/ML
PIC24FJ64GA102T-I/ML
PIC24FJ32GA102T-I/ML
PIC24FV16KA302-I/ML
PIC24FJ64GB002T-I/ML
PIC24FJ32GB002T-I/ML
PIC24FJ32GA102-I/ML
PIC24F16KA302T-I/ML
PIC24F32KA302T-I/ML
PIC24F16KA302-I/ML
PIC24F32KA302-I/ML
PIC24F32KA302T-E/ML
PIC24F32KA302-E/ML
PIC18F23K22T-I/ML
PIC18F25K22-I/ML
PIC24FV32KA302-I/ML
PIC24FV32KA302T-I/ML
PIC18F25K22T-I/ML
PIC18F24K22-I/ML
PIC18F24K22T-I/ML
PIC18F23K22-I/ML
PIC16F1933T-I/ML
PIC16F1933-I/ML
PIC24FJ64GB002-I/ML
PIC24FJ32GB002-I/ML
MCP23017-E/ML
MCP23017T-E/ML
MCP23S17-E/ML
MCP23S17T-E/ML
PIC16LF1847-I/ML
PIC16LF1847T-I/ML
DSPIC33FJ12MC202-E/ML
PIC16LF1713-I/ML
PIC16LF1716-I/ML
PIC16F1716-E/ML
SM813011UMG-TR
SM803331UMG
SM803331UMG-TR

- SM803335UMG
- SM803335UMG-TR
- SM803337UMG
- SM803337UMG-TR
- SM803334UMG
- SM803334UMG-TR
- SM803329UMG
- SM803329UMG-TR
- SM803340UMG
- SM803340UMG-TR
- SM803338UMG
- SM803338UMG-TR
- SM803339UMG
- SM803A340UMG
- SM803A340UMG-TR
- SM803339UMG-TR
- SM803332UMG
- SM803332UMG-TR
- SM803341UMG
- SM803341UMG-TR
- SM803348UMG-TR
- MIC23153YMT-TR
- MIC23153-GYMT-TR
- MIC4604YMT-TR
- MIC4604YMT-T5
- MIC4605-1YMT-TR
- MIC4605-1YMT-T5
- MIC4605-2YMT-TR
- MIC4605-2YMT-T5
- MIC5316-F4CYMT-TR
- MIC5316-F5CYMT-TR
- MIC5316-GGCYMT-TR
- MIC23250-AAYMT-TR
- MIC5316-GW3YMT-TR
- MIC23060-G4YMT-TR
- MIC2039AYMT-TR
- MIC2039BYMT-T5
- MIC2039BYMT-TR
- MIC2039EYMT-T5
- MIC2039EYMT-TR
- MIC2039FYMT-T5
- MIC2039FYMT-TR
- MIC2039AYMT-T5
- MIC37112YMT-TR
- MIC37120-1.8YMT-TR
- MIC37122YMT-TR
- MIC2033-05AYMT-T5
- MIC2033-05AYMT-TR
- MIC2033-05BYMT-T5

MIC2033-05BYMT-TR
MIC2033-08AYMT-TR
MIC2033-08BYMT-TR
MIC2033-10AYMT-T5
MIC2033-10AYMT-TR
MIC2033-10BYMT-T5
MIC2033-10BYMT-TR
MIC2033-12BYMT-TR
MIC2033-55AYMT-T5
MIC2033-55AYMT-TR
MIC5325-1.2YMT-TR
MIC5325-1.5YMT-TR
MIC5325-1.8YMT-TR
MIC5325-3.6YMT-TR
MIC5219-5.0YMT-TR
MIC5219YMT-TR
MIC5305-4.6YMT-TR
MIC5305-2.8YMT-TR
MIC5323YMT-TR
MIC5323-1.8YMT-TR
MIC5323-2.8YMT-TR
MIC5323-3.3YMT-TR
MIC47053YMT-TR
MIC47053YMT-T5
MIC5331-PMYMT-TR
MIC5332-MMYMT-TR
MIC5332-SSYMT-T5
MIC5332-SSYMT-TR
MIC2789-XYMT-TR
MIC5331-G4YMT-TR
MIC5332-J4YMT-TR
MIC2843AYMT-TR
MIC2843YMT-TR
MIC23164YMT-T5
MIC23164YMT-TR
MIC2844AYMT-TR
MIC5264-JGYML-TR
MIC5264-KGYML-TR
MIC5264-KKYML-TR
MIC5264-MGYML-TR
MIC5264-MJYML-TR
MIC5264-MKYML-TR
MIC5264-MMYML-TR
MIC5264-NFYML-TR
MIC5264-NGYML-TR
SM803348UMG
SM803347UMG
PIC18LF45K80-I/ML
PIC16F917-I/ML

- PIC16F917T-I/ML
- PIC16F914-I/ML
- PIC18LF4320T-I/MLC06
- PIC18LF4321-I/ML
- PIC18F4321-I/ML
- PIC18LF4510-I/ML
- PIC18F4680-I/ML
- PIC16F914T-I/ML
- PIC16F884-E/ML
- PIC16F747-I/ML
- PIC18LF4320-I/ML
- PIC18F4320-I/ML
- PIC18F442-I/ML
- PIC18F4410-I/ML
- PIC18LF4580-I/ML
- PIC18F4320-E/ML
- PIC18F4680-E/ML
- PIC18LF4221-I/ML
- PIC18F4221-I/ML
- PIC18F4680T-I/ML
- PIC18F46J13-I/ML
- PIC18F47J53-I/ML
- PIC18LF4620-I/ML035
- PIC18F47J13-I/ML
- PIC18F43K20-I/ML
- PIC18F43K20T-I/ML
- PIC18F44J50-I/ML
- PIC18F46J50T-I/ML
- PIC24HJ32GP302T-E/MM
- DSPIC33FJ64GP202T-E/MM
- DSPIC33FJ64GP802T-E/MM
- DSPIC33FJ128GP202T-E/MM
- DSPIC30F1010-20E/MM
- DSPIC30F2020-20E/MM
- DSPIC33FJ64MC802-I/MM
- DSPIC33FJ128MC202-I/MM
- DSPIC33FJ128MC802-I/MM
- DSPIC33FJ32MC302-I/MM
- PIC24HJ128GP502T-I/MM
- PIC24HJ32GP302T-I/MM
- DSPIC33FJ64GP202T-I/MM
- DSPIC33FJ64GP802T-I/MM
- DSPIC33FJ128GP802T-E/MM
- DSPIC33FJ32GP302T-E/MM
- DSPIC33FJ64MC202T-E/MM
- DSPIC33FJ64MC802T-E/MM
- DSPIC33FJ06GS202A-I/MM
- DSPIC33FJ128GP202T-I/MM
- DSPIC33FJ128GP802T-I/MM

DSPIC33FJ32GP302T-I/MM
DSPIC33FJ64MC202T-I/MM
DSPIC33FJ64MC802T-I/MM
DSPIC33FJ128MC202T-E/MM
DSPIC33FJ128MC802T-E/MM
DSPIC33FJ32MC302T-E/MM
DSPIC33FJ06GS102A-I/MM
DSPIC33FJ09GS302-I/MM
DSPIC33FJ128MC202T-I/MM
DSPIC33FJ128MC802T-I/MM
DSPIC33FJ32MC302T-I/MM
DSPIC30F1010-30I/MM
DSPIC30F2020-30I/MM
DSPIC30F2020T-30I/MM
DSPIC33FJ64MC202T-E/MMC04
PIC18LF25K80-I/MM
PIC18LF26K80-I/MM
PIC18LF26K80-I/MMC01
PIC18LF26K80T-I/MMC01
PIC18F25K80-E/MM
PIC18F26K80-E/MM
PIC18F25K80-E/MMC01
PIC18F25K80-I/MM
PIC18F26K80-I/MM
PIC18F25K80-I/MMC04
PIC18F25K80T-I/MM
PIC18F26K80T-I/MM
PIC18F25K80T-I/MMC04
PIC18F25K80T-E/MM
PIC18F26K80T-E/MM
PIC18F25K80T-E/MMC01
PIC18F25K80T-E/MMCUI
DSPIC33FJ128GP802T-I/MM039
DSPIC33FJ16GS502-E/MMC03
DSPIC33FJ64GP802T-E/MM041
PIC24HJ64GP502-H/MM
PIC24HJ128GP202-E/MMC01
PIC18F26K22T-I/ML032
PIC16F876AT-E/ML
PIC16F72-E/ML
PIC16F648A-I/ML
PIC16F648AT-E/ML
PIC16F648AT-I/ML
PIC16F716-E/ML
PIC16LF648A-I/ML
PIC16LF648AT-I/ML
PIC16F648A-E/ML
PIC16F628A-I/ML
PIC16F628AT-I/ML

PIC16LF628AT-I/ML
PIC16LF628A-I/ML
PIC16LF88-I/ML
PIC16F88-I/ML
PIC16LF87-I/ML
PIC16F87-I/ML
PIC16LF88T-I/ML
PIC16F88T-I/ML
PIC18F46J50-I/ML
PIC18F45J50-I/ML
PIC18LF4680-I/ML
PIC18F46J11T-I/ML
PIC16F707-E/ML
PIC18F4480-E/ML
PIC18F44J11-I/ML
PIC18F46J11-I/ML
PIC18F45J11-I/ML
PIC18F46J53-I/ML
PIC18F44K20-I/ML
PIC18F44K20T-I/ML
PIC18F45K20T-I/ML
PIC18F44K20-E/ML
PIC18F45K20-I/ML
PIC18F45K20T-I/MLC01
PIC18LF43K22-I/ML
PIC18LF4585-I/ML
PIC18F4585-I/ML
PIC18F4580-E/ML
PIC18F4585-E/ML
PIC18F44K22-E/ML
MIC5399-GMYMX-T5
MIC5399-GMYMX-TR
MIC5399-MMYMX-T5
MIC5399-MMYMX-TR
MIC5399-SGYMX-T5
MIC5399-SGYMX-TR
MIC5399-SMYMX-T5
MIC5399-SMYMX-TR
MIC5399-SSYMX-T5
MIC5399-SSYMX-TR
MIC5396-GMYMX-TR
MIC5396-GMYMX-T5
MIC5397-GPYMX-T5
MIC5397-GPYMX-TR
MIC5398-P4YMX-T5
MIC5398-P4YMX-TR
PIC18F2480-I/ML
PIC18F2480T-I/ML
PIC18F2580-I/ML

PIC18F2580T-I/ML
PIC18F2480T-E/ML
PIC18F2480-E/ML
PIC18F2331-E/MM
PIC18LF2580-I/ML
PIC18LF2431-I/MM
PIC18F2431-E/MM
PIC18F2331-I/MM
PIC18F2480-I/MLC01
PIC18LF2480T-I/ML
PIC18LF2480-I/ML
PIC18F2431-I/MM
PIC18LF2331-I/MM
PIC18F2580-E/ML
PIC18F2580T-E/ML
DSPIC33FJ32GP302T-E/MMC03
DSPIC33FJ64GP802T-I/MMB21
DSPIC33FJ64GP802-I/MMB21
HA7612-I/MM033
HA7612T-I/MM033
DSPIC33FJ16GS502T-E/MMC03
PIC18LF2331T-I/MM
DSPIC33FJ64MC202-E/MMC04
PIC18F25K80-I/MM030
PIC18F25K80-I/MM032
DSPIC30F2010T-30V/MMA31
DSPIC33FJ32MC202T-I/MM
PIC18F1330-I/ML
PIC18F1330-I/MLXXX
PIC18LF1230-I/ML
PIC18F1230-I/ML
PIC18F2450T-I/ML
PIC18F1230-I/MLXXX
PIC18LF1330-I/ML
PIC16LF627A-I/ML
PIC16F627A-I/ML
PIC16LF876A-I/ML
PIC16F876A-I/ML
PIC16LF767-I/ML
PIC16F913T-I/ML
PIC16F913-I/ML
PIC16F627AT-I/ML
PIC18LF2523-I/ML
PIC16F916T-I/ML
PIC16F876A-E/ML
PIC16F916-I/ML
PIC16F767-I/ML
PIC18LF2450-I/ML
PIC18F2450-I/ML

PIC16F873A-I/ML
PIC16LF873A-I/ML
PIC16LF873AT-I/ML
PIC16F873AT-I/ML
MCP23016-I/ML
PIC16F882-I/ML
PIC16LF72-I/ML026
PIC18F1330-E/ML
PIC16F882T-I/ML
PIC18F2420T-E/ML
PIC18F2420-E/ML
PIC16LF73-I/ML
PIC16F73-I/ML
PIC16LF76-I/ML
PIC18F2420-I/ML
PIC16LF72-I/ML
PIC18F2420T-I/ML
PIC16F876AT-I/ML
SM803327UMG-TR
SM813009UMG
SM813009UMG-TR
SM803328UMG
SM803328UMG-TR
SM8130010UMG
SM8130010UMG-TR
SM813010UMG
SM813010UMG-TR
SM803333UMG
SM803333UMG-TR
SM803330UMG
SM803330UMG-TR
SM813011UMG
DSPIC33FJ32GP202T-E/MM
DSPIC33FJ32MC202T-E/MM
DSPIC33FJ16GS502-H/MM
DSPIC33FJ06GS202T-I/MM
DSPIC33FJ06GS102T-I/MM
DSPIC33FJ16GS402T-I/MM
DSPIC33FJ16GS502T-I/MM
DSPIC33FJ06GS202-E/MM
DSPIC33FJ16GS402-E/MM
DSPIC33FJ16GS502-E/MM
DSPIC33FJ06GS202T-E/MM
DSPIC33FJ06GS102T-E/MM
DSPIC33FJ16GS402T-E/MM
DSPIC33FJ16GS502T-E/MM
DSPIC33FJ16GS402-50I/MM
DSPIC33FJ16GS502-50I/MM
DSPIC33FJ06GS202-I/MM

DSPIC33FJ06GS102-I/MM
DSPIC33FJ16GS402-I/MM
DSPIC33FJ16GS502-I/MM
DSPIC33FJ16GS402T-50I/MM
DSPIC33FJ16GS502T-50I/MM
PIC24HJ32GP202-E/MM
DSPIC33FJ32GP202-E/MM
DSPIC33FJ32MC202-E/MM
PIC24HJ32GP202-I/MM
DSPIC33FJ32GP202-I/MM
DSPIC33FJ32MC202-I/MM
DSPIC33FJ32MC202T-H/MM
DSPIC33FJ32MC202-H/MM
PIC24HJ32GP202T-I/MM
DSPIC33FJ32GP202T-I/MM
DSPIC30F2010T-20E/MM
DSPIC30F2010-20E/MM
DSPIC30F2010-20I/MM
DSPIC30F2010-30I/MM
DSPIC30F2010T-20I/MM
DSPIC30F2010T-30I/MM
PIC24HJ128GP502-H/MM
DSPIC33FJ64GP802-H/MM
DSPIC33FJ64MC802-H/MM
DSPIC33FJ128MC802-H/MM
PIC24HJ64GP202-E/MM
PIC24HJ64GP502-E/MM
PIC24HJ128GP202-E/MM
PIC24HJ128GP502-E/MM
PIC24HJ32GP302-E/MM
DSPIC33FJ64GP202-E/MM
DSPIC33FJ64GP802-E/MM
DSPIC33FJ128GP202-E/MM
DSPIC33FJ128GP802-E/MM
DSPIC33FJ32GP302-E/MM
DSPIC33FJ64MC202-E/MM
DSPIC33FJ64MC802-E/MM
PIC24HJ64GP202-I/MM
PIC24HJ64GP502-I/MM
PIC24HJ128GP202-I/MM
DSPIC33FJ128MC202-E/MM
DSPIC33FJ128MC802-E/MM
DSPIC33FJ32MC302-E/MM
PIC24HJ128GP502-I/MM
PIC24HJ32GP302-I/MM
DSPIC33FJ64GP202-I/MM
DSPIC33FJ64GP802-I/MM
PIC24HJ64GP202T-E/MM
PIC24HJ64GP502T-E/MM

PIC24HJ128GP202T-E/MM
PIC24HJ128GP502T-E/MM
DSPIC33FJ06GS102A-E/MM
DSPIC33FJ09GS302-E/MM
DSPIC33FJ128GP202-I/MM
DSPIC33FJ128GP802-I/MM
DSPIC33FJ32GP302-I/MM
DSPIC33FJ64MC202-I/MM
PIC24HJ64GP202T-I/MM
PIC24HJ64GP502T-I/MM
PIC24HJ128GP202T-I/MM
MIC94310-4YMT-T5
MIC94310-4YMT-TR
SM802405UMG
SM802405UMG-TR
SM802406UMG
SM802406UMG-TR
SM802355UMG
SM802355UMG-TR
SM802413UMG
SM802413UMG-TR
SM802421UMG-TR
SM802421UMG
SY88932LMG
SY89874AUMG
SY89228UMG
SY58023UMG
MIC4555YML-TR
MIC2550YML-TR
PIC18LF2510-I/ML
PIC18F2510-I/ML
PIC16F916-E/ML
PIC18LF1320-I/ML
PIC18F25J50-I/ML
PIC18F26J50-I/ML
PIC18LF2221-I/ML
PIC18F2221-I/ML
PIC18F25K20T-E/ML
PIC18F24K20-I/ML
PIC16LF819-I/ML
PIC16F722A-I/ML
PIC16F722AT-I/ML
PIC16F723AT-I/ML
SM802002
SM802006
SM802358UMG
SM802360UMG
PL903162UMG
PL903163UMG

PL903164UMG
SM802104UMG
SM802105UMG
SM802116UMG
SM802108UMG
SM802109UMG
SM802110UMG
SM802111UMG
SM802365UMG
SM802140UMG
SY89843UMG
SY89844UMG
SY89845UMG
SY89473UMG
SM802381UMG
SM802382UMG
SM802383UMG
SM802182UMG
SM802185UMG
SM802204UMG
SY58620LMG
SM802251UMG
SM802378UMG
SM802379UMG
SY88432LMG
PL903165UMG
PL607041UMG
MIC3003GML
MIC3001GML
MIC3003AGML
MIC3003AGML-TR
SPN950004
MIC2555-0YML-TR
MIC2555-1YML-TR
SM802401UMG
SY58621LMG-TR
SY89474UMG-TR
SY89844UMG-TR
SY89297UMG-TR
PL903150UMG-T5
PL903150UMG-TR
PL903151UMG-T5
PL903151UMG-TR
PL903160UMG-TR
MIC2550AYML-TR
MIC2101YML-TR
MIC2102YML-TR
MIC2103YML-TR
MIC2104YML-TR

MIC4600YML-T5
MIC4600YML-TR
SPN030050G-TR
MIC4742YML-TR
MIC4744YML-TR
SY54011RMG
SY75572LMG
SY58011UMG
SY58012UMG
SY84113BUMG
SY89834UMG
SY89874UMG
SY84782UMG
SY89875UMG
SY89230UMG
SY89231UMG
SY89876LMG
SY89840UMG
SY89841UMG
SY89842UMG
SY89851UMG
SY89852UMG
MCP1703A-5002E/MC
MIC2125YML-T5
MIC2125YML-TR
MIC2126YML-T5
MIC2126YML-TR
MIC23158YML-TR
MIC23158YML-T5
MIC23159YML-TR
MIC23159YML-T5
MIC22400YML-TR
MIC22405YML-TR
SY89296UMG-TR
SY58034UMG-TR
SY89854UMG
SY89831UMG
SY89832UMG
SY89871UMG
SY89833ALMG
SY89872UMG
SY89833LMG
SY89873LMG
SY54017ARMG
SY54017RMG
SY54020ARMG
SY54020RMG
SY58609UMG
SY58610UMG

SY58611UMG
SY54023ARMG
SY54023RMG
SY56011RMG
SY56017RMG
SY56020RMG
SY56020XRMG
SY56023RMG
SY56216RMG
SY88422LMG
SY58020UMG
SY58021UMG
SY58022UMG
SM802383UMG-TR
SM802395UMG-TR
SM802401UMG-TR
MIC3001GML-TR
SPN950001-TR
SPN950002-TR
MIC3003GML-TR
SY88432LMG-TR
SY89473UMG-TR
SY58620LMG-TR
SY89843UMG-TR
PL903101UMG-T5
PL903101UMG-TR
SM802365UMG-TR
SM802378UMG-TR
SM802379UMG-TR
SM802381UMG-TR
SM802382UMG-TR
PL903161UMG-TR
PL903162UMG-TR
PL903163UMG-TR
PL903164UMG-TR
PL903165UMG-TR
PL602041UMG-TR
SM802111UMG-TR
SM802116UMG-TR
SM802121UMG-TR
SM802140UMG-TR
SM802185UMG-TR
SM802251UMG-TR
SM802356UMG-TR
SM802357UMG-TR
SM802358UMG-TR
SM802360UMG-TR
SPN950004-TR
SM802404UMG

SM802404UMG-TR
SM802105UMG-TR
SM802391UMG
SM802391UMG-TR
PL903166UMG-TR
PL903166UMG
SM802416UMG
SM802416UMG-TR
SM802415UMG
SM802415UMG-TR
SY88992LMG
SY58013UMG
SY58016LMG
SY58017UMG
SY58018UMG
SY58019UMG
SY58051AUMG
SY88022ALMG-TR
SY88022ALMG
SY58052AUMG
SY58606UMG
SY58607UMG
SY58608UMG
SY88149HALMG
SY56034ARMG-TR
SY58626LMH-TR
SY58024UMG-TR
SY58025UMG-TR
SY58026UMG-TR
SY58027UMG-TR
SY56028XRMG-TR
SY58028UMG-TR
SY89544UMG-TR
SY89545LMG-TR
SY89547LMG-TR
SY89837UMG-TR
SY89838UMG-TR
SY89846UMG-TR
SY89847UMG-TR
SY55859LMG-TR
SY75578LMG-TR
SY89200UMG-TR
SY89202UMG-TR
SY89542UMG-TR
SY89543LMG-TR
SY58029UMG-TR
SY58030UMG-TR
SY58031UMG-TR
SY58032UMG-TR

SY58033UMG-TR
SM802398UMG-TR
SY58036UMG-TR
SY56572XRMG-TR
SY58627LMG-TR
SY89546UMG-TR
SM802386UMG-TR
SM802392UMG-TR
SM802397UMG-TR
SM802362UMG-TR
SM802363UMG-TR
SM802364UMG-TR
SM802368UMG-TR
SM802377UMG-TR
SY58035UMG-TR
SY89838UMG001-TR
SY58627LMG
SM803002
SM803062UMG
SM803115UMG
SM803062UMG-TR
SM803115UMG-TR
MIC261203-ZAYJL-TR
MIC261203-ZYJL-TR
MIC24056YJL-TR
MIC261203YJL-TR
MIC24055YJL-TR
MIC261201YJL-TR
MIC26603-ZYJL-TR
MIC28510HYJL-TR
MIC24053YJL-TR
MIC26901YJL-TR
MIC26903YJL-TR
MIC26903-ZAYJL-TR
MIC26603-ZAYJL-TR
MIC24051YJL-TR
MIC24052YJL-TR
MIC26601YJL-TR
MIC26603YJL-TR
MIC24054YJL-TR
MIC27600YJL-TR
MIC28510YJL-TR
MIC26400YJL-TR
MIC26950YJL-TR
SPN030054-TR
SPN030055-TR
MIC26600YJL-TR
MIC27600YJL-TRAAA
SM802384UMG

SM802389UMG
SM802387UMG
SM802388UMG
SM802385UMG
PL602081UMG
MCP73830LT-0BCI/MYY
MCP73830T-2AAI/MYY
MCP73830LT-0AAI/MYY
MCP6402T-E/MNY
MCP6N11T-001E/MNY
MCP6N11T-005E/MNY
MCP6N11T-002E/MNY
MIC2130-1YML-TR
MIC2130-4YML-TR
MIC2131-1YML-TR
MIC2131-4YML-TR
MIC4606-1YML-TR
MIC4606-1YML-T5
MIC2214-AA YML-TR
MIC2214-AA YML-T5
MIC2215-MMGYML-TR
MIC4606-2YML-TR
MIC4606-2YML-T5
MIC2215-PPGYML-TR
93AA46BT-I/MNY
93LC46CT-I/MNY
93AA46CT-I/MNY
93LC66CT-I/MNY
93AA66BT-I/MNY
93C56CT-E/MNY
93C56AT-E/MNY
93C56BT-E/MNY
93LC66CT-E/MNY
93LC66AT-E/MNY
93C56AT-I/MNY
93C66AT-E/MNY
93C46CT-I/MNY
93C46CT-E/MNY
93C56CT-I/MNY
93C66CT-E/MNY
93C66BT-E/MNY
93LC66BT-E/MNY
93C56BT-I/MNY
24LC256T-I/MNY
24AA256T-I/MNY
24FC256T-I/MNY
24LC256T-E/MNY
24AA256T-E/MNY
34AA04T-I/MNY

34AA04T-E/MNY
25LC010AT-I/MNY
25AA010AT-I/MNY
25LC010AT-E/MNY
25LC020AT-I/MNY
25AA020AT-I/MNY
25LC020AT-E/MNY
25LC040AT-I/MNY
25AA040AT-I/MNY
25LC040AT-E/MNY
PIC10F220T-I/MC
PIC10F220T-E/MC
MCP1725T-0802E/MC
MCP1725T-1202E/MC
PIC10F220-E/MC
PIC10F220-I/MC
MCP1725-3302E/MC
MCP1725-5002E/MC
MCP1725-ADJE/MC
MCP1725-2502E/MC
MCP1725-3002E/MC
MCP1725-0802E/MC
MCP1725-1202E/MC
MCP1725T-3302E/MC
MCP1725-1802E/MC
MCP1725T-2502E/MC
MCP1725T-3002E/MC
MCP1725T-5002E/MC
MCP1725T-ADJE/MC
PL903167UMG
PL903167UMG-TR
MIC22705YML-TR
MIC4607-2YML-T5
MIC4607-1YML-T5
MIC4607-1YML-TR
MIC4607-2YML-TR
SY55859LMG
MIC2215-PPMYML-TR
MIC2215-AAAYML-TR
MIC2213-AAAYML-TR
MIC4606-1YML
MIC68400YML-TR
MIC68400-1.2YML-TR
MIC68400-1.8YML-TR
MIC68401YML-TR
MIC2215-MMMYML-TR
MIC2215-PMMYML-TR
MIC2215-PPPYML-TR
NX9548ILQ-TR

SY89297UMG
SY58621LMG
SY89297UMH
MIC25400YML-TR
MICRF405YML-TR
MIC3263YML-TR
MIC24420YML-TR
MIC24421YML-TR
MIC2150YML-TR
MIC2151YML-TR
MIC5167YML-TR
MIC22601YML-TR
MIC22602YML-TR
MIC22700YML-TR
MIC22600YML-TR
SY89474UMG
PL602041UMG
SM802395UMG
PL903000
PL903101UMG
PL903150UMG
PL903151UMG
SM802356UMG
SM802357UMG
PL903160UMG
PL903161UMG
MCP6N11T-010E/MNY
MCP651T-E/MNY
MCP6N11T-100E/MNY
MCP6051T-E/MNY
MCP6061T-E/MNY
MCP6071T-E/MNY
MCP6442T-E/MNY
MCP661T-E/MNY
MCP621T-E/MNY
MIC22950YML-TR
SY89542UMG
SY89543LMG
SY89544UMG
SY89545LMG
SY89546UMG
SY89296UMG
SPN115002-TR
SM802386UMG
MIC23450-AAAYML-TR
MIC23450-AAAYML-T5
MIC2155YML-TR
MICRF505YML-TR
MICRF506YML-TR

SM802392UMG

SM802005

SY89200UMG

SY75578LMG

SM802362UMG

SY89202UMG

SM802363UMG

SM802364UMG

SY89838UMG

SM802368UMG

SY89295UMG

SY89837UMG

SY89846UMG

SY89847UMG

SY89547LMG

SY89853UMG

SY89855UMG

SY89856UMG

SY89858UMG

SY58034UMG

SY58035UMG

SY58036UMG

SY58626LMH

SY56028XRMG

SY56034ARMG

SY56572XRMG

SY58024UMG

SY58025UMG

SY58026UMG

SY58027UMG

SY58028UMG

SY58029UMG

SY58030UMG

SY58031UMG

SY58032UMG

SY58033UMG

SM802239UMG

SM802377UMG

SM802397UMG

SM802398UMG

SY89853UMG-TR

SY89855UMG-TR

SY89856UMG-TR

SY89858UMG-TR

SY89295UMG-TR

MCP9805-BE/MC

MCP1725T-1802E/MC

MCP9805T-BE/MC

MCP73832T-2DCI/MC

MCP73832T-3ACI/MC
MCP73832T-4ADI/MC
MCP1624-I/MC
MCP1624T-I/MC
MCP73832-2ACI/MC
MCP73832-2ATI/MC
MCP73832-2DCI/MC
MCP73832-3ACI/MC
MCP73832-4ADI/MC
MCP73832-5ACI/MC
MCP73832T-2ACI/MC
MCP73832T-2ATI/MC
MCP73832T-5ACI/MC
MCP1623T-I/MC
MCP1623-I/MC
MCP1640-I/MC
MCP1640T-I/MC
MCP1640B-I/MC
MCP1624T-I/MCAAA
MCP1624-I/MCAAA
MCP1640BT-I/MC
MCP1703A-1202E/MC
MCP1703A-1502E/MC
MCP1703A-2502E/MC
MCP1703A-1802E/MC
PIC10LF320-I/MC
PIC10LF320T-I/MC
MCP1703A-4002E/MC
MCP631T-E/MNY
24C00T-I/MNY
24LC00T-I/MNY
24AA00T-I/MNY
93C76CT-I/MNY
MCP1632T-AAE/MC
MCP1632T-BAE/MC
PIC12LF1501-E/MC
PIC12LF1501T-E/MC
PIC12LF1501-I/MC
PIC12LF1501T-I/MC
PIC12LF1501-I/MC020
MCP1642B-50I/MC
MCP1642D-50I/MC
MCP1642BT-50I/MC
MCP1642DT-50I/MC
MCP1642B-ADJI/MC
MCP1642D-ADJI/MC
MCP1642BT-ADJI/MC
MCP1642DT-ADJI/MC
MCP1642BT-33I/MC

MCP1642DT-33I/MC
MCP1642B-18I/MC
MCP1642D-18I/MC
MCP1642BT-18I/MC
MCP1642DT-18I/MC
MCP1642B-30I/MC
MCP1642D-30I/MC
MCP1642DT-30I/MC
MCP1642BT-30I/MC
MCP1642D-33I/MC
MCP1642B-33I/MC
24FC64-I/MC
MCP1755-3002E/MC
MCP1755S-3002E/MC
MCP1755T-3002E/MC
MCP1755ST-3002E/MC
MCP4011T-202E/MC
MCP4011T-502E/MC
MCP4011T-103E/MC
MCP4011T-503E/MC
MCP1703AT-5002E/MCAAB
PIC12LF1501T-I/MC021
PIC12LF1501T-I/MC020
MCP9804-E/MC
MCP9804T-E/MC
PIC12F519T-E/MC046
PIC10F322-E/MC
PIC10LF322-E/MC
PIC10LF322-I/MC
PIC10LF322T-I/MC
MCP9808T-E/MC
PIC12F510-E/MC
PIC12F510-I/MC
PIC12F510T-I/MC
PIC12F510T-E/MC
24LC16B-E/MC
24LC16BT-E/MC
25LC010AT-I/MC
25AA010AT-I/MC
25LC010AT-E/MC
25LC020AT-I/MC
25AA020AT-I/MC
25LC020AT-E/MC
PIC10F322T-I/MC033
MCP1631VT-E/ML
MCP73871T-1AAI/ML
MCP1631V-E/ML
MCP73871T-1CAI/ML
MCP73871T-1CCI/ML

MCP73871T-2AAI/ML
MCP73871T-2CAI/ML
MCP73871T-3CAI/ML
MCP73871-1AAI/ML
MCP4331-502E/ML
MCP4331-103E/ML
MCP73871T-4CCI/ML
MCP73871T-3CCI/ML
MCP73871T-4CAI/ML
MCP73871-2CAI/ML
MCP73871-4CCI/ML
AR1020T-I/ML
PL602082UMG
SM802001
SM802359UMG
SM802101UMG
SM802361UMG
SM802128UMG
SM802149UMG
SM802394UMG
SM802396UMG
93C46BT-E/MNY
93LC46AT-I/MNY
93AA46AT-I/MNY
MCP6H72T-E/MNY
93LC46AT-E/MNY
93LC86CT-E/MNY
93LC76CT-I/MNY
93AA76CT-I/MNY
93LC76CT-E/MNY
SM803352UMG
SM803122UMG
SM803003
SM803004
SM803005
SM803008
KSZ9021RNI
KSZ9021RN
SM803302UMG
SM803303UMG
SM803301UMG
SM803300UMG
SM803304UMG
SM803306UMG
SM803305UMG
SM813008UMG
SM803308UMG
SM803307UMG
SM803309UMG

SM813007UMG
SM803311UMG
SM803314UMG
SY58021UMG-TR
SY58022UMG-TR
SY54023ARMG-TR
SY56216RMG-TR
SY88422LMG-TR
SY58609UMG-TR
SY58610UMG-TR
SY88982LMG-TR
SYCUSTDIP2-TR
SY89833LMG-TX
PIC16F1708-E/ML035
PIC16F785T-I/ML047
PIC16F690T-I/ML050
PIC16LF721T-I/ML025
PIC16LF721T-I/ML028
PIC16LF721T-I/ML030
PIC16LF1828T-I/ML025
PIC16F1829T-I/ML031
PIC16F1509T-I/ML045
PIC16F1509T-E/ML
PIC16LF1459T-I/MLC01
PIC16LF1459T-I/MLC03
PIC16LF1459T-I/MLC05
PIC16F1708T-E/ML027
PIC16F1708T-E/ML030
PIC16F1708T-E/ML034
PIC16F1708T-E/ML035
PIC16F1708T-E/ML037
PIC16F1708T-E/ML038
PIC16F1709T-I/ML020
PIC16F1619T-I/ML
PIC16F1618T-I/ML
MCP2515T-I/ML
MCP2515T-E/ML
PIC16F685-I/ML
PIC16F685T-I/ML
PIC16F687-I/ML
PIC16F687T-I/ML
PIC16F689-I/ML
MCP3901A0T-I/ML
MCP3901A0T-E/ML
MCP3911A0T-E/ML
MCP3910A1T-E/ML
MCP3918A1T-E/ML
MCP4331T-502E/ML
MCP4331T-103E/ML

MCP4331T-104E/ML
MCP4331T-503E/ML
MCP4341T-502E/ML
MCP4341T-103E/ML
MCP4341T-104E/ML
MCP4341T-503E/ML
MCP4351T-502E/ML
MCP4351T-103E/ML
MCP4351T-104E/ML
MCP4351T-503E/ML
MCP4361T-502E/ML
MCP4361T-103E/ML
MCP4361T-104E/ML
MCP4361T-503E/ML
PIC16F689T-I/ML
PIC16F690-I/ML
PIC16F690T-I/ML
PIC16F1508-I/ML
PIC16F1509-I/ML
PIC16F1508T-I/ML
PIC16F1509T-I/ML
PIC16LF1559T-I/MLM10
PIC16LF1559-I/MLM10
MIC94069YML-TR
MIC5310-PPYML-TR
MIC5310-MGYML-TR
MIC5310-PGYML-TR
MIC23050-SYML-TR
MIC94067YML-TR
MIC47100-1.0YML-TR
MIC47100YML-TR
MIC47100-1.2YML-TR
MIC23050-GYML-TR
MIC2250YML-TR
MIC44F18YML-TR
MIC44F19YML-TR
MIC2605YML-TR
MIC2287-34YML-TR
MIC2289-15YML-TR
MIC2290YML-TR
SPN035007G-TR
MIC2292-34YML-TR
MIC2293-15YML-TR
MIC2295YML-TR
MIC5330-PMYML-TR
MIC5330-SGYML-TR
MIC5330-KGYML-TR
MIC5330-MGYML-TR
SY10EP51VMG-TR

SY58602UMG-TR
SY58603UMG-TR
SY58604UMG-TR
SY58605UMG-TR
SY89850UMG-TR
SY89206VMG-TR
SY89322VMG-TR
SY89325VMG-TR
MIC4782YML-TR
SYCUSTDIP1-TR
MIC2128YML-T5
MIC2128YML-TR
MIC2127AYML-TR
MIC2127AYML-T5
HV96001-E/NFA
SY89306VMG-TR
SY89222LMG-TR
SY89328LMG-TR
SY89321LMG-TR
SY54016ARMG-TR
SY58600UMG-TR
SY58601UMG-TR
SY89312VMG-TR
SY89311UMG-TR
SY89835UMG-TR
SY89327LMG-TR
SY89313VMG-TR
SY89307VMG-TR
SY89329VMG-TR
SY89323LMG-TR
SY89250VMG-TR
SY89251VMG-TR
SY54016RMG-TR
MIC23050-4YML-TR
SY100EP16UMG-TR
MIC94090YMT-TR
MIC94091YMT-TR
MIC94092YMT-TR
MIC94094YMT-TR
MIC94095YMT-TR
MIC94093YMT-TR
MIC94062YMT-TR
MIC94063YMT-TR
MIC94064YMT-TR
MIC94065YMT-TR
MIC94072YMT-TR
MIC5302-1.8YMT-TR
MIC5302-2.1YMT-TR
SM803315UMG

SM803313UMG
SM803297UMG
SM803298UMG
SM803069UMG
SM803070UMG
SM803026UMG
SM803060UMG
SM803071UMG
SM803208UMG
SM803211UMG
SM803220UMG
SM803286UMG
SM803184UMG
SM803295UMG
SM803284UMG
SM803285UMG
SM803287UMG
SM803280UMG
SM803186UMG
SM803196UMG
SM803282UMG
SM803283UMG
SM803291UMG
SM803292UMG
SM803296UMG
SM803144UMG
SM803153UMG
SM803163UMG
SM803281UMG
SM803149UMG
SM803175UMG
SM803278UMG
MCP1703AT-1202E/MC
MCP9804-E/MCBBB
MCP9804T-E/MCBBB
MCP1703A-3302E/MC
MCP1640C-I/MC
MCP1640DT-I/MC
MCP1640D-I/MC
MCP1640CT-I/MC
93LC86CT-I/MNY
93AA86CT-I/MNY
93C46AT-I/MNY
93LC46BT-I/MNY
93C46BT-I/MNY
MCP6H71T-E/MNY
93C86CT-E/MNY
93C76CT-E/MNY
93C86CT-I/MNY

93LC46BT-E/MNY
93C46AT-E/MNY
24C00T-E/MNY
MCP16251T-I/MNY
MCP16252T-I/MNY
MCP6482T-E/MNY
MCP6492T-E/MNY
MCP6472T-E/MNY
MCP1662T-E/MNY
MCP1661T-E/MNY
93C66CT-I/MNY
93C66AT-I/MNY
93C66BT-I/MNY
93LC46CT-E/MNY
93LC56CT-I/MNY
93AA56CT-I/MNY
93LC56AT-I/MNY
93AA56AT-I/MNY
93LC56BT-I/MNY
93AA56BT-I/MNY
24FC256T-E/MNY
93LC56CT-E/MNY
93LC56AT-E/MNY
93LC56BT-E/MNY
93AA66CT-I/MNY
93LC66AT-I/MNY
93AA66AT-I/MNY
93LC66BT-I/MNY
SM802158UMG
SM802173UMG
SM802230UMG
SY88149NDLMG
SY88303BLMG
SY88343BLMG
SY88349NDLMG
SY88353BLMG
SY88982LMG
SY88403BLMG
SY88773VMG
SY88083LMG
SY88953ALMG
SY88063CLMG
SY88073LMG
SY88053CLMG
SY89874AUMG-TR
SY84782UMG-TR
SY88349NDLMG-TR
SY89874UMG-TR
SY88149NDLMG-TR

SY89840UMG-TR
SY89876LMG-TR
SY89841UMG-TR
SY89875UMG-TR
SY89831UMG-TR
SY89833LMG-TR
SY89871UMG-TR
SY88149HALMG-TR
SY89872UMG-TR
SY89228UMG-TR
SY89832UMG-TR
SY89834UMG-TR
SY89873LMG-TR
SY88992LMG-TR
SY89833ALMG-TR
SY88932LMG-TR
SY89230UMG-TR
SY88063CLMG-TR
SY88073LMG-TR
SY88083LMG-TR
SY88953ALMG-TR
SY58051AUMG-TR
SY58052AUMG-TR
SY88053CLMG-TR
SY58011UMG-TR
SY58012UMG-TR
SY58013UMG-TR
SY58017UMG-TR
SY58018UMG-TR
SY58019UMG-TR
SY58606UMG-TR
SY58607UMG-TR
SY58608UMG-TR
SY89854UMG-TR
SY89851UMG-TR
SY89852UMG-TR
SY84113BUMG-TR
SY88303BLMG-TR
SY88353BLMG-TR
SY88403BLMG-TR
SY88773VMG-TR
SY56011RMG-TR
SY54017RMG-TR
SY89842UMG-TR
SY58611UMG-TR
SY54023RMG-TR
SY56020XRMG-TR
SY56023RMG-TR
SY58023UMG-TR

SY54011RMG-TR
SY75572LMG-TR
SY89231UMG-TR
SY54017ARMG-TR
SY56017RMG-TR
SY54020RMG-TR
SY54020ARMG-TR
SY56020RMG-TR
SY58020UMG-TR
PIC18F1330-ICD/ML
PIC18F23K20T-I/ML
PIC16F1786-I/ML
PIC16F1786-E/ML
PIC16LF1786T-I/ML
PIC24F16KM202-I/ML
PIC24F08KM202-I/ML
PIC16LF1786-I/ML
PIC24FV16KM202-E/ML
PIC16F1786T-I/ML
PIC24FV16KM202T-I/ML
PIC18F23K22T-E/ML
PIC18F2221-E/ML
PIC24FV16KM202-I/ML
PIC24FV08KM202-I/ML
PIC24FV16KM102-I/ML
PIC18F2321-E/ML
PIC16LF1788T-I/ML
PIC18LF26K22-I/ML
PIC18LF26K22T-I/ML
PIC24F16KM202-E/ML
PIC16LF1788-I/ML
PIC16LF1788-E/ML
PIC18LF27J53-I/ML
PIC18LF26J53-I/ML
PIC18LF26J11-I/ML
PIC18LF24J11-I/ML
PIC18LF24J11T-I/ML
PIC18LF26J50-I/ML
PIC18LF26K22T-E/ML
PIC18F24K22T-E/ML
PIC18LF27J13-I/ML
PIC18LF26J13-I/ML
PIC18F25J10T-I/ML020
PIC16F1933-E/ML
PIC18LF23K22T-I/ML021
PIC18LF26K22-E/ML
PIC18F26K22-I/ML
PIC18F44K22-I/ML
MIC94310-DYMT-T5

MIC94310-DYMT-TR
MIC94310-FYMT-T5
MIC94310-FYMT-TR
MIC94310-GYMT-T5
MIC94310-JYMT-T5
MIC94310-JYMT-TR
MIC94310-LYMT-T5
MIC94310-LYMT-TR
MIC94310-MYMT-T5
MIC94310-MYMT-TR
MIC94310-NYMT-T5
MIC94310-NYMT-TR
MIC94310-PYMT-T5
MIC94310-PYMT-TR
MIC94310-SYMT-T5
MIC94310-SYMT-TR
MIC5353-3.0YMT-TR
MIC5353-3.3YMT-TR
MIC5353YMT-TR
MIC5318YMT-TR
MIC5301-2.5YMT-TR
MIC5320-SGYMT-TR
MIC5320-SJYMT-TR
MIC5320-SMYMT-TR
MIC5320-SNYMT-TR
MIC5335-MGYMT-TR
MIC5308YMT-TR
MIC5335-SGYMT-TR
MIC2098-1YMT-TR
MIC5335-SSYMT-TR
MIC5318-3.3YMT-TR
MIC5308-1.2YMT-TR
MIC23030-AYMT-TR
MIC23031-4YMT-TR
MIC23031-AYMT-TR
MIC23031-CYMT-TR
MIC5367-3.3YMT-TR
MIC5370-MFYMT-TR
MIC5370-MGYMT-TR
MIC5370-PGYMT-TR
MIC5370-PKYMT-TR
MIC5370-PMYMT-TR
MIC5370-PPYMT-TR
MIC5370-SGYMT-TR
MIC5370-SKYMT-TR
MIC5370-SMYMT-TR
MIC5320-MFYMT-TR
MIC5370-SPYMT-TR
MIC5370-SSYMT-TR

MIC5301-3.3YMT-TR
MIC5321-JJYMT-TR
SPN035006G-TR
MIC5333-MMYMT-TR
MIC5333-MNYMT-TR
MIC5333-NNYMT-TR
MIC5333-PNYMT-TR
MCP6V27T-E/MD
MCP2025T-330E/MD
MCP2025T-500E/MD
MCP2025-500E/MD
MCP2021T-330E/MD
MCP2021-330E/MD
PIC12HV615-I/MD
MCP2025-330E/MD
MCP2021-500E/MD
MCP2021T-500E/MD
PIC12F635T-I/MD070
PIC12F675T-E/MD
PIC12F635T-I/MD073
MCP2021A-330E/MD
MCP2021AT-330E/MD
PIC12F629-I/MD
PIC12F629T-I/MD
MCP2021A-500E/MD
MCP2021AT-500E/MD
MIC5377YMT-TR
MIC5378YMT-TR
MIC2827-B2YMT-TR
MIC2827-E1YMT-TR
MIC2846A-MFYMT-TR
MIC2846A-PPYMT-TR
MIC2846A-SCYMT-TR
MIC2846A-MGYMT-TR
MIC2846A-PGYMT-TR
MIC2826-A0YMT-TR
MIC2826-D9YMT-TR
MIC23156-0YML-T5
MIC23156-0YML-TR
MIC23156-2YML-T5
MIC23156-2YML-TR
MIC2807-JJYML-TR
MIC2807-MMYML-TR
MIC2807-NNYML-TR
MIC2807-OOYML-TR
SY56016RMG-TR
PIC16HV785-I/ML
PIC16F1708-E/ML034
PIC16LF1718T-I/ML

- PIC16LF1718-E/ML
- PIC16F1782-I/ML
- PIC16F1782T-I/ML
- PIC16LF1718-I/ML
- PIC16F1713T-I/ML
- PIC16F1716T-I/ML
- PIC16F1783-E/ML
- PIC16F1783-I/ML
- PIC16F1783T-I/ML
- PIC16F1782-E/ML
- PIC18LF4620T-I/ML035
- PIC24FJ16GA004-I/ML
- PIC24FJ48GA004-I/ML
- PIC24FJ16GA004T-I/ML
- PIC24FJ48GA004T-I/ML
- PIC24FJ32GB004T-I/ML
- PIC24FJ64GA104-E/ML
- PIC24FJ32GA104-E/ML
- PIC24FJ32GA104-I/ML
- PIC24FV16KA304-I/ML
- PIC24FJ64GB004-I/ML
- PIC24FJ32GB004-I/ML
- PIC24FJ64GB004T-I/ML
- PIC24FJ64GA104-I/ML
- PIC24F32KA304-E/ML
- PIC24FV32KA304T-I/ML
- PIC24FV32KA304-E/ML
- PIC24FV32KA304-I/ML
- PIC16F1939-E/ML
- PIC16F1939-I/ML
- PIC16F1939T-I/ML
- PIC24F16KA304-I/ML
- PIC24F32KA304-I/ML
- MIC5283-3.3YML-T5
- MIC5283-3.3YML-TR
- MIC5283-5.0YML-T5
- MIC5283-5.0YML-TR
- MIC4129YML-TR
- MIC5356-MMYML-T5
- MIC5356-MMYML-TR
- MIC5356-MGYML-TR
- MIC5356-MGYML-T5
- MIC2208YML-TR
- MIC4720YML-TR
- MIC4723YML-TR
- MIC23303YML-T5
- PIC18F45K20-I/MLC05
- PIC18F45K80-E/ML
- PIC18F46K80-E/ML

PIC18F45K80-I/ML
PIC18F46K80-I/ML
PIC18F45K80T-I/ML
PIC18F46K80T-I/ML
PIC18F45K80T-E/ML
PIC18F46K80T-E/ML
PIC24FJ16GA004T-E/ML
PIC18LF43K22T-E/ML
PIC18LF43K22T-I/ML
PIC16F887-E/ML
PIC16F887-I/ML
PIC16F887T-I/ML
PIC16F1789T-I/ML
PIC24HJ32GP204-E/ML
SM802399UMG-TR
SM802402UMG-TR
MCP73871-1CCI/ML
MCP73871-2AAI/ML
MCP73871-3CAI/ML
MCP73871-3CCI/ML
MCP73871-4CAI/ML
MCP4331-104E/ML
AR1020-I/ML
MCP4331-503E/ML
AR1010-I/ML
MCP4361-104E/ML
MCP4361-503E/ML
PIC16LF1828-E/ML
PIC16LF1828-I/ML
PIC16LF1828T-I/ML
PIC16F685-E/ML
PIC16F687-E/ML
PIC16F687T-E/ML
PIC16F677-E/ML
MCP3901A0-E/ML
MCP73871-1CAI/ML
PIC16F690-E/ML
PIC16F689-E/ML
MCP4341-503E/ML
MCP2515-E/ML
MCP2515-I/ML
PIC16F721T-I/ML
MCP4341-104E/ML
MCP4341-502E/ML
MCP4341-103E/ML
PIC16LF720-I/ML
MCP4351-502E/ML
MCP4351-103E/ML
MCP4351-104E/ML

MCP4351-503E/ML
MCP4361-103E/ML
MCP4361-502E/ML
PIC16LF720-E/ML
PIC16LF720T-I/ML
MIC23303YML-TR
MIC22200YML-TR
MIC22205YML-TR
MIC2207YML-TR
MIC4833YML-TR
MIC4722YML-TR
MIC2230-AA YML-TR
MIC2238-AA YML-TR
MIC2230-G4YML-TR
MIC2238-G4YML-TR
MIC2230-GFHYML-TR
MIC2238-GFHYML-TR
MIC2230-GSYML-TR
MIC2238-GSYML-TR
MIC2230-J4YML-TR
MIC2238-J4YML-TR
MIC2230-S4YML-TR
MIC2238-S4YML-TR
MIC2230-SSYML-TR
MIC2238-SSYML-TR
MIC2267YML-TR
MIC2253-06YML-TR
MIC2298-15YML-TR
MIC2299-15YML-TR
MIC3230YML-TR
MIC3231YML-TR
MIC4123YML-TR
MIC4124YML-TR
MIC4125YML-TR
MIC2198YML
MIC2198YML-TR
SPN030022Y-TR
MIC2199YML
MIC2199YML-TR
MIC69303YML-TR
MIC23603YML-T5
MIC23603YML-TR
MIC68220YML-TR
MIC5528-2.8YMX-T5
MIC5528-2.8YMX-TR
MIC5528-3.3YMX-T5
MIC5393-SGYMX-T5
MIC5393-SGYMX-TR
MIC5393-SSYMX-T5

MIC5393-SSYMX-TR
MIC5528-3.3YMX-TR
MIC5393-FMYMX-T5
MIC5393-FMYMX-TR
MIC5393-GMYMX-T5
MIC5393-GMYMX-TR
MIC5393-MMYMX-T5
MIC5393-MMYMX-TR
MIC5393-PGYMX-T5
MIC5393-PGYMX-TR
MIC5393-PPYMX-T5
MIC5393-PPYMX-TR
MIC5528-1.1YMX-T5
MIC5528-1.1YMX-TR
MIC5528-1.2YMX-TR
MIC5528-1.8YMX-TR
PIC16LF721-E/ML
PIC16LF721-I/ML
PIC16F721-I/ML
PIC16LF721T-I/ML
PIC16LF1508-E/ML
PIC16LF1508-I/ML
PIC16LF1508T-I/ML
PIC16F785T-E/ML
PIC18F26K20T-I/ML046
PIC18F26K20T-I/ML047
PIC18F26K20T-I/ML048
PIC18F26K20-I/ML049
PIC18F26K20T-I/ML049
PIC18F26K20-I/ML050
PIC18F26K20T-I/ML050
PIC16LF1936T-I/ML020
PIC16LF1936-I/ML
PIC16LF1936T-I/ML
PIC18F26K20T-I/ML051
PIC18F26K20T-I/ML052
PIC18F26K20T-I/ML053
PIC18F26K20T-I/ML055
PIC16F723AT-E/ML
PIC16F886-I/ML
PIC16F886T-I/ML
PIC16F886T-I/MLC06
PIC18F26K20T-I/ML054
PIC18F26K22T-I/ML026
PIC18F26K22T-I/ML027
PIC18F26K22-I/MLC03
PIC18F26K22T-I/MLC03
PIC18LF26K22-I/MLC03
PIC18LF26K22T-I/MLC03

PIC18LF26K22-I/MLC04
PIC18LF26K22T-I/MLC04
PIC18F25K20T-I/MLC10
ENC28J60T-I/ML
PIC24F16KA102-E/ML
PIC24F16KA102T-I/ML
PIC16LF1938T-I/MLC01
PIC16F1938-I/MLRA2
PIC16F1938T-I/MLRA2
PIC16LF1938-I/MLC01
PIC24F16KA102-I/ML
ENC28J60-I/ML
PIC18F25K20-I/MLC10
PIC18F1320-E/ML
PIC18F1320-I/ML
PIC18F1320T-I/ML
PIC18F1220-E/ML
PIC18LF1220-I/ML
PIC18F1220-I/ML
PIC18F1220T-I/ML
PIC24F08KA102-I/ML
PIC18F26K20-I/ML056
PIC18F26K20T-I/ML056
PIC18F26K20-I/ML057
PIC18F26K20T-I/ML057
PIC24FJ64GA002-I/ML044
PIC24FJ16GA002T-E/ML
DSPIC33FJ12GP202-I/ML
DSPIC33FJ12MC202-I/ML
DSPIC33FJ12GP202T-I/ML
DSPIC33FJ12MC202T-I/ML
DSPIC33FJ12GP202T-E/ML
DSPIC33FJ12MC202T-E/ML
PIC16F1788-E/ML
PIC16F1788-I/ML
PIC24HJ12GP202-E/ML
DSPIC33FJ12GP202-E/ML
MIC5264-NNYML-TR
MIC5264-OFYML-TR
MIC5264-OGYML-TR
MIC5264-OKYML-TR
MIC5264-PGYML-TR
MIC5264-PJYML-TR
MIC5264-PMYML-TR
MIC5264-PPYML-TR
MIC5264-SFYML-TR
MIC5264-SMYML-TR
MIC5264-SPYML-TR
MIC5264-SSYML-TR

MIC5264-SGYML-TR
MIC5264-SJYML-TR
MICRF302YML-TR
MIC2297-15YML-TR
MIC2297-38YML-TR
MIC2297-42YML-TR
MIC5264-MFYML-TR
MIC2007YML-TR
MIC2008YML-TR
MIC2009YML-TR
MIC2013-0.5YML-TR
MIC2013-1.2YML-TR
MIC2017YML-TR
MIC2004-1.2YML-TR
MIC2004-0.5YML-TR
MIC47050YML-TR
MIC47050-1.2YML-TR
MIC5255-3.3YML-TR
MIC5247-1.8YML-TR
MIC5255-3.0YML-TR
MIC5319-5.0YML-TR
MIC5219-3.3YML-TR
MIC5259-3.3YML-TR
MIC23201YML-T5
MIC23201YML-TR
MIC2224YML-TR
MIC2214-JQYML-TR
MIC2210-FMYML-TR
MIC2210-GSYML-TR
MIC2210-MPYML-TR
MIC2210-MWYML-TR
MIC2210-PSYML-TR
MIC2211-OFYML-TR
MIC2211-OOYML-TR
MIC2211-PLYML-TR
MIC2211-PMYML-TR
MIC2211-PPYML-TR
MIC2214-KPYML-TR
MIC5190YML-TR
MIC2210-SSYML-TR
MIC2211-DLYML-TR
MIC2211-PSYML-TR
MIC2211-SGYML-TR
MIC2211-SMYML-TR
MIC2211-SSYML-TR
MIC2211-WMYML-TR
MIC2214-KKYML-TR
MIC2211-WOYML-TR
MIC2211-WSYML-TR

MIC2211-YMYML-TR
MIC2211-AAYML-TR
MIC2214-PNYML-TR
MIC2214-PWYML-TR
MIC61150YML-TR
MIC61150-10YML-TR
MIC2211-KGYML-TR
SPN025001G-TR
MIC2214-DIYML-TR
MIC61300-10YML-TR
MIC2211-KPYML-TR
MIC2211-MFYML-TR
MIC2214-DKYML-TR
MIC2214-DLYML-TR
MIC2214-DNYML-TR
MIC2214-DOYML-TR
MIC2214-FMYML-TR
MIC61300YML-TR
MIC2211-MJYML-TR
MIC2212-PNYML-TR
MIC2214-GKYML-TR
MIC2214-GLYML-TR
MIC2214-GMYML-TR
MIC2214-GOYML-TR
MIC2214-GPYML-TR
MIC2211-NSYML-TR
MIC2214-GSYML-TR
MIC2214-JGYML-TR
MIC2214-JMYML-TR
MIC2214-JPYML-TR
MIC2214-KMYML-TR
MIC2211-PNYML-TR
MIC2212-DNYML-TR
MIC2212-DOYML-TR
MIC2212-GKYML-TR
MIC2212-GLYML-TR
MIC2212-GMYML-TR
MIC2214-KNYML-TR
MIC2214-LMYML-TR
MIC2214-LPYML-TR
MIC2214-MMYML-TR
MIC2214-MPYML-TR
MIC2211-PWYML-TR
MIC2211-VVYML-TR
MIC2212-GPYML-TR
MIC2212-GSYML-TR
MIC2212-JSYML-TR
MIC2212-KMYML-TR
MIC2212-KNYML-TR

- MIC2214-NNYML-TR
- MIC2214-PMYML-TR
- MIC2214-PSYML-TR
- MIC2214-SGYML-TR
- MIC2214-SMYML-TR
- MIC2211-FGYML-TR
- MIC2212-LMYML-TR
- MIC2212-LOYML-TR
- MIC2212-LPYML-TR
- MIC2212-MKYML-TR
- MIC2212-MMYML-TR
- MIC2214-SWYML-TR
- MIC2214-WMYML-TR
- MIC2214-WSYML-TR
- MIC2211-FMYML-TR
- MIC2211-FNYML-TR
- MIC2211-FOYML-TR
- MIC2211-FQYML-TR
- MIC2211-GJYML-TR
- MIC2212-MPYML-TR
- MIC2212-NNYML-TR
- MIC2212-PMYML-TR
- MIC2212-PPYML-TR
- MIC2212-PSYML-TR
- MIC2202YML
- MIC2202YML-TR
- MIC2211-GKYML-TR
- MIC2211-GMYML-TR
- MIC2211-GOYML-TR
- MIC2211-GPYML-TR
- DSPIC33FJ16MC304-E/ML
- DSPIC33FJ32MC204-E/ML
- PIC24HJ16GP304-I/ML
- PIC24HJ32GP204-I/ML
- DSPIC33FJ16GP304-I/ML
- DSPIC33FJ32GP204-I/ML
- DSPIC33FJ16MC304-I/ML
- DSPIC33FJ32MC204-I/ML
- PIC24HJ16GP304T-I/ML
- PIC24HJ32GP204T-I/ML
- DSPIC33FJ16GP304T-I/ML
- DSPIC33FJ32GP204T-I/ML
- DSPIC33FJ16MC304T-I/ML
- DSPIC33FJ32MC204T-I/ML
- PIC24HJ16GP304T-E/ML
- PIC24HJ32GP204T-E/ML
- DSPIC33FJ16GP304T-E/ML
- DSPIC33FJ32GP204T-E/ML
- DSPIC33FJ16MC304T-E/ML

DSPIC33FJ32MC204T-E/ML
DSPIC30F3011-10I/MLB24
DSPIC33FJ32GP104-I/ML
PIC24FJ32MC104-I/ML
DSPIC30F2023T-30V/MLD31
DSPIC30F4013-30I/MLB31
DSPIC30F4013T-30I/MLB31
DSPIC30F2023-20E/ML
DSPIC30F2023-30I/ML
DSPIC30F2023T-30I/ML
PIC24FJ64GA004T-I/MLC13
PIC24FJ32GA004T-E/ML
PIC24FJ64GA104T-E/ML
DSPIC30F4011-20E/ML
DSPIC30F4012-20E/ML
DSPIC30F4011-20I/ML
DSPIC30F4011-30I/ML
DSPIC30F4012-20I/ML
DSPIC30F4012-30I/ML
DSPIC30F3012-20E/ML
DSPIC30F3013-20E/ML
DSPIC30F3012-20I/ML
DSPIC30F3012-30I/ML
DSPIC30F3013-20I/ML
DSPIC30F3013-30I/ML
DSPIC30F3012T-20I/ML
DSPIC30F3013T-20I/ML
DSPIC30F3013T-30I/ML
DSPIC30F3011-20E/ML
DSPIC30F3010-20I/ML
DSPIC30F3011-30I/ML
DSPIC30F3011-20I/ML
DSPIC30F3010-30I/ML
DSPIC30F3010T-30I/ML
PIC18F4410-E/ML
PIC18F4455T-I/ML
PIC18LF4550T-I/ML
PIC18F4550T-I/ML
PIC18LF2420T-I/ML
PIC16F72-I/ML
MCP23016T-I/ML
PIC16F72T-I/ML
PIC18LF2420-I/ML
PIC18LF2423-I/ML
PIC16LF876AT-I/ML
PIC18F2520-E/ML
PIC18F2423-I/ML
PIC18F2423T-I/ML
PIC18LF2520-I/ML

PIC18F2520-I/ML
PIC16LF819T-I/ML
PIC16LF818-I/ML
PIC16LF818T-I/ML
PIC18LF24J10-I/ML
PIC18F24J10-I/ML
PIC18F24J10T-I/ML
PIC18F25K20-E/ML
PIC18F24K20-E/ML
PIC16LF737-I/ML
PIC16F737-I/ML
PIC16LF76T-I/ML057
PIC18F2523-I/ML
PIC18F2523T-I/ML
PIC18F2423-E/ML
PIC16F886-E/ML
PIC16F886T-E/ML
PIC18F25J10-I/ML020
PIC16F913-E/ML
PIC16F883-I/ML
PIC18F25J10-I/ML
PIC18F25J10T-I/ML
PIC18LF2450T-I/ML206
PIC16F883T-E/ML
PIC18LF2520T-I/ML
PIC18F2520T-I/ML
PIC16F76T-I/ML
PIC16F76-I/ML
PIC16LF73T-I/ML
PIC16F73T-I/ML
PIC16F737T-I/ML
PIC18F2523-E/ML
PIC16F883T-I/ML
PIC16F819T-I/ML
PIC16F818-I/ML
PIC16F819-E/ML
PIC16F883-E/ML
PIC16F819-I/ML
PIC16LF726T-I/ML
PIC18LF2321-I/ML
PIC18F2321-I/ML
PIC16F1826-E/ML
PIC16F1826-I/ML
PIC16F1826T-I/ML
PIC18F2410-I/ML
PIC16LF722T-I/ML
PIC18F24J50-I/ML
PIC18F26J50T-I/ML
PIC18F25J50T-I/ML

PIC18F25J11-I/ML
PIC18F24J11-I/ML
PIC18F26J11T-I/ML
PIC18F25J11T-I/ML
PIC18F26J11-I/ML
PIC18F24J11T-I/ML
PIC16F726-I/ML
PIC16F726T-I/ML
PIC16LF722-I/ML
PIC16LF1827-I/ML
PIC16LF1827T-I/ML
PIC16LF726-I/ML
PIC16F1827-E/ML
SM803347UMG-TR
SM803349UMG
SM803349UMG-TR
SM803351UMG
SM803351UMG-TR
SM803350UMG
SM803350UMG-TR
SM803355UMG-TR
SM803355UMG
SM803356UMG-TR
SM803356UMG
SM803358UMG
SM803358UMG-TR
SM803357UMG-TR
SM803357UMG
SM803359UMG-TR
SM803359UMG
SM803361UMG-TR
SM803361UMG
KSZ9021GNI
KSZ9021GN-TR
KSZ9021GN
MIC21LV32YML-TR
MIC21LV33YML-TR
MIC2132YML-TR
MIC2133YML-TR
PIC18F4682-E/ML
PIC18LF4682-I/ML
PIC18F4685-E/ML
PIC18F4685T-I/ML
PIC18F4682-I/ML
PIC18LF4685-I/ML
PIC18F4331-I/ML
PIC18F4685-I/ML
PIC18LF4431-I/ML
PIC18F4431-I/ML

PIC18F4450-I/ML
PIC16F884-I/ML
PIC16F877A-E/ML
PIC16F884T-I/ML
PIC18F4580-I/ML
PIC18LF4420-I/ML
PIC18F452-E/ML
PIC18F44J10-I/ML
PIC16LF877A-I/ML
PIC18F4423-I/ML
PIC18LF4523-I/ML
PIC18F47J53T-I/ML
PIC18F45J10T-I/ML
PIC18F45J10-I/ML
PIC16F877A-I/ML
PIC18F4523-I/ML
PIC18LF45J10-I/ML
PIC18F4520-I/ML
PIC18F4520T-I/ML
PIC18F4520-E/ML
PIC18F4220-I/ML
PIC18LF452-I/ML
PIC18LF452T-I/ML
PIC18F452-I/ML
PIC18LF46K80-I/ML
PIC18F4520T-E/ML
PIC18LF4520-I/ML
PIC18LF4520T-I/ML
PIC18F4420-I/ML
PIC18LF45K80T-I/ML
PIC18F4420-E/ML
PIC16F917-E/ML
PIC24FJ48GA004T-I/ML022
DSPIC30F3014-20I/ML
DSPIC30F3014-30I/ML
DSPIC30F4013-20I/ML
DSPIC30F4013-30I/ML
DSPIC33FJ32MC204-V/MLC21
DSPIC33FJ32MC204T-V/MLC21
DSPIC30F3014-20E/ML
DSPIC30F4013-20E/ML
DSPIC30F4013T-30I/ML
PIC24FJ32GA104T-I/ML025
PIC18F46K22T-E/ML
PIC18LF4620T-I/ML
PIC18F4620T-I/ML
PIC18F4620-E/ML
PIC18F4620-I/ML
PIC18LF4620-I/ML

PIC18LF4515-I/ML
PIC18F4515-I/ML
PIC18F4525-I/ML
PIC18LF4525T-I/ML
PIC18F4610-I/ML
PIC18LF4525-I/ML
PIC16LF1939-I/ML
PIC16LF1939T-I/ML
PIC16F1784T-I/ML
PIC16F1787T-I/ML
PIC16F1787-I/ML
PIC18F4585-H/ML
PIC24FJ64GA004-I/MLC13
PIC16F1787T-E/ML021
PIC24FJ16GA004T-I/MLC09
PIC24FJ32GA104-I/ML026
PIC24FJ32GA104T-I/ML026
PIC18F45K20T-I/MLC05
PIC18F45K20-I/MLC01
MIC2211-GSYML-TR
MIC2212-SGYML-TR
MIC2212-SJYML-TR
MIC2212-SMYML-TR
MIC2212-WSYML-TR
MIC2219-PSYML-TR
MIC2203YML-TR
MIC2211-HPYML-TR
MIC2211-JGYML-TR
MIC2211-JMYML-TR
MIC2211-JPYML-TR
MIC2211-JSYML-TR
PIC16LF1709-E/ML
MCP3901A0-I/ML
PIC16LF1708T-I/ML
PIC16LF1708-I/ML
PIC16F1708T-I/ML
PIC16F1708-I/ML
PIC16F1708T-E/ML
PIC16F1708-E/ML
MCP1631-E/ML
MCP1631T-E/ML
PIC16F1709-E/ML
PIC16F1709-I/ML020
PIC16F1709-I/ML
PIC16F1709T-I/ML
PIC16F785T-I/ML036
PIC16LF1559-E/ML
PIC16LF1559-I/ML
PIC16LF1559T-I/ML

PIC16F1508T-I/MLOPP
MCP73871-2CC/ML
MCP73871T-2CC/ML
MCP73871-2CCI/ML
MCP73871T-2CCI/ML
PIC16HV785T-I/ML
PIC16HV785T-E/ML
PIC16HV785-E/ML
PIC16F1788T-I/ML
PIC16F1788T-E/ML
PIC24HJ12GP202-I/ML
PIC24F16KM202T-I/ML
DSPIC33FJ16GP102T-I/ML
DSPIC33FJ16MC102T-I/ML
PIC24FJ16MC102T-I/ML
DSPIC33FJ16GP102T-E/ML
DSPIC33FJ16MC102T-E/ML
PIC24FJ16MC102T-E/ML
DSPIC30F2012-20E/ML
DSPIC30F2011-20I/ML
DSPIC30F2011-30I/ML
DSPIC30F2012-20I/ML
DSPIC30F2012-30I/ML
DSPIC33FJ16GP102-E/ML
PIC24FJ16MC102-E/ML
DSPIC33FJ16GP102-I/ML
DSPIC33FJ16MC102-I/ML
PIC24FJ16MC102-I/ML
PIC24FJ32MC102T-I/ML
PIC24FJ32MC102-E/ML
DSPIC33FJ32MC102-I/ML
PIC24FJ32MC102-I/ML
PIC16F1716T-E/ML
PIC24FJ64GA002T-I/ML044
PIC18LF24K50-I/ML
PIC18LF25K50-I/ML
PIC18F25K50T-E/ML020
PIC18F25K50T-E/ML022
PIC16F883T-I/ML031
PIC24FJ16GA002T-I/ML023
PIC18F26K22T-I/ML030
PIC18F25K20T-I/ML044
PIC18F26K20T-I/ML058
PIC12F675-E/MD
PIC12F629-E/MD
PIC12F675-I/MD
PIC12F635-I/MD
PIC12F609-E/MD
PIC12F615T-I/MD

PIC12F609T-I/MD
PIC12F615-I/MD
PIC12F615-E/MD
PIC12F609-I/MD
MCP6V07T-E/MD
MCP6V07-E/MD
MCP6V02-E/MD
MCP6V02T-E/MD
PIC12F629T-E/MD
PIC12F683T-I/MD
PIC12F683-I/MD
MCP2021P-330E/MD
MCP2021P-500E/MD
MCP2021PT-500E/MD
PIC12F615T-I/MD029
MCP2021PT-330E/MD
PIC12F683-E/MD
MCP6V27-E/MD
MIC5302-2.85YMT-TR
MIC5302-3.3YMT-TR
MIC5303-1.8YMT-TR
MIC94061YMT-TR
MIC94300YMT-T5
MIC94300YMT-TR
MIC94310-GYMT-TR
MIC5303-3.3YMT-TR
MIC842HYMT-T5
MIC5337-1.8YMT-TR
MIC842HYMT-TR
MIC842LYMT-T5
MIC842LYMT-TR
MIC842NYMT-T5
MIC842NYMT-TR
MIC5303-2.8YMT-TR
MIC5528-3.0YMX-TR
PIC18F44K22T-I/ML
PIC18LF46K22T-I/ML
PIC18LF46K22-I/ML
PIC18F43K22T-I/ML
PIC18F43K22-I/ML
PIC18F46K22-E/ML
PIC18F46K22-I/ML
PIC18F46K22T-I/ML
PIC18LF46K22-E/ML
PIC18F45K22T-I/ML
PIC18F45K22-I/ML
PIC18F45K22-E/ML
PIC18LF4458-I/ML
PIC18F4458-I/ML

PIC18LF45K22T-I/ML
PIC18F4455-I/ML
PIC18LF4455-I/ML
PIC18F46K20-E/ML
PIC18F46K20-I/ML
PIC16LF1787-I/ML
PIC16LF1784-E/ML
PIC18F46K20T-I/ML
PIC18F46K20T-E/ML
PIC18LF45K22-I/ML
PIC18F4321-E/ML
PIC18LF4550-I/ML
PIC18F4550-I/ML
PIC16F1789-I/ML
PIC16F1787-E/ML
PIC24F16KM204-I/ML
PIC16LF1789T-I/ML
PIC24FV16KM204-I/ML
PIC16LF1789-E/ML
PIC18LF46J11T-I/ML
PIC18LF47J53-I/ML
PIC18LF46J53-I/ML
PIC18LF46J11-I/ML
PIC16LF1789-I/ML
PIC18LF46J50-I/ML
ENC424J600-I/ML
ENC424J600T-I/ML
PIC18LF47J13-I/ML
PIC18LF46J13-I/ML
PIC24FJ32GA004T-I/ML
PIC24FJ64GA004T-I/ML
PIC24FJ32GA004T-I/MLC12
PIC24FJ16GA004-E/ML
PIC24FJ64GA104T-I/ML
PIC24FJ32GA104T-I/ML
PIC24FJ32GA104T-E/ML
PIC24FJ32GA004-E/ML
PIC24FJ32GA004-I/ML
PIC24FJ64GA004-I/ML
PIC24FJ64GA004-E/ML
SM802220UMG
SM802227UMG
SM802265UMG
SM802272UMG
SM802255UMG
PIC10LF320-E/MC
PIC10F320T-I/MC
PIC10F320-I/MC
PIC10F320-E/MC

MCP1703A-3002E/MC
MCP1703AT-3002E/MC
MCP1703AT-3302E/MC
MCP1703A-2802E/MC
MCP1703AT-2502E/MC
MCP1703AT-4002E/MC
MCP1703AT-5002E/MC
PIC10F322T-I/MC
PIC10F322-I/MC
MCP1703AT-1802E/MC
MCP1703AT-1502E/MC
MCP1703AT-2802E/MC
24LC64T-I/MC
24AA64T-I/MC
24FC64T-I/MC
MCP1703AT-1852E/MC
24LC32AT-I/MC
24AA32AT-I/MC
PIC12F1501-E/MC
PIC12F1501-I/MC
PIC12F1501T-I/MC
PIC12F519T-I/MC034
MCP1755T-1802E/MC
MCP1755T-3302E/MC
24LC32AT-E/MC
MCP1755-5002E/MC
MCP1755S-5002E/MC
MCP1755T-5002E/MC
MCP1755ST-5002E/MC
PIC12F519-I/MC
PIC12F519T-I/MC
MCP1755-1802E/MC
MCP1755S-1802E/MC
MCP1755ST-1802E/MC
MCP1755-3302E/MC
MCP1755S-3302E/MC
MCP1755ST-3302E/MC
MCP1643-I/MC
MCP1643T-I/MC
24LC16BT-I/MC
24AA16T-I/MC
24LC16B-I/MC
24AA16-I/MC
MCP1632-AAE/MC
MCP1632-BAE/MC
SM803279UMG
SM803133UMG
SM803262UMG
SM803267UMG

SM803273UMG
SM803123UMG
SM803126UMG
SM803105UMG
SM803116UMG
SM803255UMG
SM803259UMG
SM803260UMG
SM803261UMG
SM803091UMG
SM803234UMG
SM803236UMG
SM803086UMG
SM803087UMG
SM803233UMG
SM803079UMG
SM803080UMG
SM803083UMG
SM803299UMG
SM803317UMG
SM803316UMG
SM803321UMG
SM803321UMG-TR
SM803318UMG
SM803318UMG-TR
SM803319UMG
SM803319UMG-TR
SM803320UMG
SM803320UMG-TR
SM803322UMG
SM803322UMG-TR
SM803323UMG
SM803323UMG-TR
SM803026UMG-TR
SM803060UMG-TR
SM803259UMG-TR
SM803083UMG-TR
SM803086UMG-TR
SM803087UMG-TR
SM802372UMG
SM802283UMG
SM802287UMG
SM802374UMG
SM802312UMG
SM802375UMG
SM802352UMG
SM802353UMG
PL607081UMG
SM802400UMG

SM802403UMG
SM802403UMG-TR
PL607081UMG-TR
PL602081UMG-TR
SM802101UMG-TR
SM802220UMG-TR
SM802128UMG-TR
SM802144UMG-TR
SM802158UMG-TR
SM803311UMG-TR
SM803313UMG-TR
SM803314UMG-TR
SM803315UMG-TR
SM803316UMG-TR
SM803317UMG-TR
SM803283UMG-TR
SM803284UMG-TR
SM803236UMG-TR
SM803220UMG-TR
SM803234UMG-TR
SM803273UMG-TR
SM803262UMG-TR
SM803278UMG-TR
SM803279UMG-TR
SM803280UMG-TR
SM803281UMG-TR
SM803282UMG-TR
SM803233UMG-TR
SM803260UMG-TR
SM803091UMG-TR
SM803261UMG-TR
SM803255UMG-TR
SM803122UMG-TR
SM803126UMG-TR
SM803267UMG-TR
SM802227UMG-TR
SM802400UMG-TR
SM802384UMG-TR
SM802385UMG-TR
SM802387UMG-TR
SM802388UMG-TR
SM802389UMG-TR
SM802394UMG-TR
SM802396UMG-TR
SM802230UMG-TR
SM802265UMG-TR
SM802287UMG-TR
SM802283UMG-TR
SM802312UMG-TR

SM802352UMG-TR
SM802353UMG-TR
SM802359UMG-TR
SM802272UMG-TR
SM802361UMG-TR
SM802372UMG-TR
SM802374UMG-TR
SM802375UMG-TR
SM802412UMG
SM802412UMG-TR
SM802411UMG
SM802411UMG-TR
SM802410UMG
SM802410UMG-TR
SM802414UMG
SM802414UMG-TR
SM802123UMG
SM802123UMG-TR
SM802418UMG-TR
SM802418UMG
SM802417UMG
SM802417UMG-TR
SM803352UMG-TR
SM803133UMG-TR
SM803144UMG-TR
SM803211UMG-TR
SM803285UMG-TR
SM803286UMG-TR
SM803287UMG-TR
SM803291UMG-TR
SM803292UMG-TR
SM803295UMG-TR
SM803296UMG-TR
SM803153UMG-TR
SM803297UMG-TR
SM803298UMG-TR
SM803299UMG-TR
SM803300UMG-TR
SM803301UMG-TR
SM803302UMG-TR
SM803303UMG-TR
SM803304UMG-TR
SM803305UMG-TR
SM803306UMG-TR
SM813007UMG-TR
SM803307UMG-TR
SM803308UMG-TR
SM813008UMG-TR
SM803309UMG-TR

SM803327UMG
PIC16F1782T-E/ML
PIC16F1713-I/ML
PIC16F1716-I/ML
PIC16LF723A-I/ML
PIC16LF723AT-I/ML
PIC24FJ32GA002T-I/MLC11
PIC24FJ64GA002-I/ML
PIC24FJ64GA002T-I/ML
PIC24FJ16GA002-E/ML
PIC24FJ16GA002-I/ML
PIC24FJ16GA002T-I/ML
PIC18F26K22T-E/ML
PIC18F26K22-E/ML
PIC24FJ32GA002-E/ML
PIC24FJ32GA002T-E/ML
PIC16LF1938-I/ML
PIC16LF1938T-I/ML
PIC16LF1938T-E/ML
PIC16F1938-E/ML
PIC16F1938-I/ML
PIC16F1938T-I/ML
PIC16LF1938-E/ML
PIC24FJ64GA002T-E/ML
PIC24FJ32GA002-I/ML
PIC24FJ32GA002T-I/ML
PIC24FJ64GA002-E/ML
PIC18F26K20-I/ML035
PIC18F26K20-I/ML
PIC18F26K20-I/MLC03
PIC18F26K20T-I/ML033
PIC18F26K20T-I/ML034
PIC18F26K20T-I/ML035
PIC24FJ16GA002T-I/MLC06
PIC24FJ48GA002-I/ML
PIC24FJ48GA002T-I/ML
PIC18F26K20T-I/ML040
PIC18F26K20T-I/ML043
PIC18F26K20T-I/ML
PIC18F25K20-I/ML
PIC18F25K20-I/MLC02
PIC18F25K20T-I/ML
PIC18F25K20T-I/MLC02
PIC16F1718-E/ML
PIC16F1718-I/ML
PIC16F1718T-I/ML
SM802419UMG-TR
SM802419UMG
SM802420UMG-TR

SM802420UMG
SM802393UMG
SM802390UMG
SM802003
SM802004
SM802134UMG
SM802366UMG
SM802371UMG
SM802181UMG
SM802369UMG
SM802370UMG
SM802191UMG
SM802215UMG
SM802194UMG
SM802214UMG
SM802231UMG
SM802285UMG
SM802373UMG
SM802314UMG
SM802319UMG
SM802376UMG
SM802320UMG
SM802380UMG
SM802354UMG
SM802399UMG
SM802402UMG
SM802194UMG-TR
SM802191UMG-TR
SM802320UMG-TR
SM802354UMG-TR
SM802366UMG-TR
SM802369UMG-TR
SM802370UMG-TR
SM802371UMG-TR
SM802231UMG-TR
SM802373UMG-TR
SM802181UMG-TR
SM802376UMG-TR
SM802380UMG-TR
SM802390UMG-TR
SM802393UMG-TR
DSPIC33FJ16MC102-E/ML
PIC18F25K22-E/ML
PIC16F819-I/MLTSL
PIC18F25K50-E/ML
PIC18F25K50T-E/ML
PIC18F24K50-I/ML
PIC18F25K50-I/ML
PIC18F25K50T-I/ML

PIC18F26K20-I/ML045
PIC18F26K20-I/ML048
PIC18F26K20T-I/ML045
PIC16F785T-I/ML
PIC16F785-I/ML
PIC16F785-E/ML
PIC16LF1507-I/ML
AR1021-I/ML
AR1011-I/ML
AR1011T-I/ML
AR1021T-I/ML
PIC16F720-I/ML
PIC16F1508-E/ML
PIC16LF1507-E/ML
PIC16F785T-I/ML045
PIC16LF1507T-I/ML
PIC18F13K22-E/ML
PIC18F13K22-I/ML
PIC18F13K22T-I/ML
PIC16F527-E/ML
PIC16F1459-I/ML
PIC16F1459T-I/ML
PIC16F1509-E/ML
PIC16F1508T-E/ML
PIC16F1828-E/ML
PIC16F1828-E/MLC02
PIC16F1828-I/ML
PIC16F1828T-I/ML
PIC16F1828T-E/ML
PIC16LF1459-E/ML
PIC16F1829-I/ML
PIC16F1829T-I/ML
PIC16F1829T-E/ML
PIC16F1829-E/ML
PIC16LF1459-I/ML
PIC18F13K22T-I/ML020
PIC16F1459T-I/ML020
PIC16F1459-E/ML
MCP3910A1-E/ML
MCP3918A1-E/ML
MCP3911A0-E/ML
PIC16F1507-E/ML
PIC16F1507-I/ML
PIC16F1507T-I/ML
PIC16F677-I/ML
PIC16LF1829-E/ML
PIC16LF1829-I/ML
PIC16LF1829T-I/ML
PIC16F677T-I/ML

- PIC16F1707-E/ML
- PIC16F527T-I/ML
- PIC16F527-I/ML
- PIC16F1707-I/ML
- PIC16F1829-I/ML031
- PIC16LF1509T-I/ML
- PIC16LF1509-E/ML
- PIC16LF1509-I/ML
- PIC16F1619-I/ML
- PIC16F1618-I/ML
- PIC16F1619-E/ML
- PIC16LF1618-E/ML
- PIC16F1618-E/ML
- PIC16LF1619-E/ML
- PIC16LF1619-I/ML
- PIC16LF1619T-I/ML
- PIC16LF1618T-I/ML
- PIC16LF1709-I/ML
- PIC16LF1709T-I/ML
- PIC16LF1618-I/ML
- MIC2213-GNYML-TR
- MIC2213-GSYML-TR
- MIC2213-JSYML-TR
- MIC2211-JYYML-TR
- MIC2211-KNYML-TR
- MIC2211-LGYML-TR
- MIC2211-LPYML-TR
- MIC2211-MGYML-TR
- MIC2211-MMYML-TR
- MIC2211-MPYML-TR
- MIC2211-MSYML-TR
- MIC2211-MWYML-TR
- MIC2211-NNYML-TR
- MIC69101-1.8YML-TR
- MIC69103YML-TR
- MIC69153YML-TR
- MIC79110YML-TR
- MIC79110-4.2YML-TR
- MIC2145YML
- MIC2145YML-TR
- MIC2204YML
- MIC2204YML-TR
- MIC2205-1.3YML-TR
- MIC2205-1.38YML-TR
- MIC2205-1.5YML-TR
- MIC2205-1.58YML-TR
- MIC2205-1.8YML-TR
- MIC2205-1.85YML-TR
- MIC2205YML-TR

MIC2206-1.2YML-TR
MIC2206-1.8YML-TR
MIC2206-83YML-TR
MIC2206-9IYML-TR
MIC2245YML-TR
MIC2285YML-TR
MIC3205YML-T5
MIC3205YML-TR
MIC5166YML-TR
MIC68200-1.0YML-TR
MIC68200-1.2YML-TR
MIC68200-1.5YML-TR
MIC68200-1.8YML-TR
MIC68200-2.5YML-TR
MIC68200-3.3YML-TR
MIC68200YML-TR
MIC4126YML-TR
MIC5060YML-TR
MIC4127YML-TR
MIC4128YML-TR
MIC5283YML-TR
MIC4120YML-TR
MIC37303YML-TR
MIC37303YML-T5
MIC5209YML-TR
MIC5209YML-T5
MIC4830YML-TR
MIC4832YML-TR
MIC5283YML-T5



QUALIFICATION PLAN SUMMARY

PCN #: BLAS-21SMFQ723

**Date:
October 12, 2023**

**Qualification of UNIG as a new assembly site for various products
available in Tube, Tray and Tape & Reel packing media.**

Purpose: Qualification of UNIG as a new assembly site for various products available in Tube, Tray and Tape & Reel packing media.

CCB No.: 6462

<u>Misc.</u>	Assembly site	UNIG
	BD Number	D-008111
	MP Code (MPC)	27807YHNAAA1
	Part Number (CPN)	MIC4605-1YMT-TR
	MSL information	MSL 1, 260°C
	Assembly Shipping Media (T/R, Tube/Tray)	T&R
	Base Quantity Multiple (BQM)	5000
	Reliability Site	UNIS
<u>Lead-Frame</u>	Paddle size	65x91mils
	Material	A194ESH
	DAP Surface Prep	Ag selective
	Treatment	No
	Process	Etch
	Lead-lock	Yes
	Part Number	40100183
	Lead Plating	Matte Sn
	Strip Size	70x250mm
	Strip Density	1444
<u>Bond Wire</u>	Material	Au
<u>Die Attach</u>	Part Number	8290
	Conductive	Yes
<u>MC</u>	Part Number	G770HCD
<u>PKG</u>	Package Type	UDFN
	Pin/Ball Count	10
	PKG width/size	2.5x2.5x0.6mm

Test Name	Conditions	Sample Size	Min. Qty of Spares per Lot (should be properly marked)	Qty of Lots	Total Units	Fail Accept Qty	Est. Dur. Days	ATE Test Site	REL Test Site	Special Instructions
Standard Pb-free Solderability	J-STD-002D ; Perform 8 hour steam aging for Matte tin finish prior to testing. Standard Pb-free: Matte tin/ NiPdAu finish, SAC solder, wetting temp 245°C for both SMD & through hole packages.	22	5	1	27	> 95% lead coverage	5			Standard Pb-free solderability is the requirement. SnPb solderability (backward solderability- SMD reflow soldering) is required for any plating related changes and highly recommended for other package BOM changes.
Wire Bond Pull - WBP	Mil. Std. 883-2011	5	0	1	5	0 fails after TC	5			30 bonds from a min. 5 devices.
Wire Bond Shear - WBS	CDF-AEC-Q100-001	5	0	1	5		5			30 bonds from a min. 5 devices.
Wire Sweep										Required for any reduction in wire bond thickness.
Physical Dimensions	Measure per JESD22 B100 and B108	10	0	3	30		5			
External Visual	Mil. Std. 883-2009/2010	All devices prior to submission for qualification testing	0	3	ALL	0	5			
HTSL (High Temp Storage Life)	150°C for 1008 hrs. Electrical test pre and post stress at +25C and hot temp +125°C.	45	5	1	50	0	10	UNIG	UNIS	Must be in progress at time of package release to production, but completion is not required for release to production. 3 lots are required for Cu wire qual.
Preconditioning - Required for surface mount devices	'+150°C Bake for 24 hours, moisture loading requirements per MSL level + 3X reflow at peak reflow temperature per Jedec-STD-020E for package type; Electrical test pre and post stress at +25°C. MSL 1, 260°C	231	15	3	738	0	15	UNIG	UNIS	Spares should be properly identified. 77 parts from each lot to be used for HAST, uHAST, Temp Cycle test.
UHAST	+130°C/85% RH for -192hrs Electrical test pre and post stress at +25°C	77	5	3	246	0	10	UNIG	UNIS	Spares should be properly identified. Use the parts which have gone through Pre-conditioning.
Temp Cycle	'-65°C to +150°C for 500 cycles. Electrical test pre and post stress at hot temp +125°C; 3 gram force WBP, on 5 devices from 1 lot, test following Temp Cycle stress.	77	5	3	246	0	15	UNIG	UNIS	Spares should be properly identified. Use the parts which have gone through Pre-conditioning.