

How to use your 50ml cartridge adaptor...




1 You will require a 320ml mastic gun into which the converter will fit



2 Slot the 50ml cartridge into the oval end of the translucent cylinder.



3 The cartridge is now ready to slot into the gun.



4 The blue plunger fits onto the gun's plunger. Squeeze the trigger, aligning the plungers with the back pistons on the cartridge.



5 Remove the cap from the cartridge and affix a static mixing nozzle. Purging the nozzle before use will ensure correct mix-ratio.

PermaBond
Engineering Adhesives

How to use your 50ml cartridge adaptor...




1 You will require a 320ml mastic gun into which the converter will fit



2 Slot the 50ml cartridge into the oval end of the translucent cylinder.



3 The cartridge is now ready to slot into the gun.



4 The blue plunger fits onto the gun's plunger. Squeeze the trigger, aligning the plungers with the back pistons on the cartridge.



5 Remove the cap from the cartridge and affix a static mixing nozzle. Purging the nozzle before use will ensure correct mix-ratio.

PermaBond
Engineering Adhesives