







## **Model Number**

## UB200-12GM-I-V1


Single head system

### **Features**

- Analog output 4 mA ... 20 mA
- · Very small unusable area
- Measuring window adjustable
- **Program input**
- **Temperature compensation**

## **Diagrams**

# Characteristic response curve



Curve 1: flat surface 100 mm x 100 mm Curve 2: round bar, Ø 25 mm

Technical data	
General specifications	
Sensing range	15 200 mm
Adjustment range	20 200 mm
Unusable area	0 15 mm
Standard target plate	100 mm x 100 mm
Transducer frequency	approx. 400 kHz
Response delay	approx. 30 ms
Indicators/operating means	
LED yellow	solid yellow: object in the evaluation range yellow, flashing: program function, object detected
LED red	solid red: Error red, flashing: program function, object not detected
Electrical specifications	
Operating voltage U <sub>B</sub>	10 30 V DC , ripple 10 % <sub>SS</sub>
No-load supply current I <sub>0</sub>	≤ 30 mA
Input	
Input type	1 program input lower evaluation limit A1: -U <sub>B</sub> +1 V, upper evaluation limit A2: +4 V +U <sub>B</sub> input impedance: > 4.7 k $\Omega$ , pulse duration: $\geq$ 1 s
Output	
Output type	1 analog output 4 20 mA
Resolution	0.17 mm
Deviation of the characteristic curve	± 1 % of full-scale value
Repeat accuracy	± 0.5 % of full-scale value
Load impedance	0 200 Ω
Temperature influence	± 1.5 % of full-scale value
Ambient conditions	
Ambient temperature	-25 70 °C (-13 158 °F)
Storago tomporaturo	40 95 °C ( 40 195 °E)

Storage temperature -40 ... 85 °C (-40 ... 185 °F)

**Mechanical specifications** 

Connection type Device connector M12 x 1, 4-pin

Protection degree Material

Housing brass, nickel-plated

epoxy resin/hollow glass sphere mixture; foam polyurethane, cover PBT Transducer

Mass Compliance with standards and

Standard conformity


Standards EN 60947-5-2:2007 IEC 60947-5-2:2007 EN 60947-5-7:2003

EN 60947-5-7:2003

Approvals and certificates


UL approval cULus Listed, General Purpose CSA approval cCSAus Listed, General Purpose

## **Dimensions**




# **Additional Information**

# Programmed analogue output function



## **Electrical Connection**

Standard symbol/Connections: (version I)



Core colours in accordance with EN 60947-5-2.

## **Pinout**



Wire colors in accordance with EN 60947-5-2

1	BN	(brown
2	WH	(white)
3	BU	(blue)
4	BK	(black)

### **Accessories**

### **UB-PROG2**

Programming unit

#### BF 5-30

Universal mounting bracket for cylindrical sensors with a diameter of 5 ... 30 mm

#### BF 12

Mounting flange, 12 mm

#### **BF 12-F**

Mounting flange with dead stop, 12 mm

### V1-G-2M-PVC

Cable socket, M12, 4-pin, PVC cable

### V1-W-2M-PUR

Cable socket, M12, 4-pin, PUR cable

### UVW90-M12

Ultrasonic -deflector

### Adjusting the evaluation limits

The ultrasonic sensor features an analogue output with two teachable evaluation limits. These are set by applying the supply voltage  $-U_B$  or  $+U_B$  to the TEACH-IN input. The supply voltage must be applied to the TEACH-IN input for at least 1 s. LEDs indicate whether the sensor has recognised the target during the TEACH-IN procedure. The lower evaluation limit A1 is taught with  $-U_B$ , A2 with  $+U_B$ .

Two different output functions can be set:

- 1. Analogue value increases with rising distance to object (rising ramp)
- 2. Analogue value falls with rising distance to object (falling ramp)

# TEACH-IN rising ramp (A2 > A1)

- Position object at lower evaluation limit
- TEACH-IN lower limit A1 with U<sub>B</sub>
- Position object at upper evaluation limit
- TEACH-IN upper limit A2 with + UB

## TEACH-IN falling ramp (A1 > A2):

- Position object at lower evaluation limit
- TEACH-IN lower limit A2 with + U<sub>B</sub>
- Position object at upper evaluation limit
- TEACH-IN upper limit A1 with UR

## **Default setting**

A1: unusable area

A2: nominal sensing range

Mode of operation: rising ramp

## **LED Displays**

Displays in dependence on operating mode	Red LED	Yellow LED
TEACH-IN evaluation limit		
Object detected	off	flashes
No object detected	flashes	off
Object uncertain (TEACH-IN invalid)	on	off
Normal mode (evaluation range)	off	on
Fault	on	previous state

## Installation conditions

If the sensor is installed at places, where the environment temperature can fall below 0 °C, for the sensors fixation, one of the mounting flanges BF 12, BF 12-F or BF 5-30 must be used. In case of direct mounting of the sensor in a through hole, it has to be fixed at the middle of the housing thread.