10mm SOLID STATE LAMP

Part Number: L-813QBC-G Blue



ATTENTION OBSERVE PRECAUTIONS FOR HANDLING ELECTROSTATIC DISCHARGE SENSITIVE DEVICES

Features

- 10mm diameter big lamp.
- Reliable and rugged.
- Long life solid state reliability.
- RoHS compliant.

Description


The Blue source color devices are made with InGaN Light Emitting Diode.

Static electricity and surge damage the LEDS.

It is recommended to use a wrist band or anti-electrostatic glove when handling the LEDs.

All devices, equipment and machinery must be electrically grounded.

Package Dimensions



REV NO: V.2 CHECKED: Allen Liu DATE: OCT/05/2010 DRAWN: Y.F.Lv PAGE: 1 OF 6 ERP: 1101023858

Selection Guide

| Part No. | Dice | Dice Lens Type Iv (mcd) [2] @ 20mA | | / - - | Viewing Angle [1] | |
|------------|--------------|---------------------------------------|------|--------------|----------------------|--|
| | | | Min. | Тур. | 201/2 | |
| L-813QBC-G | Blue (InGaN) | Water Clear | 2800 | 4000 | 10° | |

Notes:

1. θ 1/2 is the angle from optical centerline where the luminous intensity is 1/2 of the optical peak value.

2. Luminous intensity/ luminous Flux: +/-15%.

Electrical / Optical Characteristics at TA=25°C

| Symbol | Parameter | Device | Тур. | Max. | Units | Test Conditions |
|--------|--------------------------|--------|------|------|-------|-----------------|
| λpeak | Peak Wavelength | Blue | 461 | | nm | IF=20mA |
| λD [1] | Dominant Wavelength | Blue | 465 | | nm | IF=20mA |
| Δλ1/2 | Spectral Line Half-width | Blue | 25 | | nm | IF=20mA |
| С | Capacitance | Blue | 100 | | pF | VF=0V;f=1MHz |
| VF [2] | Forward Voltage | Blue | 3.3 | 4 | V | I⊧=20mA |
| lr | Reverse Current | Blue | | 50 | uA | VR = 5V |

Notes:


1.Wavelength: +/-1nm. 2. Forward Voltage: +/-0.1V.


Absolute Maximum Ratings at TA=25°C

| Parameter | Blue | Units | |
|-------------------------------|---------------------|-------|--|
| Power dissipation | 120 | mW | |
| DC Forward Current | 30 | mA | |
| Peak Forward Current [1] | 150 | mA | |
| Reverse Voltage | 5 | V | |
| Operating/Storage Temperature | -40°C To +85°C | | |
| Lead Solder Temperature [2] | 260°C For 3 Seconds | | |
| Lead Solder Temperature [3] | 260°C For 5 Seconds | | |

Notes:

1.1/10 Duty Cycle, 0.1ms Pulse Width.
2.2mm below package base.
3.5mm below package base.





LED MOUNTING METHOD


 The lead pitch of the LED must match the pitch of the mounting holes on the PCB during component placement. Lead-forming may be required to insure the lead pitch matches the hole pitch. Refer to the figure below for proper lead forming procedures.
(Fig. 1)

LED LED LED LED LED PCB V PCB PCB PCB Note.1 Note.2 РСВ *ÈIIIII* 777 7777777 // Ľ TIM T $\overline{\mathcal{D}}$ Anode 45°MAX. Cathode 45'MAX. LED LED LED LED LED PCB PCB PCB PCB РСВ ()//) XIII */////* Cathode Anode >45 >45' Х Х \sim Х \times LED LED Housing Housing <u>LED</u> Housing LED Housing Housing LED (PCB PCB PCB Note.2 Note.1 PCB PCB Ŕ 1 È Cathode 45°MAX. Anode 45°MAX. Ο Ο \bigcirc (LED Housing LEQ Housing LED Housing LED Housing Housing PCB PCB PCB PCB PCB Cathode >45* Anode tinn Х Х Х Х Х Fig.1

"○" Correct mounting method "×" Incorrect mounting method Note 1-2 : Do not route PCB trace in the contact area between the leadframe and the PCB to prevent short-circuits.


2. When soldering wire to the LED, use individual heat—shrink tubing to insulate the exposed leads to prevent accidental contact short—circuit. (Fig. 2)

3. Use stand-offs (Fig. 3) or spacers (Fig. 4) to securely position the LED above the PCB.




LEAD FORMING PROCEDURES

1. Maintain a minimum of 2mm clearance between the base of the LED lens and the first lead bend. (Fig. 5 and 6)



- 2. Lead forming or bending must be performed before soldering, never during or after Soldering.
- 3. Do not stress the LED lens during lead-forming in order to fractures in the lens epoxy and damage the internal structures.
- 4. During lead forming, use tools or jigs to hold the leads securely so that the bending force will not be transmitted to the LED lens and its internal structures. Do not perform lead forming once the component has been mounted onto the PCB. (Fig. 7)
- 5. Do not bend the leads more than twice. (Fig. 8)
- 6. After soldering or other high-temperature assembly, allow the LED to cool down to 50°C before applying outside force (Fig. 9). In general, avoid placing excess force on the LED to avoid damage. For any questions please consult with Kingbright representative for proper handling procedures.



 \bigcirc

Х