## **QC6CB Series**


3.5x6.0 2-Pad SMD All Ceramic Crystal Unit

## **Features**

- All ceramic epoxy sealed SMD package
- Low in height, suitable for thin equipment
- Tight tolerance and stability available

## **Applications**

- High density applications
- · Modem, communication and test equipment








General Specifications	
Frequency Range	8.000 to 40.000MHz (Fundamental)
Frenquency Tolerance at 25°C	±20 to ±50ppm (±30ppm standard)
Frequency Stability over Temperature Range	See Stability vs. Temperature Table
Storage Temperature	-55 to +125°C
Aging per Year	±5ppm max.
Load Capacitance C <sub>L</sub>	10 to 32pF and Series Resonance
Shunt Capacitance C <sub>0</sub>	7.0pF max.
Equivalent Series Resistance (ESR)	See ESR Table
Drive Level	100μW typ. (500μW max)
Insulation Resistance (M $\Omega$ )	500 at 100Vdc ±15Vdc

Equivalent Series Resistance (ESR)				
Frequency Range - MHz	$\Omega$ max.	Mode of Operation		
8.000 to 10.000	100	Fundamental		
10.000 to 12.000	80	Fundamental		
12.000 to 16.000	60	Fundamental		
16.000 to 40.000	30	Fundamental		


Frequency Stability vs. Temperature					
Operating Temperature	±20ppm	±30ppm	±50ppm		
-20 to +70°C	0	0	0		
-40 to +85°C	0	•	0		
			● standard ○ available		



Part Nu	Part Numbering Guide							
Qantek Code	Package	Nominal Frequency (in MHz)	Vibration Mode	Load Capacitance	Operating Temperature Range	Frequency Tolerance	Frequency Stability	Packaging
Q = Qantek	C6CB = 3.5x6.0 2-Pad SMD	7 digits including the decimal point (f.ie. 12.0000)	F = AT-Fund	S = Series 12 = 12pF 18 = 18pF 20 = 20pF etc.	A = -20 to +70°C B = -40 to +85°C	2 = ±20ppm <b>3 = ±30ppm</b> 5 = ±50ppm	2 = ±20ppm <b>3 = ±30ppm</b> 5 = ±50ppm	M = 250pcs Tape&Reel R = 1000pcs Tape&Reel
Example: QC6CB12.0000F12B33R bold letters = recommended standard specification								



Phone: +1 877-227-0440 (tollfree) www.gantek.com +1 877-227-0440 (tollfree) info@qantek.com



## **Marking Code Guide**


Contains frequency, Qantek manufacturing code, production code (month and year) and load capacitance.

Month Codes				
January	Α	July	G	
February	В	August	Н	
March	С	September	1	
April	D	October	J	
May	Е	November	K	
June	F	December	L	

Year Codes					
2010	0	2011	1	2012	2
2013	3	2014	4	2015	5

Load Capacitance Code in pF					
pF	PN Code	pF	PN Code		
12	Α	20	F		
18	В	22	G		
8	С	30	Н		
10	D	32	I		
16	E	S	S		

Example: First Line: 12.000 (Frequency) Second Line: QA1A (Qantek - January - 2011 - 12 pF)



Environmental Specifications			
Mechanical Shock	MIL-STD-202, Method 213, C		
Vibration	MIL-STD-202, Method 201 & 204		
Thermal Cycle	MIL-STD, Method 1010, B		
Gross Leak	MIL-STD-202, Method 112		
Fine Leak	MIL-STD-202, Method 112		

All specifications are subject to change without notice.



Phone: +1 877-227-0440 (tollfree) w Fax: +1 877-227-0440 (tollfree) ir