

## **Model Number**

NCB10-30GM40-N0

### **Features**

- 10 mm flush
- Usable up to SIL 2 acc. to IEC 61508
- Stainless steel housing

	Technical Data		
1	General specifications		
	Switching element function		NAMUR, NC
	Rated operating distance	s <sub>n</sub>	10 mm
	Installation	-11	flush
	Output polarity		NAMUR
	Assured operating distance	Sa	0 8.1 mm
	Actual operating distance	Sr	9 11 mm typ.
	Reduction factor rAI		0.35
	Reduction factor r <sub>Cu</sub>		0.3
	Reduction factor r <sub>304</sub>		0.75
	Nominal ratings		
	Nominal voltage	U <sub>o</sub>	8 V
	Switching frequency	f	0 200 Hz
	Hysteresis	Н	1 15 typ. 5 %
	Reverse polarity protection		reverse polarity
	Short-circuit protection		yes
	Current consumption		
	Measuring plate not detected		≥ 2.2 mA
	Measuring plate detected		≤1 mA
	Switching state indicator		all direction LED
	Functional safety related parameter	eters	
	MTTF <sub>d</sub>		1870 a
	Mission Time (T <sub>M</sub> )		20 a
	Diagnostic Coverage (DC)		0 %
	Ambient conditions		
	Ambient temperature		-25 100 °C (-
	Storage temperature		-40 100 °C (-4
	Mechanical specifications		
	Connection type		cable PVC , 2 m
	Core cross-section		0.75 mm <sup>2</sup>
	Housing material		Stainless steel 1
	Sensing face		PBT
	Degree of protection		IP67
	Cable		
	Bending radius		> 10 x cable dia
	General information		
	Use in the hazardous area		see instruction r
	Category		1G; 2G; 3G; 1D
	Compliance with standards and	directive	S
	Standard conformity		
	NAMUR		EN 60947-5-6:2
			IEC 60947-5-6:
	Electromagnetic compatibility		NE 21:2007
	Standards		EN 60947-5-2:2
	Stariuarus		IEC 60947-5-2.2


# NCB10-30GM40-N0

	0	0 0
	f	0 200 Hz
	Н	1 15 typ. 5 %
ı		reverse polarity protected
		yes
ected		≥ 2.2 mA
d		≤ 1 mA
		all direction LED, yellow
paramete	rs	
		1870 a
		20 a
		0 %
		-25 100 °C (-13 212 °F)
		-40 100 °C (-40 212 °F)
		cable PVC , 2 m
		0.75 mm <sup>2</sup>
		Stainless steel 1.4305 / AISI 303
		PBT
		IP67
		> 10 x cable diameter
		see instruction manuals
		1G; 2G; 3G; 1D; 3D
s and dir	rectives	
		EN 60947-5-6:2000 IEC 60947-5-6:1999
: <b> </b> ;   ; <b></b>		NE 21:2007
ibility		
		EN 60947-5-2:2007 IEC 60947-5-2:2007
;		
		116-0165
		cULus Listed, General Purpose

### Approvals and certificates F

FM approval	
Control drawing	116-0165
UL approval	cULus Listed, General Purpose
CSA approval	cCSAus Listed, General Purpose
CCC approval	CCC approval / marking not required for products rated $\leq$ 36 V

# Dimensions



Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Pepperl+Fuchs Group www.pepperl-fuchs.com


USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com



NCB10-30GM40-N0

# **Electrical Connection**



Refer to "General Notes Relating to Pepperl+Fuchs Product Information".

Pepperl+Fuchs Group USA: +1 www.pepperl-fuchs.com fa-info@us.p

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



2

Equipment protection level Ga Instruction	Manual electrical apparatus for hazardous areas
Device category 1G EC-Type Examination Certificate CE marking	for use in hazardous areas with gas, vapour and mist PTB 00 ATEX 2048 X € 0102
ATEX marking	(x) II 1G Ex ia IIC T6T1 Ga The Ex-related marking can also be printed on the enclosed label.
Directive conformity Standards	94/9/EG EN 60079-0:2012+A11:2013 EN 60079-11:2012 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions
Appropriate type	NCB10-30GMN0
Effective internal inductivity C <sub>i</sub>	$\leq$ 105 nF; a cable length of 10 m is considered.
Effective internal inductance Li	$\leq$ 100 $\mu$ H ; a cable length of 10 m is considered.
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to! Directive $94/9/EG$ and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions. The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces by the mentioned certification authority. If the equipment is not used under atmospheric conditions, a reduction of the permis-
Ambient temperature	sible minimum ignition energies may have to be taken into consideration. Details of the correlation between the type of circuit connected, the maximum per- missible ambient temperature, the temperature class, and the effective internal reac- tance values can be found on the EC-type examination certificate. <u>Note</u> : Use the temperature table for category 1 !!! The 20 % reduction in accordance with EN 1127- 1 has already been applied to the temperature table for category 1.
Installation, commissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related appara- tus and according to the proof of intrinsic safety. The associated apparatus must satisfy the requirements of category ia. Due to the possible danger of ignition, which can arise due to faults and/or transient currents in the equipotential bonding system, galvanic isolation of the power supply and signal circuit is preferable. Associated apparatus without electrical isolation must only be used if the appropriate requirements of IEC 60079-14 are met. If the Ex- related marking is printed only on the supplied label, then this must be attached in the immediate vicinity of the sensor. The sticking surface for the label must be clean and free from grease. The attached label must be legible and indelible, including in the event of possible chemical corrosion.
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.
Special conditions	The connecting parts of the sensor must be set up in such a way that degree of pro- tection IP20, in accordance with IEC 60529, is achieved as a minimum.
Protection from mechanical danger	When using the device in a temperature range of -60 $^{\circ}$ C to -20 $^{\circ}$ C, protect the sensor against the effects of impact by installing an additional enclosure. The information regarding the minimum ambient temperature for the sensor as provided in the datasheet must also be observed.
Electrostatic charge	Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding. When used in group IIC non-permissible electrostatic charges should be avoided on the plastic housing parts. Additional requirements for gas group IIC. Information on electrostatic hazards can be found in the technical specification IEC/TS 60079-32-1. Avoid electrostatic charges that can cause electrostatic discharge when installing or operating the device.

Refer to "General Notes Relating to Pepperl+Fuchs Product Information".

Pepperl+Fuchs Group www.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com



Equipment protection level Gb			
Instruction	Manual electrical apparatus for hazardous areas		
Device category 2G	for use in hazardous areas with gas, vapour and mist		
EC-Type Examination Certificate	PTB 00 ATEX 2048 X		
CE marking	<b>CE</b> 0102		
ATEX marking	$\langle\!$		
Directive conformity	94/9/EG		
Standards	EN 60079-0:2012+A11:2013 EN 60079-11:2012 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions		
Appropriate type	NCB10-30GMN0		
Effective internal inductivity C <sub>i</sub>	$\leq$ 105 nF ; a cable length of 10 m is considered.		
Effective internal inductance L <sub>i</sub>	$\leq$ 100 $\mu H$ ; a cable length of 10 m is considered.		
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to! Directive 94/9/EG and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions. The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces by the mentioned certification authority. If the equipment is not used under atmospheric conditions, a reduction of the permis- sible minimum ignition energies may have to be taken into consideration.		
Maximum permissible ambient temperature T <sub>amb</sub>	Details of the correlation between the type of circuit connected, the maximum per- missible ambient temperature, the temperature class, and the effective internal reac- tance values can be found on the EC-type examination certificate.		
Installation, commissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appro- priate related apparatus and according to the proof of intrinsic safety. If the Ex-related marking is printed only on the supplied label, then this must be attached in the immediate vicinity of the sensor. The sticking surface for the label must be clean and free from grease. The attached label must be legible and indeli- ble, including in the event of possible chemical corrosion.		
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.		
Special conditions	The connecting parts of the sensor must be set up in such a way that degree of pro- tection IP20, in accordance with IEC 60529, is achieved as a minimum.		
Protection from mechanical danger	When using the device in a temperature range of -60 °C to -20 °C, protect the sensor against the effects of impact by installing an additional enclosure. The information regarding the minimum ambient temperature for the sensor as provided in the datasheet must also be observed.		
Electrostatic charge	Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.		

4



#### Equipment protection level Gc (nL) Note

#### Instruction

Device category 3G (nL) CE marking

ATEX marking Directive conformity Standard conformity

Effective internal capacitance  $C_i$ Effective internal inductance  $L_i$ 

General

Installation, commissioning

#### Maintenance

### Special conditions

for Pi=34 mW, li=25 mA, T6 for Pi=34 mW, li=25 mA, T5 for Pi=34 mW, li=25 mA, T4-T1 for Pi=64 mW, li=25 mA, T6 for Pi=64 mW, li=25 mA, T5 for Pi=64 mW, li=25 mA, T4-T1 for Pi=169 mW, li=52 mA, T6 for Pi=169 mW, li=52 mA, T5 for Pi=169 mW, li=52 mA, T4-T1 for Pi=242 mW, li=76 mA, T6 for Pi=242 mW, li=76 mA, T5 for Pi=242 mW, li=76 mA, T4-T1

Protection from mechanical danger

Protection from UV light

Protection of the connection cable

Electrostatic charge

Connection parts

This instruction is only valid for products according to EN 60079-15:2005, valid until 01-May-2013  $\,$ 

#### Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist  $\pmb{\mathsf{CE}}$ 

 ♦ II 3G Ex nL IIC T6 X
94/9/EG
EN 60079-15:2005 Ignition protection category "n" Use is restricted to the following stated conditions
≤ 105 nF ; a cable length of 10 m is considered.

 $\leq$  100 µH ; A cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction! The special conditions must be observed!

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The sensor must only be operated with an energy-limited circuit, which satisfies the requirements of IEC 60079-15. The explosion group complies with the connected, supplying, power limiting circuit.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

55	°C (131 °F)
55	°C (131 °F)
52	°C (125.6 °F)
52	°C (125.6 °F)
52	°C (125.6 °F)
44	°C (111.2 °F)
44	°C (111.2 °F)
44	°C (111.2 °F)

The sensor must not be exposed to **ANY FORM** of mechanical danger. When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.

The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is used in internal areas.

The connection cable must be prevented from being subjected to tension and torsional loading.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

The connection parts are to be installed, such that a minimum protection class of IP20 is achieved, in accordance with IEC 60529.

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com



inductive sensor	NCD10-30GM40-N
Equipment protection level Gc (ic)	
Instruction	Manual electrical apparatus for hazardous areas
Device category 3G (ic)	for use in hazardous areas with gas, vapour and mist
Certificate of Compliance	PF 13 CERT 2895 X
CE marking	CE
ATEX marking	(x) II 3G Ex ic IIC T6T1 Gc The Ex-significant identification is on the enclosed adhesive label
Directive conformity	94/9/EG
Standards	EN 60079-0:2012+A11:2013 EN 60079-11:2012 Ignition protection category "ic" Use is restricted to the following stated conditions
Effective internal inductivity C <sub>i</sub>	$\leq$ 105 nF ; a cable length of 10 m is considered.
Effective internal inductance L <sub>i</sub>	$\leq$ 100 $\mu H$ ; A cable length of 10 m is considered.
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction! The special conditions must be observed!
Installation, commissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed. The sensor must only be operated with energy-limited circuits, which satisfy the requirements of IEC 60079-11. The explosion group complies with the connected, supplying, power limiting circuit. If the Ex-relevant identification is printed exclusively on the adhesive label provided, this label must be affixed in the immediate vicinity of the sensor! The background surface to which the adhesivelabel is to be applied must be clean and free from grease! The applied label must be durable and remain legible, with due consideration of the possibility of chemical corrosion!
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.
Special conditions	
for Pi=34 mW, li=25 mA, T6	55 °C (131 °F)
for Pi=34 mW, li=25 mA, T5	55 °C (131 °F)
for Pi=34 mW, li=25 mA, T4-T1	55 °C (131 °F)
for Pi=64 mW, li=25 mA, T6	55 °C (131 °F)
for Pi=64 mW, li=25 mA, T5	55 °C (131 °F)
for Pi=64 mW, li=25 mA, T4-T1	55 °C (131 °F)
for Pi=169 mW, Ii=52 mA, T6	52 °C (125.6 °F)
for Pi=169 mW, li=52 mA, T5	52 °C (125.6 °F)
for Pi=169 mW, li=52 mA, T4-T1	52 °C (125.6 °F)
for Pi=242 mW, li=76 mA, T6	44 °C (111.2 °F)
for Pi=242 mW, li=76 mA, T5	44 °C (111.2 °F)
for Pi=242 mW, li=76 mA, T4-T1	44 °C (111.2 °F)
Protection from mechanical danger	The sensor must not be mechanically damaged. When used in the temperature range below $-20$ °C the sensor should be protected from the relation of the sensor should be protected.

Electrostatic charge

Connection parts

When used in the temperature range below -20 °C the s from knocks by the provision of an additional housing. nsor sho

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

The connection parts are to be installed, such that a minimum protection class of IP20 is achieved, in accordance with IEC 60529.

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com



Equipment protection level Da	
Instruction	Manual electrical apparatus for hazardous areas
Device category 1D	for use in hazardous areas with combustible dust
EC-Type Examination Certificate	PTB 00 ATEX 2048 X
	<b>CE</b> 0102
CE marking	
ATEX marking	↔ II 1D Ex ia IIIC T135°C Da The Ex-related marking can also be printed on the enclosed label.
Directive conformity	94/9/EG
Standards	EN 60079-0:2012+A11:2013 EN 60079-11:2012 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions
Appropriate type	NCB10-30GMN0
Effective internal inductivity C <sub>i</sub>	$\leq$ 105 nF ; a cable length of 10 m is considered.
Effective internal inductance L <sub>i</sub>	$\leq$ 100 $\mu H$ ; a cable length of 10 m is considered.
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. Directive 94/9/EG and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions. The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces by the mentioned certification authority. If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration.
Maximum permissible ambient temperature T <sub>amb</sub>	Details of the correlation between the type of circuit connected, the maximum per- missible ambient temperature, the surface temperature, and the effective internal reactance values can be found on the EC-type-examination certificate. The maximum permissible ambient temperature of the data sheet must be noted, in addition, the lower of the two values must be maintained.
Installation, commissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related appara- tus and according to the proof of intrinsic safety. If the Ex-related marking is printed only on the supplied label, then this must be attached in the immediate vicinity of the sensor. The sticking surface for the label must be clean and free from grease. The attached label must be legible and indeli- ble, including in the event of possible chemical corrosion.
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.
Special conditions	The connecting parts of the sensor must be set up in such a way that degree of pro- tection IP20, in accordance with IEC 60529, is achieved as a minimum.
Protection from mechanical danger	When using the device in a temperature range of -60 °C to -20 °C, protect the sensor against the effects of impact by installing an additional enclosure. The information regarding the minimum ambient temperature for the sensor as provided in the datasheet must also be observed.
Electrostatic charge	Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding. Avoid electrostatic charges that can cause electrostatic discharge when installing or operating the device. Information on electrostatic hazards can be found in the technical specification IEC/TS 60079-32-1. Do not attach the nameplate provided in areas where electrostatic charge can build up.

Release date: 2016-08-03 12:17 Date of issue: 2016-08-03 181120\_eng.xml

Refer to "General Notes Relating to Pepperl+Fuchs Product Information".

Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com



Equipment protection level Dc (tc)	
Instruction	Manual electrical apparatus for hazardous areas
Device category 3D Certificate of Compliance CE marking	for use in hazardous areas with combustible dust PF 15CERT3774 X $\mathbf{C} \in 0$ 102
ATEX marking	E II 3D Ex tc IIIC T80°C Dc The Ex-related marking can also be printed on the enclosed label.
Directive conformity	94/9/EG
Standards	EN 60079-0:2012+A11:2013, EN 60079-31:2014 Protection by enclosure "tc" Some of the information in this instruction manual is more specific than the information provided in the datasheet.
General	The corresponding datasheets, declarations of conformity, EC-type examination certifi- cates, certifications, and control drawings, where applicable (see datasheets), form an integral part of this document. These documents can be found at www.pepperl- fuchs.com. The maximum surface temperature of the device was determined without a layer of dust on the apparatus. Some of the information in this instruction manual is more specific than the information provided in the datasheet.
Installation, commissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed. If the Ex-relevant identification is printed exclusively on the adhesive label provided, this label must be affixed in the immediate vicinity of the sensor! The back- ground surface to which the adhesivelabel is to be applied must be clean and free from grease! The applied label must be durable and remain legible, with due consideration of the possibility of chemical corrosion!
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.
Special conditions	
Minimum series resistance R <sub>V</sub>	A minimum series resistance RV is to be provided between the power supply voltage and the proximity switch in accordance with the following list. This can also be assured by using a switch amplifier.
Maximum operating voltage U <sub>Bmax</sub>	The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances are not permitted.
Maximum permissible ambient temperature $T_{Umax}$	Values can be obtained from the following list, depending on the max. operating voltage Ub max and the minimum series resistance Rv.
at U <sub>Bmax</sub> =9 V, $R_V$ =562 $\Omega$	66 °C (150.8 °F)
using an amplifier in accordance with EN 60947-5-6	66 °C (150.8 °F)
Protection from mechanical danger	The sensor must not be exposed to ANY FORM of mechanical danger.
Protection from UV light	The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is used in internal areas.
Protection of the connection cable	The connection cable must be prevented from being subjected to tension and torsional loading.
Electrostatic charge	Electrostatic charges must be avoided on the mechanical housing components. Dan- gerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding. Avoid electrostatic charges that can cause electrostatic discharge when installing or operating the device. Information on

gerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding. Avoid electrostatic charges that can cause electrostatic discharge when installing or operating the device. Information on electrostatic hazards can be found in the technical specification IEC/TS 60079-32-1. Do not attach the nameplate provided in areas where electrostatic charge can build up.

8

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com