

PRO-ELEC

Programming Remote Control Socket - PEL00551



Please read these instructions carefully before use and retain for future reference.

IMPORTANT SAFETY INFORMATION

- When using electrical appliances basic safety precautions should always be followed.
- Check that the voltage indicated on the rating plate corresponds with that of the local network before connecting the socket to the mains power supply.
- This remote control socket is intended for domestic use only. It should not be used for commercial purposes.
- This remote control socket is designed for indoor use only.
- Children shall not play with the remote control socket.
- Cleaning and maintenance shall not be made by children without supervision.
- There are no user-serviceable parts in this product. Refer servicing to qualified personnel.
- Do not operate this remote control socket after a malfunction or after being dropped or damaged in any way.

FEATURES

- Individual on and off function for the remote control.
- With self-learning function, any one remote control and socket receiver can match up after finishing the programming operation.
- It is easy to match a new remote control or socket receiver if the original remote control or receiver is broken or lost.
- The socket receiver will still remain in the "Off" mode after a power cut, even after the power is restored.
- Reduces energy consumption.
- Long range transmitting distance - up to 30m in free air.
- Durable and stable operation.

PRODUCT & OPERATION

- The remote control has three buttons, numbered 1, 2 and 3.
- The buttons 1, 2 and 3 control the respective socket receivers.
- The socket receiver is operated via the remote control. Each push of the numbered button on the transmitter will turn on or turn off the corresponding socket.

INSTALLATION

- Install one 12V (A23) battery (provided) in the compartment.
- Ensure that the battery is inserted correctly, observing the plus and minus marks on both the battery and the compartment.
- Regularly change the battery in the remote control for best performance, however if you find the receivers are not responding or the indicator light has become dim, then it is advised to change the battery at the earliest opportunity.

PROGRAMMING OPERATION

All remote controlled socket units have been pre-programmed and can be used immediately. To re-programme the remote control and socket receiver, please follow the instructions below:

- Press and hold the desired button number on the remote control.
 - Plug the remote controlled socket to a power point and turn the power on.
 - The LED indicator inside of the socket receiver will be in a flashing state.
 - Programming is successful when the LED indicator stops flashing.
- Note: One transmitter can programme one or more socket receivers, but one socket receiver can only be programmed and matched to a single remote control.

BATTERY SAFETY

- Always ensure the battery compartments are secure.
- Only use the battery recommended.
- Ensure the correct fit of batteries, observing the plus and minus marks on both the battery and the compartment.
- If the battery is dead, remove it from the remote control.
- Remove the battery from the remote control if it will not be used for a long time.
- Supervise children with batteries at all times.
- Keep batteries away from small children. Seek medical attention if batteries are swallowed.
- Never attempt to recharge ordinary batteries or dispose of batteries in a fire.

Technical Specification	
Transmitter Power	DC 12V (A23) battery
Transmission Frequency	433.92MHz
Transmitting Distance	30m (free area)
Voltage for Outlet	240V~50Hz
Maximum Loading current for each socket	10A



INFORMATION ON WASTE DISPOSAL FOR CONSUMERS OF ELECTRICAL & ELECTRONIC EQUIPMENT.

This symbol indicate that separate collection of Waste Electrical and Electronic Equipment (WEEE) or waste batteries is required. Do not dispose of these items with general household waste. Separate for the treatment, recovery and recycling of the materials used. Waste batteries can be returned to any waste battery recycling point which are provided by most battery retailers. Contact your local authority for details of the battery and WEEE recycling schemes available in your area.

