















# Wireless\* data logging at 1 kS/s (1 ms)

330-channel portable logger available with your choice of plug-in modules and wireless\* modules

\* LR8450-01 only





# Two models: Standard Model and Wireless LAN Model



# Standard model (designed for use with plug-in modules only) LR8450

# You can add up to 4 plug-in modules which provides 120 channels of measurement






Configuration example: 120 channels of analog input

# Plug-in units

**VOLTAGE/TEMP UNIT U8552×4** 

Each VOLTAGE/TEMP UNIT U8552 accepts 30 channels of input. Add four units for 120 channels of measurement.

# Depending on various scenes, you can freely combine six types of plug-in modules





Configuration example: 60 channels of analog input + 1,000 channels of CAN input

# Plug-in units

VOLTAGE/TEMP UNIT U8552×2 CAN UNIT U8555×2

Each VOLTAGE/TEMP UNIT U8552 accepts 30 channels of input. Each CAN UNIT U8555 accepts 500 channels of input.

# Wireless LAN model

# Add channels freely via either plug-in or wireless modules

Can also be used exclusively with wireless modules



# Wireless LAN model LR8450-01

# Add up to 7 wireless modules in total for a maximum of 330 channels

Configuration example: 330 channels

# Plug-in modules

**VOLTAGE/TEMP UNIT U8552×4** 



# Wireless modules

WIRELESS VOLTAGE/TEMP UNIT LR8532×7



With four U8552 VOLTAGE/TEMP UNITs and seven LR8532 WIRELESS VOLTAGE/TEMP UNITs, you can measure a total of 330 channels.

# Mix plug-in and wireless modules

Mixing and matching plug-in modules and wireless modules will allow you to build a measurement system that suits your needs.\*1

If wireless modules are used with other modules (wireless or plug-in), the sampling-timing shift between the units is periodically corrected.\*2

In addition, at times when the wireless communication is cut off, the correction function works after the communication is restored and the sampling-timing shift between the modules is corrected.

<sup>\*1</sup> Up to four CAN modules can be used at the same time. (Plug-in and wireless modules may be used in any combination.)

<sup>\*2</sup> Even in good wireless communication conditions (low interference) the sampling-timing between modules may shift about 20 ms. In bad wireless conditions, the sampling-timing shift will be much worse than this.

# Voltage measurement



# Measure outputs from a pressure sensor and other sensors at 1 kS/s max. sampling rate (1 ms interval sampling)

1 kS/s sampling is necessary to record outputs of several tens of Hertz from pressure sensors and vibration sensors.







WIRELESS HIGH SPEED VOLTAGE UNIT LR8533

# Temperature measurement





# Measure temperature near inverters and batteries at a sampling rate of up to 100 S/s (10 ms interval sampling)




VOLTAGE/TEMP UNIT U8550 UNIVERSAL UNIT U8551 VOLTAGE/TEMP UNIT U8552(\*)



WIRELESS VOLTAGE/TEMP UNIT LR8530 WIRELESS UNIVERSAL UNIT LR8531 WIRELESS VOLTAGE/TEMP UNIT LR8532(\*)

# Consistent sampling rate even with added modules

Each module incorporates its own A/D converter. This design keeps the maximum sampling rate high even when Modules are added.



Example 1: use four U8553 HIGH SPEED VOLTAGE UNITs (with 5 channels each) to measure 20 channels at a sampling rate of 1 kS/s (1 ms).

Example 2: Use four U8550 VOLTAGE/ TEMP UNITs (with 15 channels each) to sample 60 channels at a sampling rate of 100 S/s (10 ms).

# Consistent noise resistance even with added modules


Since increasing the number of modules has no effect on the cutoff frequency, which changes with the sampling rate, power supply noise can be reduced without sacrificing noise resistance.

(ex.) Samplr	ig rate: 1 S/s
Number of channels	Cutoff frequency
1 ch to 15 ch	60 Hz
16 ch to 30 ch	60 Hz
31 ch to 45 ch	60 Hz
46 ch to 60 ch	60 Hz
*When using a power supply	<b>A</b>
frequency of 60 Hz.	Same cutoff

frequency

### Set filters

# Set filters for each module



The cutoff frequency, which varies with the data refresh interval, can be set separately for each module. You can use long data refresh intervals, which boost filter effectiveness, and short data refresh intervals for different modules at the same time.

- Measure control signals at maximum speed: module1 (data refresh interval: 1 ms)
- Measure battery voltage fluctuations: module 2 (data refresh interval: 1 ms)
- Measure temperature using thermocouples: module 3 (data refresh interval: 1 s) with strong filter

<sup>\*</sup> Sampling rate of 100 S/s (10 ms) is available when using 15 or fewer channels.

# Strain measurement

# Measure strain with a 1 kS/s sampling rate (1 ms)

Connect strain gages directly and measure at a sampling rate of up to 1 kS/s. Strain gages tend to have long, thin wires that are easily broken, but that potential pitfall can be avoided by using wireless modules so that wiring is minimized.






STRAIN UNIT U8554

WIRELESS STRAIN UNIT LR8534


# **Connect strain gages directly**

The strain units have a built-in bridge box, allowing you to connect strain gages directly to their input terminals.



Strain-gage-type converters such as load sensors and pressure sensors can be connected directly to make measurement.







# Reduced influence of noise


# Stable measurement, even at high voltages and high frequencies

Most competing loggers are incapable of measuring temperature accurately in noisy environments due to the influence of high frequencies, causing values to shift or fluctuate significantly. The LR8450 uses a new design to dramatically reduce the influence of high-frequency noise.

Example: measure temperature by connecting the tip of a K thermocouple to the screw on an inverter's PWM output terminal (W-phase) when using the U8550 VOLTAGE/TEMP UNIT (settings: 10 S/s sampling in the 100°C f.s. range).








Most competing loggers exhibit significant fluctuations when the inverter is operating, whereas the MEMORY HILOGGER LR8450 does not.

# **CAN** measurement NEW



# One instrument, two uses: **CAN input + CAN output of measured values**

	U8555	LR8535
Input: CAN and CAN FD	Yes	Yes
Output: CAN and CAN FD	Yes	No



# Receive CAN signals using a contactless, wireless setup!

Wireless modules interoperate flawlessly with the NON-CONTACT CAN SENSOR SP7001-95! Supply power from the battery-driven wireless unit to the NON-CONTACT CAN SENSOR SP7001-95 via USB to implement a wireless CAN measurement setup that requires no external power supply. (The system can operate for about



five hours on battery power.) Since no ECU analysis tools or computer is required, the setup takes little space to reduce the amount of wiring needed for driving tests.

# Convenient function 1 Notification when a specific ID is received

Start and stop measurement when a CAN signal with a specific ID occurs



# Convenient function 2 Bit mask trigger function

Set a trigger that corresponds to a particular pattern with the bit mask trigger function. For example, this function can be used when you wish to start recording when a control signal exhibits the specific pattern of "10101010."

# Support for multichannel measurement: receive up to 500 channels with 1 module

As a result of electrification, automobiles now use enormous quantities of data internally, and the amount of data on CAN buses consequently is growing. A single CAN module can capture up to 500 channels\*1 of data. The LR8450 can accommodate up to four modules, allowing you to measure up to 2000 channels of CAN data. Each channel can collect information for one signal

\*1 With a recording interval of 100 ms

# Convenient function 3 Sending user-defined CAN frames

Sometimes it's necessary to send a CAN signal to an ECU in advance so that the ECU will output data to the CAN bus. With the U8555, you can send userdefined CAN frames to a CAN bus while performing CAN measurement.

# One-time transmission

When you need to send a CAN control frame once in order to change an ECU's operating mode

### Repeated transmission

When an ECU won't output the value you wish to capture unless you send specific CAN data each time




CAN UNIT U8555
CAN and CAN FD input or output



WIRELESS CAN UNIT LR8535
CAN and CAN FD input only






# **High-speed output**

Higher vehicle performance is creating a demand for faster, more complex communications control. Thanks to its ability to output voltage and temperature measured values to the CAN bus with a data refresh period as short as 1 ms (1 kS/s), the LR8450 can accommodate the need to acquire measurement data for systems that require real-time control.

# Generate CAN signal output as an alarm when a malfunction is detected

Set a threshold for analog measured values like voltage or temperature so that the CAN signal is output if the threshold is exceeded. This feature lets you use a CAN logging system to detect malfunctions.



# **CAN Editor** (standard CAN configuration software accessory)

Install this software from the application disc that comes with the MEMORY HiLOGGER LR8450 onto a PC to easily configure CAN Unit settings.

# **Setting method** Online or offline


Save settings configured using the CAN Editor in the CES format and then load them with the LR8450. You can also configure instruments offline when a LAN or USB connection is difficult to establish.

# Receive mode Loading DBC files

In addition to setting up channels manually, you can complete CAN communication definition settings simply by loading a DBC file.

# Output mode Automatically configuring output targets

Creating output communication definitions one channel at a time for a logger that's handling a large number of channels is extremely time-consuming. With the CAN Editor, you need only specify the start ID and click the "Configure Automatically" button to complete all communication definitions. Those definitions can then be output as a DBC file and loaded onto an upstream system to complete the configuration process.



# Wireless for ease of use

# Collect data from dispersed locations all at the same time

The LR8450-01 can simultaneously collect measurement data from wireless units installed on various test equipment.

Collect measurement data from multiple locations with a single logger

Manage data in a single time sequence

Units can be placed in confined locations

Check the display during measurement



Up to 30 m\* (line-of-sight)

\* Better connection may be attained from placing the LR8450-01 and/or wireless module on the floor or ground for a shorter communication distance.



# Peace of mind in the event of an interruption in power or wireless connectivity

Peace of mind if communications are temporarily interrupted

# Buffer memory holds up to 5 min.\*1 of measurement data

Each wireless unit has a built-in buffer memory that can hold up to 5 min.\*1 of measurement data. Data are resent along with more recent measurement data once communications resume, after which the data are restored inside the LR8450-01\*2.

The system can be configured to output an alarm if communications are interrupted or if a module encounters a low-battery state.

- \*1 The duration for which measurement data can be maintained does not vary with the recording interval (up to a maximum of 5 min.)
- \*2 Data collected using the Logger Utility software measurement cannot be restored in this manner.

# **Battery operation**


# Use modules in locations where there's no AC power

### Example

The wireless VOLTAGE/TEMP UNIT LR8530 can operate for about 9 hours on battery power. If the unit is charged at night, it can operate on just the battery pack during the day.

Using the Battery Pack Z1007

Wireless module model	Continuous operating time
LR8530	Approx. 9 hr.
LR8531	Approx. 7 hr.
LR8532	Approx. 9 hr.
LR8533	Approx. 9 hr.
LR8534	Approx. 5 hr.
LR8535	Approx. 10 hr.*



Peace of mind in the event of a power outage during measurement

# Install a battery pack for peace of mind

If you've installed a battery pack in a module that's being powered by an AC adapter, the unit will automatically switch to battery power in the event of an outage so that the LR8450-01 can continue making measurements.



# Make measurements in locations where it would be difficult to route wires

Work time can be reduced using the LR8450-01 and wireless modules, since only minimal wiring is required. If the measurement target is located in a lab, this approach eliminates the need for wiring and avoids having to drill holes in the walls of the monitoring room where data is being checked.

Inside a room, or outside, you can make measurements with the door closed.



# Simple registration of wireless modules

Wireless modules, located within the range, that are not connected to another LR8450-01, can be automatically detected. Simply choose the module you wish to register from the list.








# Check the unused wireless LAN channels and select the wireless channel to use

You can reduce interference from other wireless devices by using an open channel (wireless frequency range being used by wireless devices in the area). Check for open channels on the instrument's screen.






# Observe data from a remote location using a PC or a tablet


By connecting the LR8450-01 to a PC or a tablet via wireless LAN, you can control the instrument remotely using the built-in HTTP server or obtain older data files using the built-in FTP server.

(You cannot use Logger Utility when using Station Mode or Access Point Mode. See below.)

# 



# Easy-to-read display of measured values




# External control terminals and interfaces to accommodate a broad range of use cases



Motor speed, flow rate integration, etc.


# 8 channel pulse measurement



In "Revolve" mode, monitor production equipment by measuring the variations in revolution speed of motors or drills. In "Count" mode, identify operation status by acquiring integrated power or flow rate.

# Useful in preventive maintenance


# 8 channel alarm outputs



You can set alarm output for eight channels. You can set a level, a window, a slope, and a logic pattern on channels you wish to monitor.

Two terminals for voltage outputs (5, 12, or 24 V)


# Supplying power to the sensors



The LR8450, LR8450-01 provides two output terminals for voltages, each of which can supply 100 mA current, eliminating the need for a separate sensor power supply. You can select 5 V, 12 V, or 24 V from the VOUTPUT1 terminal and 5 V or 12 V from the VOUTPUT2 terminal.

# **NEW** Connect and measure up to 5 units

# **Analog 600 CH Synchronous Sampling**



Synchronized sampling up to 5 plug-in modules (600 analog channels) can be measured when multiple LR8450's external sync terminals (SYNC.IN, SYNC.OUT) are connected.

Note: This function cannot be used when wireless modules are connected.


# **Extensive calculation functions**

# **Numerical calculation function**

In addition to the maximum and minimum value calculation functions provided by previous models, the LR8450/LR8450-01 offers an extensive range of calculations, including on/off time, count, and usage ratio.




#### Types of calculations



### **Waveform calculation function**

Calculate data while measurement continues and display calculated waveforms in real time. Calculation results are saved on a separate and dedicated calculation channel.



### Types of calculations

Basic arithmetic operations

Aggregation

Simple average

Moving average

Integration

# Recording over extended periods of time without interruption

Collect data on a storage device (SD memory card or USB drive) while measuring continues. The ability to segment files by hour or day without stopping measurement is convenient when you need to review data later.



# **Maximum recording time (estimate)**

# Example: Recording 30 analog channels with 2 modules (no alarm output or waveform processing)

Because the header portion of waveform files is not included in capacity calculations, expected actual maximum time is about 90% of those in the tables. The maximum recording time varies with the number of measurement channels. Recording times are doubled if the number of measurement channels shown in the table is halved.

When recording 30 analog channels with two U8550/U8551 modules or one U8552 module (no alarm output, no waveform processing) When recording 30 analog channels with two LR8530/LR8531 modules or one LR8532 module (no alarm output, no waveform processing)

Recording intervals		ouffer memory 12 MB)		RY CARD Z4001 (2 GB)		RY CARD Z4003 8 GB)		RIVE Z4006 16 GB)
10 ms	1 d		3 d	20 h	15 d	8 h	30 d	12 h
100 ms	10 d	8 h	38 d	18 h	153 d	9 h	305 d	5 h
1 s	103 d	13 h	387 d	12 h	1,533 d	21 h	3,052 d	9 h
10s	500 d		3,875 d	6 h	15,339 d	3 h	30,523 d	19 h

When recording 20 channels with four U8553 modules or U8554 modules (no alarm output, no waveform processing) When recording 20 channels with four U8553 modules or LR8534 modules (no alarm output, no waveform processing)

Recording intervals	Internal buffer memory (512 MB)	SD MEMORY CARD Z4001 (2 GB)	SD MEMORY CARD Z4003 (8 GB)	USB DRIVE Z4006 (16 GB)
1 ms	3 h 43 min	13 h 56 min	2 d 7 h	4 d 13 h
10 ms	1 d 13 h	5 d 19 h	23 d	45 d 18 h
100 ms	15 d 12 h	58 d 3 h	230 d 2 h	457 d 20 h
1s	155 d 8 h	581 d 7 h	2,300 d 21 h	4,578 d 13 h
10 s	500 d	5,813 d 1 h	23,008 d 20 h	45,785 d 20 h

When recording 330 channels with four U8552 modules and seven LR8532 modules (no alarm output, no waveform processing)

Recording intervals	Internal buffer memory (512 MB)	SD MEMORY CARD Z4001 (2 GB)	SD MEMORY CARD Z4003 (8 GB)	USB DRIVE Z4006 (16 GB)
20 ms	4 h 8 min	15 h 28 min	2 d 13 h	5 d 2 h
100 ms	20 h 42 min	3 d 5 h	12 d 18 h	25 d 10 h
1s	8 d 15 h	32 d 6 h	127 d 19 h	254 d 8 h
10 s	86 d	322 d 16 h	1,277 d 23 h	2,543 d 9 h

# Control the instrument remotely and capture data on a PC


**HTTP** server function

# Control the instrument remotely from a PC

Use a standard Web browser to control the LR8450/LR8450-01, start and stop measurement, then enter comments.

# Use a mouse to operate waveforms displayed on a PC

Enjoy intuitive mouse-based control, including waveform scrolling and cursor operations.



**FTP** server function

# Download data files onto a PC

Your PC can get files from inside the SD memory card or USB drive inserted to the LR8450/LR8450-01.

#### **FTP** client

# Automatically transfer data files to an FTP server

Automatically transmit files to an FTP server from the SD memory card or in the USB drive inserted to the LR8450/LR8450-01.

# **NTP** client function

# Set the logger's clock

Set the clock in the LR8450/LR8450-01 and synchronize it to an NTP server on the network.

#### E-mail transmission function

CAN-FD - Powertrain

# Receive email notices on errors and other information

Receive emails to your PC or mobile phone when there is a communication loss and when an error occurs during measurement and wireless module communications.


It can also send instantaneous values by e-mail periodically.

# **Use with other tools**



# Output measured values using XCP on Ethernet

The LR8450 supports XCP Secondary operation based on the XCP protocol, a standard developed by the Association for Standardisation of Automation and Measuring Systems (ASAM). You can perform control to start and stop measurement and acquire measured values using an XCP Primary. (Measured values from CAN modules cannot be output.)





CAN - Body
Vehicle bus

ECU access

ECU RAM measurement and calibration task

CAN bus measurement
GateWay ECU

ECU/bus measurement interface

Interface module

Overwrite control parameters while ECUs continue to operate
Consolidate data from multiple measurement systems and buses
Monitor large amounts of microcontroller RAM at high speeds

### NEW

# Load data using MDF-compatible waveform viewers

Voltage, temperature, strain, CAN, and other measurement data captured by the LR8450 can be saved in the Measurement Data Format (MDF) and loaded by other software that supports the format.

### Commercially available software

# **FAMOS**




- · More than 400 calculation processing variables
- · Easy report creation functionality

# **FlexPro**




- · High-speed search and processing of large volumes of data
- · Share analysis templates within your company

# NI DIAdem



- Functionality ranging from searching and loading of data to analyzing and creating of reports
- · Dialog-based interface


# OS-2000



- · Freely edit large data that cannot be handled by Excel
- Simultaneously display the waveforms which have different frequencies

# Logger Utility (standard accessory)

# Collect data at sampling speeds of up to 10 ms on a PC



Record data on a PC in real time using the Logger Utility application software, a standard accessory. You can even scroll waveforms backwards to view older data while recording is in progress. A real-time measurement is supported for recording intervals of 10 ms or longer.

U8555 and LR8535 CAN Unit real-time measurement and viewing of waveform data are not supported. Please use the GENNECT One software for real time viewing of CAN data by the U8555 and LR8535.

Recording simultaneous recording units Save destination method

10 ms 600 channels up to 5 PC LAN/USB

 $\bigcirc$ 


Simultaneously log data from five LR8450 instruments at a speed of up to 10 ms.

Display logged data in real time as a graph.

# **GENNECT** One

+ 60 waveform calculation channels

# Make simultaneous measurements using multiple instruments



Aggregate measurement data from not only loggers, but also waveform recorders, power meters, and other instruments onto a single PC.

Display this measurement data on a single graph in real time. Summarize it in daily and monthly reports. Manage in in a centralized manner. GENNECT One is a Windows application that specializes in aggregating measurement data.

Data including CAN data from the U8555 and LR8535 can be viewed and measured in real time (logging function, dashboard function). Real time measurement and viewing of CAN data will be available from the LR8450's next firmware update around mid or late 2022.

GENNECT One is a free application.

Access this code for details and downloads.



Recording interval Simultaneous recording Total No. of connected destination method

1 s 512 channels Up to 15 PC LAN

\*Up to 30 devices can be connected when using only the logging or dashboard functions



Simultaneously log data from instruments like recorders and power meters as frequently as 1 s.



Display logged data in real time as a graph. Automatically create CSV files and daily/monthly reports.



Graphically display measured values using the dashboard function. Visually identify anomalies.



Download instrument data files saved on instruments' SD cards.



Change instrument settings remotely.

# **Specifications**

Specificati	ons
	1 Memory HiLogger ions, basic specifications
Product warranty period	3 years
Accuracy guarantee period	1 year
Maximum number of connectable modules	4 plug-in modules + 7 wireless modules* *LR8450-01 only No more than 4 CAN modules (U8555 and/or LR8535) can be connected.
Connectable modules (plug-in modules)	U8550 VOLTAGE/TEMP UNIT U8551 UNIVERSAL UNIT U8552 VOLTAGE/TEMP UNIT U8555 CAN UNIT
Connectable modules (wireless modules) (LR8450-01 only)	LR8530 WIRELESS VOLTAGE/TEMP UNIT LR8531 WIRELESS UNIVERSAL UNIT LR8532 WIRELESS VOLTAGE/TEMP UNIT LR8533 WIRELESS HIGH SPEED VOLTAGE UNIT LR8534 WIRELESS STRAIN UNIT LR8535 WIRELESS CAN UNIT
Internal buffer memory	Volatile memory, 256 M-words
Clock functionality	Auto-calendar, automatic leap year recognition, 24-hour clock
Clock precision (precision of clock dis- played by instrument as well as start/stop times)	±1.0 s/day (at 23°C) Time can be synchronized with an NTP server to which the instrument is connected.
Time axis accuracy	±0.2 s/day (at 23°C)
Backup battery service life	For clock, at least 10 years (reference value at 23°C)
Operating environment	Indoors, pollution degree 2, altitude up to 2000 m
Operating temperature and humidity range	-10°C to 50°C (14°F to 122°F), 80% RH or less (non-condensing) (charging temperature range: 5°C to 35°C)
Storage temperature and humidity range	−20°C to 60°C (−4°F to 140°F), 80% RH or less (non-condensing)
Dimensions	Without any modules: 272W × 145H × 43D mm (10.72"W × 5.71"H × 1.69"D) (excluding protrusions) With 2 modules: 272W × 198H × 63D mm (10.71"W × 7.8"H × 2.78"D) (excluding protrusions) With 4 modules: 272W × 252H × 63D mm (10.71"W × 9.92"H × 2.48"D) (excluding protruding parts)
Mass	Approx. 1108 g (39.08 oz.) (excluding battery pack)
Standards	Safety: EN61010 EMC: EN61326 Class A
Vibration resistance	JIS D 1601:1995:1995 5.3 (1) Class 1: Passenger vehicles; conditions: Class A equivalent
Accessories	Quick start manual, LOGGER application disc (quick start manual, instruction manual, logger utility, logger utility instruction manual, CAN editor, CAN editor instruction manual, communication instruction manual), USB cable, AC adapter Z1014, precautions concerning use of equipment that emits radio waves (LR8450-01 only)
Display	
Dienlay	7-inch TET color LCD (MV/GA 800 x 480 dots)

Display	
Display	7-inch TFT color LCD (WVGA 800 × 480 dots)
Display resolution (with waveform display selected)	Max. 20 divisions (horizontal axis) × 10 divisions (vertical axis) (1 division = 36 dots [horizontal axis] × 36 dots [vertical axis])
Display language	Japanese, English, Chinese, Korean
Backlight service life	Approx. 100,000 h (reference value at 23°C)
Backlight saver	Turns off backlight when no key is operated for a set amount of time
Backlight brightness	5 levels (user-selectable)
Waveform background color	Dark/Light (user-selectable)

Power sup	ply	
Power supply	AC adapter	Z1014 AC Adapter (12 V DC ±10%) AC Adapter rated supply voltage: 100 V to 240 V AC (assuming voltage fluctuation of ±10%) AC Adapter rated power supply frequency: 50/60 Hz
	Battery	LR8450 accommodates 2 batteries Z1007 Battery pack (when used with AC Adapter, AC Adapter takes priority)
	External power supply	10 V to 30 V DC
Power consumption	Normal power consumption	Using Z1014 AC adapter or 12 V DC external power supply, without Battery Pack With LCD at maximum brightness: 8.5 VA (instrument only) With LCD backlight off: 7 VA (instrument only)
	Maximum rated power	When using the Z1014 AC adapter 95 VA (including AC adapter) When using a 30 V DC external power supply 28 VA (while charging battery with LCD at maximum brightness) When using the Z1007 Battery pack 20 VA (with LCD at maximum brightness)
Continuous operating time	Battery	With one Z1007 Battery pack: approx. 2 h (reference value at 23°C) With two Z1007 Battery packs: approx. 4 h (reference value at 23°C) Conditions: with one U8551 Universal Unit connected, backlight on, voltage output off, and Z4006 connected
Charging functionality	adapter is con	ailable when the Z1007 Battery pack is attached and the AC nected. Approx. 7 h (reference value at 23°C)

	specifications interface and USB interface (function) cannot be used at the same time
LAN interface	IEEE 802.3 Ethernet, automatic 100Base-TX/1000Base-T detection Auto MDI-X, DHCP, DNS supported Connector: RJ-45
	LAN functionality: Acquiring data and setting recording conditions with Logger Utility
LAN interface	LAN func- Configuring settings and controlling recording using communications tionality: commands

Manually acquiring data using the FTP server: Acquiring files from a connected SD Memory Card or USB Drive

Automatically sending of data via FTP (FTP client)
Transferring files saved on a connected SD Memory Card or USB Drive
Waveform files while measurement is in progress: binary, text, MDF
Waveform files after measurement has finished: binary, text, MDF, numerical calculation result files HTTP server function Control mode (one instrument):
Displaying screen and remotely controlling instrument and modules, current measured value display, starting/stopping measurement, acquiring data via FTP, setting comments, updating instrument and modules Browsing mode (up to four instruments): Displaying screen, measurement status, and comments Email transmission
Sends emails at the event of: start trigger, stop trigger, alarm, power outage recovery, internal buffer memory full, media full, wireless unit communications interruption, and battery low. Attachment of instantaneous value data can be enabled or disabled. Emails can be sent regularly at the following intervals: 30 min., 1 h, 12 h, or 1 day. NTP client function Time synchronization with an NTP server Regular synchronization intervals: 1 h, 1 day Pre-measurement synchronization function Wireless LAN IEEE 802.11b/g/n Communications range: 30 m, line of sight Encryption function: WPA-PSK/WPA2-PSK, TKIP/AES Available channels: between 1 and 11 interface (LR8450-01 Avdiable charifies, between 1 and 11
Auto-connect function: wireless LAN function can be toggled on and off.
Supported modes: access point, station, wireless module connectivity
Devices that can be connected in wireless module connectivity mode: wireless modules or PC/tablet only) You can use either a wireless module or PC/tablet with wireless connection Wireless Configuring settings and controlling recording using communications commands LAN funcManually acquiring data using the FTP server Acquiring files from a connected SD Memory Card or USB Drive Automatically sending data via FTP (FTP client) Transferring files saved on a connected SD Memory Card or USB Drive HTTP server function Control mode (one instrument): Displaying screen and remotely controlling instrument and modules, current measured value display, starting/stopping measurement, acquiring data via FTP, configuring comment, updating the instrument and modules Browsing mode (up to four instruments): Displaying screen, current measured value display, measurement status, and comments Email transmission Sends emails at the event of: start trigger, stop trigger, alarm, power outage recovery, internal buffer memory full, media full, wireless unit communications interruption, and battery low. Attachment of instantaneous value data can be enabled or disabled. Emails can be sent regularly at the following intervals: 30 min., 1 h, 12 h, or 1 day. NTP client function Time synchronization with an NTP server Regular synchronization intervals: 1 h, 1 day Pre-measurement synchronization function USB Standard compliance: USB 2.0 compliant interface Connectors: Series A receptacle × 2 (host) Guaranteed-operation options: Z4006 USB drive (16 GB) File system: FAT16, FAT32 Connectable devices: keyboard, mouse, hub (1 layer), USB drive (1 port only) USB standard: USB 2.0 compliant USB interface Connector: series mini-B receptacle (function) USB functionality: data acquisition, condition settings used with the Logger Utility software (bundled)
Configuring settings and controlling recording using communications commands USB drive mode: transferring data from a connected SD memory card to a computer SD card Standard compliance: SD standard-compliant slot × 1 (with SD memory card/SDHC memory card support) slot Guaranteed-operation options: Z4001 (2 GB), Z4003 (8 GB) File system: FAT16, FAT32

External	l control te	rminals	
Terminal	block	Push-button type term	ninal block
Sync input	Input voltage	0 V to 10 V DC	
(SYNC.IN)	Number of terminals	1, non-isolated (comr	non GND with instrument)
Sync out-	Format	CMOS output	
put (SYNC. OUT)	Number of terminals	1, non-isolated (comr	non GND with instrument)
External I/O	Number of terminals	4, non-isolated (comr	non GND with instrument)
	Input	Input voltage	0 V to 10 V DC
		Slope	Rising/falling (user-selectable)
		Functionality	Choose from off, start, stop, start/stop, trigger input, event input
	Output	Output format	Open-drain output (with 5 V voltage output)
		Maximum switching capacity	5 V to 10 V DC, 200 mA
		Functionality	Trigger output
Alarm ou	ıtput	Output format	Open-drain output (with 5 V voltage output)
		Maximum switching capacity	5 V to 30 V DC, 200 mA
		Number of terminals	8, non-isolated (same GND as instrument)
Voltage of	output	Output voltage	Off, 5 V, 12 V, 24 V* (user-selectable) Supply current: max. 100 mA each *24 V output can be selected for VOUTPUT1 terminal only
		Number of terminals	2, non-isolated (same GND as instrument)
GND teri	minal	Number of terminals	10 (common GND)

Decerding m			
Recording m		Normal	
Recording in	tervals	s, 5 s, 10	ms*, 5 ms*, 10 ms, 20 ms, 50 ms, 100 ms, 200 ms, 500 ms, 1 s, 2 s, 20 s, 30 s, 1 min., 2 min., 5 min., 10 min., 20 min., 30 min., 1 h railable only when using a module with data refresh intervals that include 1 ms
			ically- or user-selected value per module
Repeat recor	rding	- '	iser-selectable)
Specified ime/continud	ous	Time car (total 25) Continuo If maxim	time: recording time is set in days, hours, minutes, and seconds. n be set up to maximum capacity of internal buffer memory. 6 mega-data-points) pus: recording is performed once until it is stopped. um capacity of internal buffer memory is exceeded, memory verwritten.
Waveform recording		Last 256 Scroll th	verwitten: i mega-data-points are saved in internal buffer memory. rough and view data stored in internal buffer memory. surce data recording can be toggled on and off.
Backup of record	ded data		dies data resorting can be toggica on and on.
Display			
Max. nu CAN cha		Max. nui	heets can be switched between all channels and individual modules. mber of channels on all-channel display sheet: 120 analog/ annels, 30 waveform calculation channels, 8 pulse/logic s, 8 alarm channels
Waveform dis screen	splay		s waveform display: simultaneous display of gages and settings settings and display settings)
		Simultane values, cu Numerica cal values	cous display of time-axis waveforms and values: instantaneous ursor values, or numerical calculation values (user-switchable) Il display: simultaneous display of instantaneous values and statisti-
Display forma	at	1	s waveform display: 1 screen
K-Y composi	te		eform display: 1 screen ite up to 8 waveforms.
Numerical di			decimal, or exponent (user-selectable)
ormat		When de	ecimal is selected, number of decimal places to display can values will then be rounded to set number of places).
Naveform co Zooming in a			2 ms to 1 day/division
out on the waveform display		axis	•
.aroioiiii uis	-piu y	Vertical axis	Number of divisions per screen: 10 Setting method Select position or upper and lower limits for each channel. (Waveform calculation channels: upper and lower limits only) When setting by position: set zoom factor and zero position. Zoom factor: 1/2 × 1 × 2 × 5 × 10 × 20 × 50 × 100 × Zero position: -50% to 150% (with a zoom factor of 1 ×) When setting by upper/lower limit: set upper and lower limit.
Naveform so	rolling		can be scrolled left and right both during recording and while
recordin  Monitor display Check in		recording Check ins	g is stopped (during waveform rendering only) stantaneous values and waveforms without recording data to values and waveforms can be displayed while waiting for a trigger)
			THE PROPERTY OF THE PROPERTY O
		Indicates	s the battery remaining and the radio-wave strength, in the lls, of the wirelessly connected modules
display (LR8450-		Indicates	s the battery remaining and the radio-wave strength, in the
lisplay (LR8450-	-01 only)	Indicates four leve	s the battery remaining and the radio-wave strength, in the lls, of the wirelessly connected modules
display (LR8450- Files Save	-01 only) SD me	Indicates four leve	s the battery remaining and the radio-wave strength, in the
display (LR8450- Files Save destinations	SD me (only)	Indicates four leve emory ca storage m 8 single-	s the battery remaining and the radio-wave strength, in the les, of the wirelessly connected modules  rd or USB drive (user-selectable) nedia sold by Hioki are guaranteed for operation) byte characters
display (LR8450- Files Save destinations File names	SD m (only s Up to Autom Wavefi (user-s Numer	emory ca storage m 8 single-l natic num orm data (selectable) ical calcula	is the battery remaining and the radio-wave strength, in the less, of the wirelessly connected modules  rd or USB drive (user-selectable) redia sold by Hioki are guaranteed for operation) byte characters bering, dating, assignment of title comment (user-selectable) real-time saving): off, binary format, text format, or MDF format ation results (saved after recording): off or text format (user-selectable)
display (LR8450- Files Save destinations File names	SD m (only s Up to Autom Wavefi (user-s Numer When	emory ca storage m 8 single- natic num orm data (selectable) ical calculatext form	is the battery remaining and the radio-wave strength, in the lest, of the wirelessly connected modules  and or USB drive (user-selectable) media sold by Hioki are guaranteed for operation) byte characters bering, dating, assignment of title comment (user-selectable) real-time saving): off, binary format, text format, or MDF format stion results (saved after recording): off or text format (user-selectable) at is selected, choose whether to save all calculations in one
display (LR8450- Files Save destinations File names	SD m (only s Up to Autom Wavefi (user-s Numer When	emory ca storage m 8 single- natic num orm data ( selectable) ical calculat text form to save e	is the battery remaining and the radio-wave strength, in the lest, of the wirelessly connected modules  and or USB drive (user-selectable) media sold by Hioki are guaranteed for operation) byte characters bering, dating, assignment of title comment (user-selectable) real-time saving): off, binary format, text format, or MDF format lation results (saved after recording): off or text format (user-selectable) at is selected, choose whether to save all calculations in one ach calculation in its own file.  On/off (user-selectable) Off: system will stop saving data when SD memory card or
	SD me (only)  Up to Autom  Wavefi (user-s Numer When file or Delete save	Indicates four lever emory castorage n 8 single-inatic num orm data (selectable) ical calculatext form to save e and	is the battery remaining and the radio-wave strength, in the lest, of the wirelessly connected modules  and or USB drive (user-selectable) media sold by Hioki are guaranteed for operation) byte characters bering, dating, assignment of title comment (user-selectable) real-time saving): off, binary format, text format, or MDF format ation results (saved after recording): off or text format (user-selectable) ation results (saved after recording): off or text format (user-selectable) ation results (saved after recording): off or text format (user-selectable) and calculation in its own file.  On/off (user-selectable) Off: system will stop saving data when SD memory card or USB drive starts to run out of available space. On: when SD memory card or USB drive starts to run out of available space, system will delete oldest waveform file (binary, text, or MDF) and then continue saving data.
display (LR8450- Files Save destinations File names	SD me (only)  Up to Autom  Wavefr (user-s Numer When file or Delete save	Indicates four level emory ca storage n 8 single-Inatic num orm data (selectable) ical calculatext form to save e and	is the battery remaining and the radio-wave strength, in the lest, of the wirelessly connected modules  and or USB drive (user-selectable) media sold by Hioki are guaranteed for operation) byte characters bering, dating, assignment of title comment (user-selectable) real-time saving): off, binary format, text format, or MDF format ation results (saved after recording): off or text format (user-selectable) ation results (saved after recording): off or text format (user-selectable) ati is selected, choose whether to save all calculations in one ach calculation in its own file.  On/off (user-selectable) Off: system will stop saving data when SD memory card or USB drive starts to run out of available space. On: when SD memory card or USB drive starts to run out of available space, system will delete oldest waveform file (binary, text, or MDF) and then continue saving data.  No segmentation, 1 day, 1 week, or 1 month (user-selectable)
display (LR8450- Files Save destinations File names	SD me (only)  Up to Autom  Wavefr (user-s Numer When file or Delete save	Indicates four lever emory castorage n 8 single-inatic num orm data (selectable) ical calculatext form to save e and	is the battery remaining and the radio-wave strength, in the lest, of the wirelessly connected modules  and or USB drive (user-selectable) and asold by Hioki are guaranteed for operation) byte characters bering, dating, assignment of title comment (user-selectable) real-time saving): off, binary format, text format, or MDF format stion results (saved after recording): off or text format (user-selectable) at is selected, choose whether to save all calculations in one each calculation in its own file.  On/off (user-selectable) Off: system will stop saving data when SD memory card or USB drive starts to run out of available space. On: when SD memory card or USB drive starts to run out of available space, system will delete oldest waveform file (binary, text, or MDF) and then continue saving data.  No segmentation, 1 day, 1 week, or 1 month (user-selectable) Disabled, enabled, or timed (user-selectable) Disabled: data for each recording session is saved in its own file. Enabled: data for each set period of time is saved in its own file, starting with the start of measurement.
display (LR8450- Files Save destinations File names	SD me (only)  Up to Autom  Wavefr (user-s Numer When file or Delete save	Indicates four level emory ca storage n 8 single-Inatic num orm data (selectable) ical calculatext form to save e and	is the battery remaining and the radio-wave strength, in the lest, of the wirelessly connected modules  and or USB drive (user-selectable) and a sold by Hioki are guaranteed for operation) byte characters bering, dating, assignment of title comment (user-selectable) real-time saving): off, binary format, text format, or MDF format stion results (saved after recording): off or text format (user-selectable) at is selected, choose whether to save all calculations in one each calculation in its own file.  On/off (user-selectable) Off: system will stop saving data when SD memory card or USB drive starts to run out of available space. On: when SD memory card or USB drive starts to run out of available space, system will delete oldest waveform file (binary, text, or MDF) and then continue saving data.  No segmentation, 1 day, 1 week, or 1 month (user-selectable) Disabled, enabled, or timed (user-selectable) Disabled: data for each set period of time is saved in its own file, starting with the start of measurement. Segmentation time: day, hour, or minute (user-selectable) Timed: data will be segmented at intervals of the segment time based on the previously set reference time and saved in separate files.
display (LR8450- Files Save destinations File names	SD m (only s) Up to Auton Wavef (user-s Numer file or Delete save	Indicates four level emory castorage n 8 single-latic num orm data (selectable ical calculatext form to save e and	is the battery remaining and the radio-wave strength, in the lest, of the wirelessly connected modules  and or USB drive (user-selectable) the dia sold by Hioki are guaranteed for operation) object characters bering, dating, assignment of title comment (user-selectable) real-time saving): off, binary format, text format, or MDF format stion results (saved after recording): off or text format (user-selectable) at is selected, choose whether to save all calculations in one ach calculation in its own file.  On/off (user-selectable)  Off: system will stop saving data when SD memory card or USB drive starts to run out of available space.  On: when SD memory card or USB drive starts to run out of available space, system will delete oldest waveform file (binary, text, or MDF) and then continue saving data.  No segmentation, 1 day, 1 week, or 1 month (user-selectable)  Disabled: data for each recording session is saved in its own file.  Enabled: data for each set period of time is saved in its own file, starting with the start of measurement.  Segmentation time: day, hour, or minute (user-selectable)  Timed: data will be segmented at intervals of the segment time based on the previously set reference time and saved in separate files.  Split time: 1 min, 2 min, 5 min, 10 min, 15 min, 20 min, 30 min, 1 h, 2 h, 3 h, 4 h, 6 h, 8 h, 12 h, 1 d
display (LR8450- Files Save destinations File names	SD mi (only support of the state of the stat	Indicates four level emory ca storage m 8 single-latic num orm data (selectable ical calculate text form to save e e and example of the sample	is the battery remaining and the radio-wave strength, in the list, of the wirelessly connected modules  rd or USB drive (user-selectable) nedia sold by Hioki are guaranteed for operation)  oyte characters bering, dating, assignment of title comment (user-selectable) real-time saving): off, binary format, text format, or MDF format strong results (saved after recording): off or text format (user-selectable) at is selected, choose whether to save all calculations in one ach calculation in its own file.  On/off (user-selectable) Off: system will stop saving data when SD memory card or USB drive starts to run out of available space. On: when SD memory card or USB drive starts to run out of available space, system will delete oldest waveform file (binary, text, or MDF) and then continue saving data.  No segmentation, 1 day, 1 week, or 1 month (user-selectable) Disabled; data for each recording session is saved in its own file, starting with the start of measurement.  Segmentation time: day, hour, or minute (user-selectable) Timed: data will be segmented at intervals of the segment time based on the previously set reference time and saved in separate files.  Reference time: set in hours and minutes. Split time: 1 min, 2 min, 5 min, 10 min, 15 min, 20 min, 30 min, 1h, 2 h, 3 h, 4 h, 6 h, 8 h, 12 h, 1 d  External media can be ejected during real-time saving by activating a button on the screen and confirming a message.
display (LR8450- Files Save destinations File names	SD mi (only support of the state of the stat	Indicates four leve emory ca storage n 8 single-inatic num orm data (selectable) ical calcula text form to save e e and Splitting	is the battery remaining and the radio-wave strength, in the lest, of the wirelessly connected modules  and or USB drive (user-selectable) and as sold by Hioki are guaranteed for operation)  byte characters  bering, dating, assignment of title comment (user-selectable) real-time saving): off, binary format, text format, or MDF format atton results (saved after recording): off or text format (user-selectable) at is selected, choose whether to save all calculations in one each calculation in its own file.  On/off (user-selectable)  Off: system will stop saving data when SD memory card or USB drive starts to run out of available space.  On: when SD memory card or USB drive starts to run out of available space, system will delete oldest waveform file (binary, text, or MDF) and then continue saving data.  No segmentation, 1 day, 1 week, or 1 month (user-selectable)  Disabled: data for each recording session is saved in its own file.  Enabled: data for each set period of time is saved in its own file, starting with the start of measurement.  Segmentation time: day, hour, or minute (user-selectable)  Timed: data will be segmented at intervals of the segment time based on the previously set reference time and saved in separate files.  Reference time: set in hours and minutes.  Split time: 1 min, 2 min, 5 min, 10 min, 15 min, 20 min, 30 min, 1 h, 2 h, 3 h, 4 h, 6 h, 8 h, 12 h, 1 d  External media can be ejected during real-time saving by
display (LR8450- Files Save destinations File names	SD m (only)  SD m (only)  Up to Control Wavefi (user-s-when file or Delete save  Folder  File sp  Extern eject (factor or loat a in tono o	Indicates four level emory castorage n 8 single-latic num orm data (selectable ical calculatext form to save e and Splitting objects) Splitting order-latic num orm data (selectable ical calculatext form to save e and selectable ical calculatext form to save e and selectable ical calculatext form to save e and selectable ical calculates of the s	is the battery remaining and the radio-wave strength, in the els, of the wirelessly connected modules  rd or USB drive (user-selectable) media sold by Hioki are guaranteed for operation) byte characters bering, dating, assignment of title comment (user-selectable) real-time saving): off, binary format, text format, or MDF format stion results (saved after recording): off or text format (user-selectable) at is selected, choose whether to save all calculations in one each calculation in its own file.  On/off (user-selectable) Off: system will stop saving data when SD memory card or USB drive starts to run out of available space. On: when SD memory card or USB drive starts to run out of available space, system will delete oldest waveform file (binary, text, or MDF) and then continue saving data.  No segmentation, 1 day, 1 week, or 1 month (user-selectable) Disabled, enabled, or timed (user-selectable) Disabled: data for each recording session is saved in its own file. Enabled: data for each set period of time is saved in its own file, starting with the start of measurement. Segmentation time: day, hour, or minute (user-selectable) Timed: data will be segmented at intervals of the segment time based on the previously set reference time and saved in separate files. Reference time: set in hours and minutes. Split time: 1 min, 2 min, 5 min, 10 min, 15 min, 20 min, 30 min, 1 h, 2 h, 3 h, 4 h, 6 h, 8 h, 12 h, 1 d  External media can be ejected during real-time saving by activating a button on the screen and confirming a message.
display (LR8450- Files Save destinations File names Auto saving	SD m (only)  SD m (only)  Up to Vavefi (user-s-Numer When file or Delete save  Extern eject (for or o	Indicates four level emory castorage in 8 single-latic num orm data (selectable) icidad latic text form to save estand es	is the battery remaining and the radio-wave strength, in the lest, of the wirelessly connected modules  and or USB drive (user-selectable) the dia sold by Hioki are guaranteed for operation) object characters being, dating, assignment of title comment (user-selectable) real-time saving): off, binary format, text format, or MDF format stion results (saved after recording): off or text format (user-selectable) at is selected, choose whether to save all calculations in one in ach calculation in its own file.  On/off (user-selectable)  Off: system will stop saving data when SD memory card or USB drive starts to run out of available space.  On: when SD memory card or USB drive starts to run out of available space, system will delete oldest waveform file (binary, text, or MDF) and then continue saving data.  No segmentation, 1 day, 1 week, or 1 month (user-selectable)  Disabled: data for each recording session is saved in its own file, starting with the start of measurement.  Segmentation time: day, hour, or minute (user-selectable)  Timed: data will be segmented at intervals of the segment time based on the previously set reference time and saved in separate files.  Reference time: set in hours and minutes.  Split time: 1 min, 2 min, 5 min, 10 min, 15 min, 20 min, 30 min, 1 h, 2 h, 3 h, 4 h, 6 h, 8 h, 12 h, 1 d  External media can be ejected during real-time saving by activating a button on the screen and confirming a message.  Yes (valid only when Z1007 Battery Pack is installed)  If remaining battery life declines during real-time saving, system will close file and stop saving data (although measurement operation will continue).  when SAVE key is pressed.

Surement Segmentation time: set DD:HH:MM format Timed: calculations will be made at intervals of the segment time base on the previously set reference time. Reference time: set in hours and minutes. Split time: 1 min; 2 min; 5 min; 10 min; 15 min; 20 min; 30 min; 1 h, 2 min; 5 min; 10 min; 15 min; 20 min; 30 min; 1 h, 2 min; 15 min; 10 min; 15 min; 20 min; 30 min; 1 h, 2 min; 15 min; 20 min; 30 min; 1 h, 2 min; 15 min; 20 min; 30 min; 1 h, 2 min; 15 min; 20 min; 30 min; 1 h, 2 min; 15 min; 20 min; 30 min; 1 h, 2 min; 20 min; 30 min; 30 min; 1 h, 2 min; 30 min; 30 min; 30 min; 1 h, 2 min; 30 min;					
Calculations  Calculation  Time split calculations performed for all data during recording aggregation according to the calculations performed for all data in the internal buffer memory, or for data acciduations performed for all data in the internal buffer memory, or for data acciduations performed for all data in the internal buffer memory, or for data acciduations performed for all data in the internal buffer memory, or for data acciduations performed for all data during recording acciduations and acciduations and acciduations with the mass at the recording acciduations and acciduations and acciduations with the mass at the recording accidence and accidence accidence accidence and accidence acciden			1-		
Number of   Up to 10 calculations simultaneously coloidions   Calculation   Calculat					
calculations  Catalogy of the content of the conten					
value of the content					
large After recording has stopped:  Time spit Disabled: calculations performed for all data unit internal buffer memory, or for da in a calculation range specified by the APB cursors (on the vertical axis) in a calculation range specified by the APB cursors (on the vertical axis) bisabled: data for each segment of time, starting with the start of measurement in segment of time, starting with the start of measurement in segment of time, starting with the start of measurement in segment of time, starting with the start of measurement in segment of time, starting with the start of measurement in segment of time, starting with the start of measurement in segment of time, starting with the start of measurement in segment of time, starting with the start of measurement in timed: calculations will be made at intervals of the segment time base on Reference time, set in hours and minutes. Spit time: 1 min., 2 min., 5 min., 10 min., 15 min., 20 min., 30 min., 1 h., 2 3. h., 4 h., 6 h., 8 h., 12 h., 1 d.  Wewelom:  Calculation:  Calculation:  Calculation:  Arithmetic operations among channels  Moving average, simple average, aggregation, and integration of any channels (Withough W30). (Calculations are performed at the same time as measurement.)  Trigger sources  Trigger method  Digital comparison method  Start, stop, or start & stop  Trigger sources  Analog, pusce, logic, waveform calculations, CAN (max. 100)  Trigger types  Analog, pusce, logic, waveform calculations, CAN (max. 100)  Trigger response time  Level triggers: trigger activated by arising or falling experiments of 1/0/X match (where "X" indicates either)  Trigger response time  Logic, CAN  Trigger activated by rising or falling edge at set level in external ingersors time  Trigger activated by rising or falling edge at set level in external ingersors time.  When using plug-in units:  (recording interval or data refresh interval of the separately for ALM1 to ALM8  System will output an alarm when any of the following conditions are satisficated the process of	tions		time, minimum usage ratio*2, *1: total, posit	n value, minimum value time, integration*1, aggregation*1, on time*2, off time*2, on count*2 ive, negative, or absolute value (user-selectable)	
calculation   Sabelled: calculations performed for all data during recording   Enabled: data for each segment of time, starting with the start of measurement.			calculations p After recording calculations p	performed for all data during recording ghas stopped: erformed for all data in the internal buffer memory, or for data	
calculations   content   Moving average, simple average, aggregation, and integration of any channel Calculated values are recorded as data for calculation channels (Windows) (Calculations are performed at the same time as measur ment Values cannot be recalculated after measurement.)  Trigger method   Digital comparison method   Start, stop, or start & stop   Start, stop, or start & stop   Trigger conditions   Start, stop, or start & stop   Analog, candidated   Calculations   Calcu		calcula-	Disabled: calculations performed for all data during recording Enabled: data for each segment of time, starting with the start of mea- surement Segmentation time: set DD:HH:MM format Timed: calculations will be made at intervals of the segment time based on the previously set reference time. Reference time: set in hours and minutes. Split time: 1 min, 2 min, 5 min, 10 min, 15 min, 20 min, 30 min, 1 h, 2 h,		
Trigger timing Start, stop, or start & stop Trigger conditions AnlO/CR operation performed on trigger source, interval trigger, or external trigger When triggers are disabled, free run Trigger sources Analog, pulse, logic, waveform calculations, CAN (max. 100) Trigger types Analog, pulse, logic, waveform calculations, CAN (max. 100) Trigger types Analog, pulse, logic, waveform calculations, CAN (max. 100) Analog, pulse, logic, waveform calculations, CAN (max. 100) Trigger types Analog, pulse, logic, waveform calculations, CAN (max. 100) Trigger activated by driggers: trigger activated by arising or falling edge at a set level Window then value enters area Logic, CAN Trigger activated when patterns of 1/0/X match (whe "X" indicates either) Interval triggers Trigger activated by rising or falling edge at set level in external inp signal. Rising/falling (user-selectable) When using piller in units: (recording interval or data refresh interval, whichever is longer) × 2 + wireless response time** analog gresponse time** When using wireless units (LR8450-01 only): (recording interval or data refresh interval, whichever is longer) × 2 + wireless response time** analog response time**  "1* depends on filter settings (U8554 with a data refresh interval of 5 ms and low-pass filter or 120 Hz).  "2: when the radio-wave state is in good condition, 1s.  Analog			Moving average Calculated va through W30).	, simple average, aggregation, and integration of any channel lues are recorded as data for calculation channels (W1 (Calculations are performed at the same time as measure-	
Trigger timing Start, stop, or start & stop Trigger conditions AnlO/CR operation performed on trigger source, interval trigger, or external trigger When triggers are disabled, free run Trigger sources Analog, pulse, logic, waveform calculations, CAN (max. 100) Trigger types Analog, pulse, logic, waveform calculations, CAN (max. 100) Trigger types Analog, pulse, logic, waveform calculations, CAN (max. 100) Analog, pulse, logic, waveform calculations, CAN (max. 100) Trigger types Analog, pulse, logic, waveform calculations, CAN (max. 100) Trigger activated by driggers: trigger activated by arising or falling edge at a set level Window then value enters area Logic, CAN Trigger activated when patterns of 1/0/X match (whe "X" indicates either) Interval triggers Trigger activated by rising or falling edge at set level in external inp signal. Rising/falling (user-selectable) When using piller in units: (recording interval or data refresh interval, whichever is longer) × 2 + wireless response time** analog gresponse time** When using wireless units (LR8450-01 only): (recording interval or data refresh interval, whichever is longer) × 2 + wireless response time** analog response time**  "1* depends on filter settings (U8554 with a data refresh interval of 5 ms and low-pass filter or 120 Hz).  "2: when the radio-wave state is in good condition, 1s.  Analog	Triggere				
Trigger conditions AND/OR operation performed on trigger source, interval trigger, or external trigger when triggers are disabled, free run Analog, pulse, logic, waveform calculations, CAN (max. 100) Analog, pulse, logic, waveform calculations, CAN (max. 100) Analog, pulse, waveform calculations, CAN (max. 100) Trigger activated when patterns of 1/0/X match (whe "X" indicates either) Analog are calculated by rising or falling edge at set level in external inp signal. Rising/falling (user-selectable) When using pilug-in units: (recording interval or data refresh interval, whichever is longer) ×2+ tims + anal response time" analog and the response time" analog (120 Hz).  Trigger level response time" analog analog are sponse time, whichever is longer) ×2+ wireless response time" analog			Digital compa	arison method	
External trigger   When triggers are disabled, free run			-		
Trigger types  Analog, pulse, waveform calculations, CAN  External triggers  Trigger activated by rising or falling edge at a set level  Window triggers: it is set by trigger level upper limit and lower limit. Trigger activated when value leaves area or when value enters area  Logic, CAN  Trigger activated when patterns of 1/0/X match (whe "X" indicates either)  Trigger activated by rising or falling edge at set level in external inp signal. Rising/falling (user-selectable)  Trigger response time*  When using plug-in units: (ecording interval or data refresh interval, whichever is longer) × 2 + 1 ms + anal response time*  When using wireless units (LR8450-01 only): (recording interval or data refresh time, whichever is longer) × 2 + wireless response time*  "1" depends on filter settings (LB654 with a data refresh interval of 5 ms and low-pass filter of 120 Hz).  "2" when the radio-wave state is in good condition, 1s.  Trigger level resolution  Pre-triggers  Set day/hours/minutes/seconds.  Can be set during real-time saving.  Alarms  Alarm conditions  Set separately for ALM1 to ALM8 System will output an alarm when any of the following conditions are satisfies. Analog, pulse, logic, waveform calculations, CAN (max. 100)  Alarm sources  Alarm sources  Alarm output when a wireless communication error with a wireless module is detected module is detected module is detected on the instrument or a wireless communication disruption continues for minutes.  Alarm output when a malarm upon a communication disruption continues for minutes.  Alarm output when a arierless module.  Thermocouple  Jalarm output when a malarm if a communication disruption continues for minutes.  Alarm output when a malarm if a communication disruption continues for minutes.  Alarm output when a malarm if a communication disruption continues for minutes.  Alarm output when a malarm when value leaves area of when value enters area.  Slope: set level and time.  The system will output an alarm when the rate of change (level per unit time) continue			external triggers	er s are disabled, free run	
pulse, waveform calculations, CAN waveform Calculations, CAN   Trigger activated when value leaves area or when value enters area   Logic, CAN   Trigger activated when patterns of 1/0/X match (when "X" indicates either)    Interval triggers   Trigger activated by rising or falling edge at set level in external inp signal. Rising/falling (user-selectable)    Trigger response time   When using plug-in units: (recording interval or data refresh interval, whichever is longer) × 2 + 1 ms + anal response time   When using wireless units (LR8450-01 only): (recording interval or data refresh time, whichever is longer) × 2 + wireles response time   "1: depends on filter settings (U8564 with a data refresh interval of 5 ms and low-pass filter of 120 Hz).   "2: when the radio-wave state is in good condition, 1s.    Trigger level   Analog   0.1% f.s. (f.s. = 10 divisions)   Pulse   Count = 1c, rotational speed = 1/n (where n = pulse count per rotation setting)    Pre-triggers   Set day/hours/minutes/seconds.   Can be set during real-time saving.    Alarms   Alarm conditions   Set separately for ALM1 to ALM8   System will output an alarm when any of the following conditions are satisfie   AND/CR operation performed on alarm sources   Low battery   Thermocouple burnout   Wirreless error (LR8450-01 only)   Alarm sources   Analog, pulse, logic, waveform calculations, CAN (max. 100)   Alarm output when a wireless communication disruption   Amoutput when a wireless module.   Alarm output when a wireless module.   Level: system will output an alarm when value detected for the instrument or a wireless module.   Level: system will output an alarm when value leaves area of when value enters area   Slope: set level and time.   The system will output an alarm when the rate of change (level per unit time) continues to exceed the specified change rate udring the set time interval.   Logic   System will output an alarm when patterns of 1/0/X match (where "X" indicates either)   Apply a filter to results of AND/CR operations performed on					
Interval triggers  Figger activated for set recording interval after setting days/hours/minutes/seconds  External triggers  Trigger activated by rising or falling edge at set level in external inp signal. Rising/falling (user-selectable)  Trigger response time using plug-in units: (recording interval or data refresh interval, whichever is longer) × 2 + ms + anal response time "  When using wireless units (LR8450-01 only): (recording interval or data refresh interval, whichever is longer) × 2 + wireles response time " "1: depends on filter settings (U8554 with a data refresh interval of 5 ms and low-pass filter of 120 Hz).  Trigger level resolution  Pulse  Count = 1c, rotational speed = 1/n (where n = pulse count per rotation setting)  Pre-triggers  Set day/hours/minutes/seconds. Can be set during real-time saving.  Alarms  Alarm conditions  Set separately for ALM1 to ALM8 System will output an alarm when any of the following conditions are satisfic AND/OR operation performed on alarm sources  Low battery  * Thermocouple burnout  * Wireless error (LR8450-01 only)  Alarm sources  Alarm output when a wireless communication error with a wireless module is detected Offinow/3 min (user-selectable) Now: outputs an alarm upon a communication disruption 3 min: outputs an alarm upon a communication disruption 2 minutes.  Low remaining battery life  Alarm output when a thermocouple burnout occurs (when Tc burnout detection setting is enabled)  Thermocouple  Alarm output when a thermocouple burnout occurs (when Tc burnout detection setting is enabled)  Alarm output when a thermocouple burnout occurs (when Tc burnout detection setting is enabled)  Thermocouple  Alarm output when a thermocouple burnout occurs (when Tc burnout detection setting is enabled)  Alarm output when a thermocouple burnout occurs (when Tc burnout detection setting is enabled)  CAN  Alarm set level and time in the value leaves area of change (level per unit time) continues to exceed the specified change rate during the set time interval.  Logic  System	mgger ty	ρCG	pulse, waveform calculations,	edge at a set level Window triggers: it is set by trigger level upper limit and lower limit. Trigger activated when value leaves	
External triggers ignal. Rising/falling (user-selectable)  Trigger response time  When using plug-in units: (recording interval or data refresh interval, whichever is longer) × 2 + 1 ms + anal response time  When using plug-in units: (recording interval or data refresh time, whichever is longer) × 2 + 1 ms + anal response time*  When using wireless units (LR8450-01 only): (recording interval or data refresh time, whichever is longer) × 2 + wireles response time*  "1" depends on filter settings (U8554 with a data refresh interval of 5 ms and low-pass filter of 120 Hz).  "2: when the radio-wave state is in good condition, 1s.  Trigger level resolution  Analog   0.1% f.s. (f.s. = 10 divisions)  Pulse   Count = 1c, rotational speed = 1/n (where n = pulse count per rotation setting)  Pre-triggers  Set day/hours/minutes/seconds. Can be set during real-time saving.  Alarm conditions  Set separately for ALM1 to ALM8 System will output an alarm when any of the following conditions are satisfiest AND/OR operation performed on alarm sources  - Low battery - Thermocouple burnout - Wireless error (LR8450-01 only)  Alarm output when a wireless communication error with a wireless module is detected Off/now/3 min (user-selectable) Now: outputs an alarm upon a communication disruption 2 minutes.  Low remaining   Alarm output when low remaining battery life is detected for the instrument or a wireless module.  Topes of alarms  Analog, pulse, waveform calculations disruption continues for minutes.  Low remaining   Alarm output when low remaining battery life is detected for the instrument or a wireless module.  Types of alarms  Analog, pulse, waveform calculation of surption continues for minutes.  Low remaining   Alarm output when low remaining battery life is detected for the instrument or a wireless module.  Loy   Analog, pulse, waveform calculation of the pulse of the puls			Logic, CAN	Trigger activated when patterns of 1/0/X match (where "X" indicates either)	
Signal Rising/falling (user-selectable)	Interval tri	iggers			
(recording inferval or data refresh interval, whichever is longer) × 2 + 1 ms + anal response time*¹  When using wireless units (LR8450-01 only): (recording interval or data refresh time, whichever is longer) × 2 + wireles response time*² + analog response time*¹  *1' depends on filter settings (U8554 with a data refresh interval of 5 ms and low-pass filter of 120 Hz).  *2' when the radio-wave state is in good condition, 1s.  Trigger level resolution  Pulse  Count = 1c, rotational speed = 1/n (where n = pulse count per rotation setting)  Pre-triggers  Set day/hours/minutes/seconds.  Can be set during real-time saving.  Alarms  Alarms  Alarm conditions  Set separately for ALM1 to ALM8 System will output an alarm when any of the following conditions are satisfied and a harm sources  AND/OR operation performed on alarm sources  • Low battery • Thermocouple burnout • Wireless error (LR8450-01 only)  Alarm sources  Alarm output when a wireless communication error with a wireless module is detected Off/now/3 min (user-selectable) Now: outputs an alarm upon a communication disruption continues for minutes.  Low remaining battery life  Thermocouple burnout  Alarm output when low remaining battery life is detected for the instrument or a wireless module.  Alarm output when a thermocouple burnout occurs (when Tc burnout detection setting is enabled)  Types of alarms  Analog, pulse, waveform  calculation, CAN  Analog, pulse, waveform will output an alarm following a rising of falling edge at set level  Window: set upper limit and lower limit System will output an alarm when the rate of change (level per unit time) continues to exceed the specified change rate during the set time interval.  Logic System will output an alarm when patterns of 1/0/X match (where "X" indicates either)  Apply a filter to results of AND/OR operations performed on alarm sources. Set based on sample count (off, 2 to 1000).	External t	riggers	Trigger activated by rising or falling edge at set level in external input signal. Rising/falling (user-selectable)		
Pulse Count = 1c, rotational speed = 1/n (where n = pulse count per rotation setting)  Pre-triggers Set day/hours/minutes/seconds. Can be set during real-time saving.  Alarms  Alarm conditions Set separately for ALM1 to ALM8 System will output an alarm when any of the following conditions are satisfies. AND/OR operation performed on alarm sources. Low battery Thermocouple burnout Wireless error (LR8450-01 only)  Alarm sources Analog, pulse, logic, waveform calculations, CAN (max. 100)  Wireless error (LR8450-01 only)  Alarm output when a wireless communication error with a wireless module is detected Off/now/3 min (user-selectable) Now: outputs an alarm if a communication disruption 3 min: outputs an alarm if a communication disruption continues for minutes.  Low remaining battery life  Thermocouple burnout when low remaining battery life is detected for the instrument or a wireless module.  Alarm output when low remaining battery life is detected for the instrument or a wireless module.  Alarm output when low remaining battery life is detected for the instrument or a wireless module.  Alarm output when low remaining battery life is detected for the instrument or a wireless module.  Alarm output when low remaining battery life is detected for the instrument or a wireless module.  Window: set level will output an alarm when Tc burnout detection setting is enabled)  Types of alarms  Analog, pulse, Window: set upper limit and lower limit System will output an alarm when value leaves area of the system will output an alarm when the rate of change (level per unit time) continues to exceed the specified change rate during the set time interval.  Logic System will output an alarm when patterns of 1/0/X match (where "X" indicates either)  Apply a filter to results of AND/OR operations performed on alarm sources. Set based on sample count (off, 2 to 1000).			(recording interval or data refresh interval, whichever is longer) ×2+1 ms+analog response time*1 When using wireless units (LR8450-01 only): (recording interval or data refresh time, whichever is longer) ×2+wireless response time*2+ analog response time*1 *1: depends on filter settings (U8554 with a data refresh interval of 5 ms and low-pass filter of 120 Hz).		
Pre-triggers  Set day/hours/minutes/seconds. Can be set during real-time saving.  Alarms  Alarm conditions  Set separately for ALM1 to ALM8 System will output an alarm when any of the following conditions are satisfie • AND/OR operation performed on alarm sources • Low battery • Thermocouple burnout • Wireless error (LR8450-01 only)  Alarm output when a wireless communication error with a wireless module is detected Off/now/3 min (user-selectable) Now: outputs an alarm upon a communication disruption 3 min: outputs an alarm upon a communication disruption continues for minutes.  Low remaining battery life  Thermocouple burnout  Alarm output when low remaining battery life is detected for the instrument or a wireless module.  Alarm output when a thermocouple burnout occurs (when Tc burnout detection setting is enabled)  Types of alarms  Analog, pulse, waveform calculation, CAN  Analog, pulse, waveform calculation, CAN  CAN  Analog, pulse, logic, waveform calculation, can alarm when value leaves area of the calculation, can alarm when value leaves area of the calculation, can alarm when value leaves area of the calculation, can alarm when value leaves area of the calculation, can alarm when value leaves area of the calculation, can alarm when value leaves area of the calculation, can alarm when value leaves area of the calculation, can alarm when value leaves area of the calculation, can alarm when value leaves area of the calculation, can alarm when value leaves area of the calculation, can alarm when value leaves area of the calculation, can alarm when value leaves area of the calculation, can al					
Alarms  Alarm conditions  Set separately for ALM1 to ALM8 System will output an alarm when any of the following conditions are satisfie  • AND/OR operation performed on alarm sources • Low battery • Thermocouple burnout • Wireless error (LR8450-01 only)  Alarm sources  Analog, pulse, logic, waveform calculations, CAN (max. 100)  Alarm output when a wireless communication error with a wireless module is detected Off/now/3 min (user-selectable) Now: outputs an alarm upon a communication disruption 3 min: outputs an alarm upon a communication disruption continues for minutes.  Low remaining battery life  Alarm output when low remaining battery life is detected for the instrument or a wireless module.  Thermocouple burnout  Alarm output when a thermocouple burnout occurs (when Tc burnout detection setting is enabled)  Types of alarms  Analog, pulse, waveform calculation, CAN  Analog, pulse, logic, waveform will output an alarm following a rising of falling edge at set level  Window: set upper limit and lower limit System will output an alarm when value leaves area of the system will output an alarm when the rate of change (level per unit time) continues to exceed the specified change rate during the set time interval.  Logic  System will output an alarm when patterns of 1/0/X match (where "X" indicates either)  Apply a filter to results of AND/OR operations performed on alarm sources. Set based on sample count (off, 2 to 1000).				count per rotation setting)	
Alarm conditions  Set separately for ALM1 to ALM8 System will output an alarm when any of the following conditions are satisfie  AND/OR operation performed on alarm sources  Low battery  • Thermocouple burnout  • Wireless error (LR8450-01 only)  Alarm output when a wireless communication error with a wireless module is detected Off/now/3 min (user-selectable) Now: outputs an alarm upon a communications disruption 3 min: outputs an alarm upon a communication disruption continues for minutes.  Low remaining battery life  Alarm output when low remaining battery life is detected for the instrument or a wireless module.  Thermocouple burnout  Alarm output when a thermocouple burnout occurs (when Tc burnout detection setting is enabled)  Types of alarms  Analog, pulse, waveform calculation, CAN  CAN  Level: system will output an alarm following a rising of falling edge at set level  Window: set upper limit and lower limit system will output an alarm when value leaves area of when value enters area  Slope: set level and time. The system will output an alarm when the rate of change (level per unit time) continues to exceed the specified change rate during the set time interval.  Logic System will output an alarm when patterns of 1/0/X match (where "X" indicates either)  Apply a filter to results of AND/OR operations performed on alarm sources. Set based on sample count (off, 2 to 1000).	Pre-trigge	ers			
Alarm conditions  Set separately for ALM1 to ALM8 System will output an alarm when any of the following conditions are satisfie  AND/OR operation performed on alarm sources  Low battery  • Thermocouple burnout  • Wireless error (LR8450-01 only)  Alarm output when a wireless communication error with a wireless module is detected Off/now/3 min (user-selectable) Now: outputs an alarm upon a communications disruption 3 min: outputs an alarm upon a communication disruption continues for minutes.  Low remaining battery life  Alarm output when low remaining battery life is detected for the instrument or a wireless module.  Thermocouple burnout  Alarm output when a thermocouple burnout occurs (when Tc burnout detection setting is enabled)  Types of alarms  Analog, pulse, waveform calculation, CAN  CAN  Level: system will output an alarm following a rising of falling edge at set level  Window: set upper limit and lower limit system will output an alarm when value leaves area of when value enters area  Slope: set level and time. The system will output an alarm when the rate of change (level per unit time) continues to exceed the specified change rate during the set time interval.  Logic System will output an alarm when patterns of 1/0/X match (where "X" indicates either)  Apply a filter to results of AND/OR operations performed on alarm sources. Set based on sample count (off, 2 to 1000).	Alarms				
Wireless error (LR8450-01 only)  Alarm output when a wireless communication error with a wireless module is detected Off/now/3 min (user-selectable) Now: outputs an alarm upon a communications disruption 3 min: outputs an alarm if a communication disruption continues for minutes.  Low remaining battery life  Alarm output when low remaining battery life is detected for the instrument or a wireless module.  Alarm output when a thermocouple burnout occurs (when Tc burnout detection setting is enabled)  Types of alarms  Analog, pulse, waveform calculation, CAN  Window: set upper limit and lower limit System will output an alarm when value leaves area of when value enters area  Slope: set level and time. The system will output an alarm when the rate of change (level per unit time) continues to exceed the specified change rate during the set time interval.  Logic System will output an alarm when patterns of 1/0/X match (where "X" indicates either)  Apply a filter to results of AND/OR operations performed on alarm sources. Set based on sample count (off, 2 to 1000).			System will out  AND/OR op  Low battery  Thermocoup	put an alarm when any of the following conditions are satisfied: eration performed on alarm sources ole burnout	
(LR8450-01 only)    Module is detected Off/now/3 min (user-selectable)					
Thermocouple burnout  Alarm output when a thermocouple burnout occurs (when Tc burnout detection setting is enabled)  Analog, pulse, waveform calculation, CAN  Alarm filter  Apply a filter to results of AND/OR operations performed on alarm sources. Set based on sample count (off, 2 to 1000).			module is detected Off/now/3 min (user-selectable) Now: outputs an alarm upon a communications disruption 3 min: outputs an alarm if a communication disruption continues for 3		
Durnout detection setting is enabled)  Types of alarms Analog, pulse, waveform calculation, CAN Window: set upper limit and lower limit System will output an alarm when value leaves area of when value enters area Slope: set level and time. The system will output an alarm when the rate of change (level per unit time) continues to exceed the specified change rate during the set time interval.  Logic System will output an alarm when patterns of 1/0/X match (where "X" indicates either)  Apply a filter to results of AND/OR operations performed on alarm sources. Set based on sample count (off, 2 to 1000).			Alarm output when low remaining battery life is detected for the		
pulse, waveform calculation, CAN  falling edge at set level  Window: set upper limit and lower limit System will output an alarm when value leaves area of when value enters area  Slope: set level and time. The system will output an alarm when the rate of change (level per unit time) continues to exceed the specified change rate during the set time interval.  Logic  System will output an alarm when patterns of 1/0/X match (where "X" indicates either)  Alarm filter  Apply a filter to results of AND/OR operations performed on alarm sources. Set based on sample count (off, 2 to 1000).	Thermocouple				
The system will output an alarm when the rate of change (level per unit time) continues to exceed the specified change rate during the set time interval.  Logic System will output an alarm when patterns of 1/0/X match (where "X" indicates either)  Alarm filter Apply a filter to results of AND/OR operations performed on alarm sources. Set based on sample count (off, 2 to 1000).	Types of alarms		pulse, waveform calculation,	Window: set upper limit and lower limit System will output an alarm when value leaves area or when value enters area	
Alarm filter Apply a filter to results of AND/OR operations performed on alarm sources. Set based on sample count (off, 2 to 1000).			Logic	The system will output an alarm when the rate of change (level per unit time) continues to exceed the specified change rate during the set time interval.  System will output an alarm when patterns of 1/0/X	
	Alarm filter		sources. Set	to results of AND/OR operations performed on alarm based on sample count (off, 2 to 1000).	

Alarm retention	On/Off (user-selectable) Clear alarms: when alarm retention is on, alarms will be cleared without stopping recording.
Alarm tone	On/Off (user-selectable)
Alarm output response time	When using plug-in modules: (recording interval or data refresh interval, whichever is longer)×2+1 ms+analog response time*1 When using wireless units (LR8450-01 only): (recording interval or data refresh interval, whichever is longer)×2+wireless response time*2+analog response time*1 *1: depending on filter settings (U8554 with a data refresh interval of 5 ms and low-pass filter of 120 Hz). *2: when the radio-wave state is in good condition, 1s.

Synchronous operation		
Instrument synchronization	Start/stop, triggers, and sampling are synchronized among multiple instruments (using the SYNC.OUT and SYNC.IN terminals).  Trigger synchronization time: Within (recording interval × 2) samples Can not be used with wireless modules	
Number of instruments that can be synchronized	5 (Up to four secondary instruments can operate in synchronization with one primary instrument)	
Recording interval	No limitations (can be set from 1 ms)	

No limitations (can be set from 1 ms)		
ılity		
Number of inputs	Up to 1000 inputs per measurement	
Search waveforms and display target location in center of waveform screen.		
Search conditions	Search by choosing level, window, maximum value, minimum value, local maximum value, or local minimum value.	
Search range	All data in internal buffer memory or data between A/B cursors (on vertical axis)	
Search targets	Analog, pulse, logic, waveform calculations	
Specify event m display position	nark, A/B cursor position, trigger point, or waveform to display that section in center of waveform screen.	
Cursor display	All channels or specified channels (user-selectable)	
Cursor movement	A, B, or simultaneous (user-selectable)	
Types of cursors	Vertical or horizontal (user-selectable)	
Scaling settings	s can be configured separately for each channel	
Enter titles and	channel-specific comments	
On/Off (user-se	electable)	
On/Off (user-se	electable)	
Up to five groups of setting conditions can be saved in the instrument's internal backup memory.		
or a USB drive ca	s saved in the instrument's memory or on an SD memory card an be automatically loaded when the instrument is powered on.	
an SD memory ca	g conditions stored in the instrument's memory as well as on ard and a USB drive, setting conditions have the following ument's memory, SD memory card, and USB drive.	
ing if user wishe	STOP key is pressed, system will display a message asks to start or stop measurement.  essage: enable/disable (user-selectable)	
	, ,	
,	s, LCD, ROM/RAM, LAN, media, and modules.	
Horizontal axis (time value) display can be set to time, date, or data point count. These are reflected in saved text data.		
	ent start and stop conditions. et start time and stop time (year, month, day, hour, and min.)	
nectivity trouble	e registration guide (LR8450-01 only), wireless con- eshooting guide (LR8450-01 only), connection diagram gage, external terminals), loading setting conditions	
50 Hz/60 Hz se	lection	
	Number of inputs Search waveform Search conditions Search targets Specify event in display position Cursor display Cursor display Cursor movement Types of cursors Scaling settings Enter titles and On/Off (user-se Can check key Horizontal axis point count. The Set measurems Specified time: s Wireless modul display (strain of	

lr	put	
Ρ	ulse/logic input	
Number of channels		8 channels (common GND, non-isolated) Exclusive setting for pulse/logic input for individual channels
	Terminal block	Push-button type terminal block
	Adaptive input format	Non-voltage contact, open collector (PNP open collector requires external resistor), or voltage input
	Max. input voltage	0 V to 42 V DC
	Input resistance	1.1 MΩ ±5%
	Detection level	2 levels (user-selectable) High: 1.0 V or greater; low: 0 to 0.5 V High: 4.0 V or greater; low: 0 to 1.5 V

# Pulse input

# Measurement range, resolution

	Rotational speed		Range	Maximum resolution	Measurable range
			1000 mega-pulse f.s.	1 pulse	0 to 1000 M pulse
			5000/n (r/s) f.s.	1/n (r/s)	0 to 5000/n (r/s)
			300,000/n (r/min) f.s.	1/n (r/min)	0 to 300,000/n (r/min)
			n: number of pulses per ro	otation (1 to 1000)	
Pulse input With period With		With filte	Iter off: 200 µs or greater (100 µs or greater during high and low interval) Iter on: 100 ms or greater (50 ms or greater during high and low interval)		
Slo	Slope Set ri		ng/falling for each channel.		
Me	eas. Mode	Integration (addition, instantaneous), rotational speed			
Ins		Instanta	: counts number of pulse ineous: counts number (integrated value is res	of pulses input with	in each recording

		r/s: counts number of input pulses during 1 s and calculates rotational speed. r/min: counts number of input pulses during 1 min and calculates rotational speed.
	Smoothing func.	Select value from 1 s to 60 s (valid only when set to rotational speed and r/min).
	Chatter pre- vention filter	Set to on/off for each channel
Logic input		
	Meas. Mode	Records 1 or 0 for each recording interval

# **Software Logger Utility specifications**

U8555 CAN Unit and	LR8535 Wireless CAN Unit are not supported.
Operating Environment	Windows7, Windows8, Windows10 (32 bit/64 bit) Windows11 (64 bit)
Overview	Control PC-connected logger to receive, display, and save measured waveform data sequentially. (Total recording samples is maximum 10 million data. Data exceeding this number will be segmented into separate measurement files while recording continues.) *Real-time measurement on the LR8450, LR8450-01 is possible with a recording interval of 10 ms or more. Max. number of analog CH: 600 CH
Function	Controllable loggers: 5 Data Collection System: 1 system Display Format:  • Waveforms (split time-axis display is possible)  • Numerical values (logging): numerical display can be enlarged  • Alarms  Above items can be displayed simultaneously Numerical value monitor Display: display in a separate window is possible.  Scroll: waveforms can be scrolled during measurement.
Data Collection	Settings: data collection settings of logger modlues can be configured Monitor function can be checked before measurement. Save: save settings from multiple devices supporting real-time measurement (LUS format) and measurement data (LUW format) as one file. Data save format: real-time data collection file (LUW format), transfer data in real-time or non-real-time to Microsoft Excel®, Excel® template can be specified  Event mark: recording during measurement is possible
Waveform Display	Supported files: waveform data file (LUW format, MEM format) Display format: waveforms (split time-axis display available), simulta- neous display of numerical values (logging) is available Maximum number of channels: 2,035 channels (measured) + 60 channels (waveform calculation) Waveform display sheets: waveform of each channel can be dis- played on any of the ten sheets Scroll: available Event mark recording: available Cursors: cursors A and B can be used to display voltage values at cursor positions. Screen capture: screen capture of waveform display is available
Data Conversion	Applicable files: waveform data file (LUW format, MEM format) Conversion section: all data, specified section Conversion format: CSV format (comma delimited, space delimited, tab delimited), transfer to Exce® sheet, LR5000 format (hrp2,hrp) Data thinning: simple thinning with any thinning number
Waveform Calculation	Calculation items: arithmetic operations Number of calculation channel: 60 channels
Numerical Calculations	Applicable data: waveform data file (LUW format, MEM format), real-time measurement data, waveform calculation Calculation items: average value, peak value, maximum value, time to maximum value, minimum value, time to minimum value, on time, off time, on count, off count, standard deviation, aggregation, area value, and integration Save calculation: performs numerical calculation and save to file
Search	Applicable data: real-time data collection file (LUW format), main unit measurement file (MEM format), waveform calculation data Search mode: event mark, date and time, maximum position, minimum position, local maximum position, local maximum position, level, window, and variation
Print	Applicable printer: printer compatible to the OS in use Applicable data: waveform data file (LUW format, MEM format) Print format: waveform image, report print, list print (channel settings, event, cursor value) Print area: all area, specified area by A-B cursor Print preview: available

# Option specifications (sold separately)

# Plug-in modules: U8550, U8551, U8552, U8553, U8554, U8555 Common

Host model	LR8450, LR8450-01 Memory HiLogger
Operating temperature and humidity range	-10°C to 50°C, 80% RH or less (non-condensing)
Storage temperature and humidity range	-20°C to 60°C, 80% RH or less (non-condensing)
Vibration resistance	JIS D 1601:1995 5.3 (1), Class 1A (passenger vehicle) equivalent
Accessories	User manual, mounting screw × 2, wiring confirmation label (U8554 only)

# Wireless modules: LR8530, LR8531, LR8532, LR8533, LR8534, LR8535 Common

Host model	LR8450-01 Memory HiLogger
Control communications method	Connect wirelessly via Z3230 WIRELESS LAN ADAPTER (included)
Communications buffer memory	4 Mword (volatile memory) Saves data in the event of a communications error. Data is resent when communications are restored.
Operating temperature and humidity range	-20°C to 55°C, 80% RH (non-condensing) (charging temperature range: 5°C to 35°C)
Storage temperature and humidity range	-20°C to 60°C, 80% RH (non-condensing)
Vibration resistance	JIS D 1601:1995 5.3 (1), Class 1A (passenger vehicle) equivalent
LED display	Wireless connection and measurement status, error status, AC adapter or external power, battery power, charge status
Operation key	[AUTO], [RESET]

Auto-connect function	Available
Accessories	Z3230 WIRELESS LAN ADAPTER, user manual, Z1008 AC ADAPTER, mounting plate, M3×4 screw × 2 (for use with mounting plate), wiring confirmation label (LR8534 only)
Z3230 wireless specifications	Wireless LAN (IEEE 802.11b/g/n) Range: 30 m (line of sight) Encryption: WPA-PSK/WPA2-PSK, TKIP/AES Channels: channel 1 to 11

Power supply specifications		
AC adapter	Z1008 AC ADAPTER (12 V DC, standard accessory) Rated supply voltage: 100 to 240 V AC Rated power supply frequency: 50/60 Hz Maximum rated power: 25 VA (including AC adapter) Normal power consumption (instrument only, without battery pack) LR8530, LR8532, LR8533: 2.5 VA LR8531: 3.0 VA LR8534, LR8535: 4.0 VA	
Battery	Z1007 BATTERY PACK (when using AC adapter, AC adapter takes precedence.) Maximum rated power LR8530, LR8532: 1.5 VA LR8531, LR8533: 2.0 VA LR8534, LR8535: 3.5 VA	
External power supply	Rated supply voltage: 10 to 30 V DC Maximum rated power: 8 VA (30 V DC external power supply, while charging battery) Normal power consumption (12 V DC external power supply, without battery pack) LR8530, LR8532, LR8533: 2.5 VA LR8531: 3.0 VA LR8534, LR8535: 4.0 VA	
Continuous operating time	When using Z1007 BATTERY PACK (all data refresh rates, good communications state, 23°C reference values) LR8530, LR8532, LR8533: approx. 9 h LR8531: approx. 7 h LR8534: approx. 5 h LR8535: approx. 10 h (approx. 5 h when using two non-contact CAN sensors)	
Charging function	When Z1007 BATTERY PACK installed while connected to AC adapter or 10 to 30 V DC external power supply Charging time: approx. 7 h (23°C reference value)	

# VOLTAGE/TEMP UNIT U8550 UNIVERSAL UNIT U8551 VOLTAGE/TEMP UNIT U8552

WIRELESS VOLTAGE/TEMP UNIT LR8530 WIRELESS UNIVERSAL UNIT LR8531 WIRELESS VOLTAGE/TEMP UNIT LR8532

# (Accuracy guaranteed for 1 year)

# **General specifications**

Number of input channels	U8550: 15 (set voltage, thermocouple, or humidity for each channel) LR8530: 15 (set voltage or thermocouple for each channel) U8551, LR8531: 15 (set voltage, thermocouple, humidity, RTD, or resistor for each channel) U8552: 30 (set voltage, thermocouple, or humidity for each channel) LR8532: 30 (set voltage or thermocouple for each channel)
Input terminals	U8550, LR8530: M3 screw-type terminal block (2 terminals per channel) U8551, LR8531: push-button type terminal block (4 terminals per channel) U8552, LR8532: push-button type terminal block (2 terminals per channel)
Output terminals	M3 screw-type terminal block (1 output, 2 terminals, Z2000 HUMIDITY SENSOR power supply [can power up to 15 Z2000 HUMIDITY SENSOR])(LR8531 only)
Measurement target	U8550, U8552: voltage, temperature (thermocouples), humidity LR8530, LR8532: voltage, temperature (thermocouples) U8551, LR8531: voltage, temperature (thermocouples), humidity, temperature (RTD), resistor
Input type	Scanning by semiconductor relays All channels isolated (not isolated when measuring with RTD, resistance or humidity)
A/D resolution	16 bits
Maximum input voltage	±100 V DC (maximum voltage between input terminals without causing damage)
Maximum channel- to-channel voltage	300 V DC (maximum voltage that can be applied between each input channel without causing damage; not isolated when measuring with RTD, resistance or humidity)  *Channels are isolated from each other with semiconductor relays. Never allow a voltage exceeding the product specifications, for example a lightning surge, to be applied across channels as doing so may cause the semiconductor relays to short.
Maximum rated terminal-to-ground voltage	300 V AC, DC (maximum voltage that can be applied between input channels and the instrument or its chassis, or between units without causing damage; humidity measurement not isolated)
Input resistance	10 M $\Omega$ or greater (10 mV f.s. to 2 V f.s. voltage ranges, thermocouple ranges, RTD and resistor ranges) 1 M $\Omega$ ±5% (10 V f.s. to 100 V f.s. voltage range, 1-5 V f.s. voltage range, humidity measurement)
Allowable signal source resistance	1 kΩ or less
Data refresh interval	10 ms to 10 s (10 selectable levels)
Digital filters	Digital filter cutoff frequency is automatically set to data refresh interval, burnout setting, and power supply frequency filter setting
Dimensions	U8550, U8551, U8552: approx. 134W × 70H × 63D mm (5.28"W × 2.76"H × 2.48"D) LR8530, LR8531, LR8532: approx. 154W × 106H × 57D mm (6.06"W × 4.17"H × 2.24"D)
Mass	U8550: approx. 345 g (12.2 oz.), U8551: approx. 318 g (11.2 oz.), U8552: approx. 319 g (11.3 oz.), LR8530: approx. 423 g (14.9 oz.), LR8531: approx. 386 g (13.6 oz.), LR8532: approx. 388 g (13.7 oz.), (including Z3230 WIRELESS LAN ADAPTER)

Analog input specifications (23  $\pm$ 5°C [73  $\pm$ 9°F], 80% rh or less, after 30 minutes of warm-up and zero-adjustment, with the 50/60 Hz cut-off setting selected)

# Voltage

Range	Maximum resolution	Measurable range	Measurement accuracy
10 mV f.s.	500 nV	-10 mV to 10 mV	±10 μV
20 mV f.s.	1 μV	-20 mV to 20 mV	±20 μV
100 mV f.s.	5 μV	-100 mV to 100 mV	±50 μV
200 mV f.s.	10 μV	-200 mV to 200 mV	±100 μV
1 V f.s.	50 μV	-1 V to 1 V	±500 μV
2 V f.s.	100 μV	-2 V to 2 V	±1 mV
10 V f.s.	500 μV	-10 V to 10 V	±5 mV
20 V f.s.	1 mV	-20 V to 20 V	±10 mV
100 V f.s.	5 mV	-100 V to 100 V	±50 mV
1-5 V f.s.	500 μV	1 V to 5 V	±5 mV

# Temperature

Thermocouple (not including accuracy of reference junction compensation)

ype	Range	Measurable range	Maximum resolution	Measurement accura
K	100°C f.s.	0.01°C	-100°C to less than 0°C	±0.7
			0°C to 100°C	±0.5
	500°C f.s.	0.05°C	-200°C to less than -100°C	±1.4
			-100°C to less than 0°C	±0.7
			0°C to 500°C	±0.5
	2,000°C f.s.	0.1°C	-200°C to less than -100°C	±1.4
	,		-100°C to less than 0°C	±0.7
			0°C to less than 500°C	±0.5
			500°C to 1,350°C	±0.7
J	100°C f.s.	0.01°C	-100°C to less than 0°C	±0.7
•	100 0	0.01.0	0°C to 100°C	±0.5
	500°C f.s.	0.05°C	-200°C to less than -100°C	±0.9
	000 0	0.00	-100°C to less than 0°C	±0.7
			0°C to 500°C	±0.5
	2,000°C f.s.	0.1°C	-200°C to less than -100°C	±0.9
	2,000 0 1.3.	0.10	-100°C to less than 0°C	±0.3
			0°C to 1,200°C	±0.7
E	100°C f.s.	0.01°C	-100°C to less than 0°C	±0.5
	100 € 1.5.	0.01 C		
	500°C f.s.	0.05°0	0°C to 100°C -200°C to less than -100°C	±0.5
	500°C f.S.	0.05°C		
			-100°C to less than 0°C	±0.7
	0.00000.6	0.400	0°C to 500°C	±0.5
	2,000°C f.s.	0.1°C	-200°C to less than -100°C	±0.9
			-100°C to less than 0°C	±0.7
_			0°C to 1,000°C	±0.5
T	100°C f.s.	0.01°C	-100°C to less than 0°C	±0.7
			0°C to 100°C	±0.5
	500°C f.s.	0.05°C	-200°C to less than -100°C	±1.4
			-100°C to less than 0°C	±0.7
			0°C to 400°C	±0.5
	2000°C f.s.	0.1°C	-200°C to less than -100°C	±1.4
			-100°C to less than 0°C	±0.7
			0°C to 400°C	±0.5
Ν	100°C f.s.	0.01°C	-100°C to less than 0°C	±1.1
			0°C to 100°C	±0.9
	500°C f.s.	0.05°C	-200°C to less than -100°C	±2.1
			-100°C to less than 0°C	±1.1
			0°C to 500°C	±0.9
	2,000°C f.s.	0.1°C	-200°C to less than -100°C	±2.1
			-100°C to less than 0°C	±1.1
			0°C to 1,300°C	±0.9
R	100°C f.s.	0.01°C	0°C to 100°C	±4.4
	500°C f.s.	0.05°C	0°C to less than 100°C	±4.4
			100°C to less than 300°C	±2.9
			300°C to 500°C	±2.2
	2000°C f.s.	0.1°C	0°C to less than 100°C	±4.4
			100°C to less than 300°C	±2.9
			300°C to 1,700°C	±2.2
S	100°C f.s.	0.01°C	0°C to 100°C	±4.4
-	500°C f.s.	0.05°C	0°C to less than 100°C	±4.4
	110 0 1.0.	3.00 0	100°C to less than 300°C	±2.9
			300°C to 500°C	±2.2
	2,000°C f.s.	0.1°C	0°C to less than 100°C	±4.4
	2,000 0 1.5.	0.10	100°C to less than 300°C	±2.9
D	2.00000 f	0.400	300°C to 1,700°C	±2.2
В	2,000°C f.s.	0.1°C	400°C to less than 600°C	±5.4
			600°C to less than 1,000°C	±3.7
_	10707		1,000°C to 1,800°C	±2.4
С	100°C f.s.	0.01°C	0°C to 100°C	±1.7
	500°C f.s.	0.05°C	0°C to 500°C	±1.7
	2,000°C f.s.	0.1°C	0°C to 2,000°C	±1.7

Other specifications about thermocouple measurement

Reference junction compensation: internal/external	At INT RJC, total accuracy = add ±0.5°C
detection: on/off	System will check for burnout at each data refresh interval during thermocouple measurement. (not available with 10 ms interval)

# U8550, U8551, U8552, LR8531 only input specifications Humidity (use HUMIDITY SENSOR Z2000)

#### **HUMIDITY SENSOR Z2000**


Operating temperature and humidity range: 0°C to 50°C (32°F to 122°F), 100% RH or less (non-condensing)

Range	Maximum resolution	Measurable range
100% rh f.s.	0.1% rh	5.0% rh to 95.0% rh

#### **HUMIDITY SENSOR Z2000 accuracy**

If the humidity value lies on a boundary line below, the better of the two regions' measurement accuracy values applies.





# U8551, LR8531 only input specifications

Temperature RTD

Connection: 3-wire/4-wire, measurement current: 1mA (Pt100, Jpt100), 0.1mA (Pt1000) Standards: Pt100, Pt1000: JIS C1604-2013, IEC751 JPt100: JIS C1604-1989

Туре	Range	Maximum resolution	Measurable range	Measurement accuracy
	100°C f.s.	0.01°C	-100°C to 100°C	±0.5°C
Pt100	500°C f.s.	0.05°C	-200°C to 500°C	±0.7°C
	2,000°C f.s.	0.1°C	-200°C to 800°C	±0.9°C
JPt100	100°C f.s.	0.01°C	-100°C to 100°C	±0.5°C
	500°C f.s.	0.05°C	-200°C to 500°C	±0.7°C
	2,000°C f.s.	0.1°C	-200°C to 500°C	±0.9°C
Pt1000	100°C f.s.	0.01°C	-100°C to 100°C	±0.5°C
	500°C f.s.	0.05°C	-200°C to 500°C	±0.7°C
	2,000°C f.s.	0.1°C	-200°C to 800°C	±0.9°C

<sup>\*</sup>When using Pt1000, data refresh intervals of 10ms, 20m, and 50ms are not available.

Resistance Connection: 4-wire; measurement current is 1 mA

Range	Maximum resolution	Measurable range	Measurement accuracy
10 Ω f.s.	0.5 mΩ	0 $\Omega$ to 10 $\Omega$	±10 mΩ
20 Ω f.s.	1 mΩ	0 Ω to 20 Ω	±20 mΩ
100 Ω f.s.	5 mΩ	0 Ω to 100 Ω	±100 mΩ
200 Ω f.s.	10 mΩ	0 Ω to 200 Ω	±200 mΩ

# HIGH SPEED VOLTAGE UNIT U8553 WIRELESS HIGH SPEED VOLTAGE UNIT LR8531

(Accuracy guaranteed for 1 year)

### General specifications

Number of input channels	5 (voltage only)
Input terminals	M3 screw-type terminal block (2 terminals per channel), outfitted with terminal block cover
Measurement target	Voltage
Input type	Scanning by semiconductor relays, all channels isolated
A/D resolution	16 bits
Maximum input voltage	±100 V DC (maximum voltage between input terminals without causing damage)
Maximum channel-to- channel voltage	300 V DC (maximum voltage between input channels without causing damage) *Channels are isolated from each other with semiconductor relays. Never allow a voltage exceeding the product specifications, for example a lightning surge, to be applied across channels as doing so may cause the semiconductor relays to short.
Maximum rated termi- nal-to-ground voltage	300 V AC, DC (maximum voltage between input channel and chassis, or between modules, without causing damage)
Input resistance	1 MΩ ±5%
Allowable signal source resistance	100 $\Omega$ or less
Data refresh interval	1 ms to 10 s (13 selectable levels)
Digital filters	Digital filter cutoff frequency is automatically set to data refresh interval, burnout detection setting, and power supply frequency filter setting.

Dimensions	U8553: approx. 134W×70H×63D mm (5.28"W×2.76"H×2.48"D) LR8531: approx. 154W×106H×57D mm (6.06"W×4.17"H×2.24"D)
Mass	U8553: approx. 237 g (8.4 oz.) LR8531: approx. 370 g (13.1 oz.) (including Z3230 WIRELESS LAN ADAPTER)

Analog input specifications (23  $\pm$ 5 °C/73  $\pm$ 9 °F, 80% rh or less, after 30 minutes of warm-up and zero-adjustment, with the 50/60 Hz cut-off setting selected)

Measurement target	Range	Maximum resolution	Measurable range	Measurement accuracy
Voltage	100 mV f.s.	5 μV	-100 mV to 100 mV	±100 μV
	200 mV f.s.	10 μV	-200 mV to 200 mV	±200 μV
	1 V f.s.	50 μV	-1 V to 1 V	±1 mV
	2 V f.s.	100 μV	-2 V to 2 V	±2 mV
	10 V f.s.	500 μV	-10 V to 10 V	±10 mV
	20 V f.s.	1 mV	-20 V to 20 V	±20 mV
	100 V f.s.	5 mV	-100 V to 100 V	±100 mV
	1-5 V f.s.	500 μV	1 V to 5 V	±10 mV

STRAIN UNIT U	J8554	WIRELESS STRAIN UNIT LR8534		
(Accuracy guarant	eed for 1	year)		
General specifica	itions			
Number of input channels	5 (set vo	5 (set voltage or strain for each channel)		
Input terminals		ton type terminal block (5 terminals per channel), outfitted with block cover, set DIP switches according to measurement target		
Measurement	Voltage			
target	Strain	Strain gage-type converter Strain gage 1-gage method (2-wire setup), 1-gage method (3-wire setup), 2-gage method (adjacent sides), 4-gage method		
Adaptive gage resistance	1-gage n 4-gage n	nethod, 2-gage method: 120 $\Omega$ (external bridge box required for 350 $\Omega)$ nethod: 120 $\Omega$ to 1 $k\Omega$		
Gage ratio	2.0 (fixed	<u> </u>		
Bridge voltage	2 V ±0.0	5 V DC		
Balance	Method	Electronic auto-balancing		
adjustment	Range	Voltage: $\pm 20$ mV or less (1 mV f.s. to 20 mV f.s. range), $\pm 200$ mV or less (50 mV f.s. to 200 mV f.s. range) Strain: $\pm 20,000$ με or less (1,000 με f.s. to 20,000 με f.s. range), $\pm 200,000$ με or less (50,000 με f.s. to 200,000 με f.s. range)		
Input type		d differential input, simultaneous sampling of all channels (non- channels)		
A/D resolution	16 bit			
Maximum input voltage	±0.5 V D damage)	C (maximum voltage between input terminals without causing		
Maximum channel- to-channel voltage	Non-isola	ated (all channels share common GND)		
Maximum rated terminal-to-ground voltage	30 Vrms chassis v	30 Vrms AC or 60 V DC (maximum voltage between input channel and chassis without causing damage)		
Input resistance	2 MΩ ±5	%		
Data refresh interval	1 ms to 1	10 s (13 selectable levels)		
Low-pass filter	Cut-off frequency: -3 dB ±30% Auto, 120, 60, 30, 15, 8, 4 (Hz) Auto: cut-off frequency of low-pass filter is automatically set based set data refresh interval.			
		ion characteristics: 5th-order butterworth filter, -30 dB/oct		
Dimensions	U8554: ap LR8534: a	prox. 134W×70H×63Dmm (5.28"W×2.76"H×2.48"D) approx. 154W×106H×57D mm (6.06"W×4.17"H×2.24"D)		
Mass		oprox. 236g (8.3 oz.) approx. 372g (13.1 oz.) (including Z3230 WIRELESS LAN ADAPTER)		

Analog input specifications (23  $\pm 5^{\circ}$  C/73  $\pm 9^{\circ}$ F, 80% rh or less, auto-balance at least 30 minutes after power on, with LPF set at 4 Hz)


Measure- ment target	Range	Maximum resolution	Measurable range	Measurement accuracy
Voltage	1 mV f.s.	50 nV	-1 mV to 1 mV	±9 μV
	2 mV f.s.	100 nV	-2 mV to 2 mV	±10 μV
	5 mV f.s.	250 nV	-5 mV to 5 mV	±25 μV
	10 mV f.s.	500 nV	-10 mV to 10 mV	±50 μV
	20 mV f.s.	1 μV	-20 mV to 20 mV	±100 μV
	50 mV f.s.	2.5 μV	-50 mV to 50 mV	±250 μV
	100 mV f.s.	5 μV	-100 mV to 100 mV	±500 μV
	200 mV f.s.	10 μV	-200 mV to 200 mV	±1 mV
Strain	1,000 με f.s.	0.05 με	-1,000 με to 1,000 με	±9 με
	2,000 με f.s.	0.1 με	-2,000 με to 2,000 με	±10 με
	5,000 με f.s.	0.25 με	-5,000 με to 5,000 με	±25 με
	10,000 με f.s.	0.5 με	-10,000 με to 10,000 με	±50 με
	20,000 με f.s.	1 με	-20,000 με to 20,000 με	±100 με
	50,000 με f.s.	2.5 με	-50,000 με to 50,000 με	±250 με
	100,000 με f.s.	5 με	-100,000 με to 100,000 με	±500 με
	200,000 με f.s.	10 με	-200,000 με to 200,000 με	±1000 με

<sup>\*</sup> Internal bridge resistance precision tolerance: ±0.01%; temperature characteristics: ±2 ppm/°C \* Measurement accuracy does not include internal bridge resistance tolerance and temperature characteristics

# CAN UNIT U8555 WIRELESS CAN UNIT LR8535

# General specifications

Number of ports 2 Input terminals D-sub 9 pin MALE × 2



Pin No.	Signal	Function
1	N.C.	Unused
2	CAN_L	CAN_L communications line
3	GND	GND
4	N.C.	Unused
5	N.C.	Unused
6	N.C.	Unused
7	CAN_H	CAN_H communications line
8	N.C.	Unused
9	N.C.	Unused

Power supply terminals (LR8535 only)	USB port (connectors: Series A receptacle × 2) Dedicated power supply for Hioki NON-CONTACT CAN SENSOR		
Interface	Protocols supported	CAN (ISO11898) CAN FD (ISO11898) CAN FD (non-ISO)	
	Physical layer	ISO11898 (High Speed)	
Terminator	On/off setting available for each port 120 Ω ±10 Ω built-in resistance		
ACT LED	Displays CAN bus operating status		
TERM LED	Illuminates when terminator is on		
Data refresh interval	10 ms to 10 s (10 selectable levels)		
Baud rate	CAN/CAN FD (arbitration): 50k, 62.5k, 83.3k, 100k, 125k, 250k, 500k, 800k, 1,000k [Baud] CAN FD (data): 0.5M, 1M, 2M, 2.5M, 4M, 5M [Baud]		
Sampling point	CAN or CAN FD (arbitration): 50.0% to 95.0% CAN FD (data): 50.0% to 95.0%		
ACK transmission	ACK response when receiving CAN data can be set to on or off		
Operation mode	U8555: supports switching between receive mode and measured value output mode LR8535: supports only receive mode		
Dimensions	U8553: approx. 134W×70H×54D mm (5.28"W×2.76"H×2.13"D) LR8531: approx. 154W×106H×48D mm (6.06"W×4.17"H×1.89"D)		
Mass	U8553: approx. 235 g (8.3 oz.) LR8531: approx. 355 g (12.2 oz.) (including Z3230 WIRELESS LAN ADAPTER)		

# Receive mode specifications

	channels	Data refresh interval 10 ms: max. 50 channels (max. 50 signals) Data refresh interval 20 ms: max. 100 channels (max. 100 signals) Data refresh interval 50 ms: max. 250 channels (max. 250 signals) Data refresh interval 100 ms or greater: max. 500 channels (max. 500 signals)
		Function for recording the number of times a target ID is received during the data refresh interval
		Sends user-defined CAN frames during receive mode operation No. of configurable conditions: 8 per unit

# Measured values output mode specifications (U8555 only)

Overview	Converts LR8450 measured values and output them as CAN frames.
Output target	Measurement data from plug-in modules (other than CAN Unit) Measurement time
Output data refresh period	Depends on data refresh interval of module generating output (as fast as 1 ms)
Response	Data refresh interval × 2 + 1 ms + analog response time (*1) *1 Varies with filter settings (U8554: 5 ms with 120 Hz low-pass filter)

# **CAN Editor (software) specifications**

# **General specifications**

General specificat	ions		
Operating environment	Windows 10 (32/64-bit), Windows 11 (64-bit)		
Interface	LAN/USB		
Supported languages	Japanese/English/C	Chinese	
Supported instruments	HIOKI LR8450/LR8450-01 MEMORY HILOGGER		
Set module position			
CAN interface set- ting	Interface, terminator, baud rate, data rate, sampling points, data sampling points, ACK		
Module operating mode	Switch between receive mode and measured value output mode on a module-by-module basis		
Receive mode sett	ings		
Data refresh interval	10 ms to 10 s (10 selectable levels)		
Receive channel	CAN input port settings	Port 1 or Port 2	
definition settings	Channel type	Data or ID count	
	Shared settings	1. Format: standard/extended 2. ID: Oh to 1 FFFFFFH 3. Comment 4. Unit 5. Factor, offset	
	Channel type: data	Start bits: 0 to 511     Bit length: 1 to 64 [bits]     Byte order: Motorola/Intel     Data type: unsigned/signed/IEEE/float/	
	LR8450 display settings	Display upper limit value or display lower limit value     No. of display digits, display format     Numerical calculation threshold     Waveform color	
User-defined frame transmission set-	Receive condition numbe	No. 1 to No. 8	
tings	CAN output port set- ting	Port 1 or Port 2	
	No. of frame	1 to 8	
	Regular transmis- sion setting	On/off	
	Regular transmis- sion interva	1 to 9999 (× 10 [ms])	
	Timing	At measurement start, at measurement stop, at start trigger, at alarm, manual	
	Frame type	CAN standard, CAN extended, CAN FD standard, CAN FD extended	
	Transmit ID	0 h to 1FFFFFF h	
	DLC (bite)	0 to 15 (0, 12, 16, 20, 24, 32, 48, 64)	
	Transmit data	Set as hexadecimal value	
	Delay	0 to 9999 (× 10 [ms])	
Measured value out	put mode setting		
Measured value output setting	CAN output port set- ting	Port 1 or Port 2	
	Frame type	Standard/extended	
	ID	0 h to 1FFFFFFF h	
	Data	Measured values from the following modules can be set as output data U8550, U8551, U8552, U8553, U8554	
		ld be the CAN bus load increase rate if	
estimation function	measured values v	vere to be output using the current settings	
File specifications			
Save function	CANdb file (.dbc) for transmit data defined using measured value output mode settings     Overall settings data for CAN Editor (.CES)		
Load function	Loads CANdb files (.dbc) and MR8904 definition files (.CDF) and use them to configure receive channel settings.     Loads LR8450 settings (.SET) and CAN Editor settings (.CES) and applies them to the CAN Editor's overall settings.		
Title	Sets titles for settings data (.CES) (up to 50 single-byte or 25 double-byte characters).		

# **Model: MEMORY HILOGGER LR8450**



# Option

# Plug-in modules



#### **VOLTAGE/TEMP UNIT U8550**

Channels: 15: maximum sampling rate: 10 ms



# **UNIVERSAL UNIT U8551**

Channels: 15; maximum sampling rate: 10 ms



# **VOLTAGE/TEMP UNIT U8552**

Channels: 30: maximum sampling rate: 20 ms (When 15 or fewer channels are used, 10 ms)



#### **HIGH SPEED VOLTAGE UNIT U8553**

Channels: 5; maximum sampling rate: 1 ms



### **STRAIN UNIT U8554**

Channels: 5; maximum sampling rate: 1 ms



#### **CAN UNIT U8555**

Ports: 2, input: CAN or CAN FD, output: CAN or CAN FD maximum sampling rate: 10 ms

#### Model No. Specifications (order code) LR8450 Standard model, main unit only LR8450-01 Wireless LAN equipped model, main unit only

- The LR8450 and LR8450-01 cannot perform measurement on their own. One or more plug-in modules or wireless modules are required (sold separately)
- The LR8450-01 and each wireless module emit radio waves. Use of radio waves is subject to licensing requirements in certain countries. Using it in a country or region other than those indicated may violate the law and may result in legal penalties for the operator. For the latest information about countries and regions where wireless operation is currently supported, please visit the Hioki website.

#### Wireless modules



#### **WIRELESS VOLTAGE/TEMP UNIT LR8530**

Channels: 15: maximum sampling rate: 10 ms



#### **WIRELESS UNIVERSAL UNIT LR8531**

Channels: 15; maximum sampling rate: 10 ms



#### WIRELESS VOLTAGE/TEMP UNIT LR8532

Channels: 30: maximum sampling rate: 20 ms (When 15 or fewer channels are used, 10 ms)



#### **WIRELESS HIGH SPEED VOLTAGE UNIT LR8533**

Channels: 5; maximum sampling rate: 1 ms



#### **WIRELESS STRAIN UNIT LR8534**

Channels: 5; maximum sampling rate: 1 ms



#### **WIRELESS CAN UNIT LR8535**

Ports: 2, input: CAN or CAN FD, maximum sampling rate: 10 ms

# Power supplies

For instrument and wireless modules



**BATTERY PACK** Z1007

Instrument takes two wireless modules take one For instrument



**AC ADAPTER** Z1014

Ships standard with LR8450/LR8450-01

For wireless modules



**AC ADAPTER** Z1008

# **Fixed Stand**



**FIXED STAND** Z5040

For installing logger on wall

# Case



**CARRYING CASE** C1012

Accommodates instrument and four plug-in modules or seven wireless modules

# Wireless Lan Adapter

For wireless modules



**WIRELESS LAN ADAPTER** Z3230

### Cables, sensors, etc.



# LAN CABLE 9642

Straight Ethernet cable, supplied with straight to cross conversion adapter, 5 m (16.41 ft) length



#### **HUMIDITY SENSOR** Z2000

(analog output), 3 m (9.84 ft) length



# Thermocouple

For reference only. Please purchase locally.



# **CAN CABLE 9713-01**

For the U8555, LR8535. Unprocessed on one end, 1.8 m (5.91 ft) length



#### NON-CONTACT CAN SENSOR SP7001-95

Supports CAN FD or CAN signals, SP7001, SP9250, SP7150 set

# Storage media

\*Always use HIOKI optional storage media. Proper operation is not guaranteed when using storage media from other manufacturers, and may prevent the product from saving and loading data properly.



SD memory card Z4001

2 GB capacity



SD memory card Z4003 8 GB capacity



**DISTRIBUTED BY** 

### USB drive Z4006

16 GB, long-life, high-reliability SLC flash memory

# For the PC





**GENNECT One** 

### LOGGER UTILITY/CAN EDITOR

LOGGER UTILITY: The control of the measurement of loggers, real-time data collection CAN EDITOR: CAN configuration software Standard accessory

You can download the latest version from our website

#### Displays measurement results from multiple instruments in graph form Free application for Windows

Note: Company names and product names appearing in this catalog are trademarks or registered trademarks of various companies



# **HEADQUARTERS**

81 Koizumi. Ueda, Nagano 386-1192 Japan https://www.hioki.com/



Scan for all regional contact information