

---

## WINC1500 Xplained Pro User's Guide


---

### Description

---

The WINC1500-XPRO is an extension board to evaluate the performance of the ATWINC15x0-MR210xB IoT (Internet of Things) module that supports an IEEE<sup>®</sup> 802.11 b/g/n standard. The WINC1500 Xplained Pro extension board is designed to provide Wi-Fi<sup>®</sup> functionality in the 2.4 GHz ISM band to the Xplained Pro evaluation platform. This kit provides access to the features of the ATWINC15x0-MR210xB wireless module and explains how to integrate the module in a custom design.

**Figure 1. WINC1500 Xplained Pro Extension Board**



---

**Table of Contents**

---

Description.....	1
1. Introduction.....	3
1.1. Features.....	3
1.2. Kit Overview.....	4
2. Getting Started.....	5
2.1. Xplained Pro Quick Start.....	5
2.2. Design Documentation and Relevant Links.....	5
3. Xplained Pro.....	7
3.1. Hardware Identification System.....	7
3.2. Xplained Pro Standard Extension Header.....	7
4. Hardware Specifications.....	9
4.1. Headers and Connectors.....	9
4.2. WINC1500-XPRO Peripherals.....	11
4.3. Hardware Revision History.....	12
5. Ordering Information.....	13
6. Document Revision History.....	14
The Microchip Web Site.....	15
Customer Change Notification Service.....	15
Customer Support.....	15
Microchip Devices Code Protection Feature.....	15
Legal Notice.....	16
Trademarks.....	16
Quality Management System Certified by DNV.....	17
Worldwide Sales and Service.....	18

## 1. Introduction

### 1.1 Features

- Compliant Wi-Fi module with IEEE 802.11 b/g/n standard specifications:
  - Supports 20 MHz single spatial stream (1x1), up to 72.2 Mbps PHY rate in the 2.4 GHz ISM band
  - Supported network features: TCP, UDP, DHCP, ARP, HTTP, SSL, and DNS
  - Supports host interface through SPI
- Integrated Power Amplifier (PA), Tx/Rx switch and Printed Circuit Board (PCB) antenna
- Supports very low input level (sensitivity) and long range
- Supports on-chip network stack to offload MCU
- Integrated flash memory for system software
- Debug I<sup>2</sup>C and UART header footprints
- Extension port and RESET switch footprints
- Current measurement header
- Crypto authentication (optional)
- Xplained Pro extension hardware identification system
- Supports an operating temperature range from -40°C to +85°C
- Supports footprint compatible modules shown in the table below. The kit contains the ATWINC1510-MR210PB module by default

**Table 1-1. Wireless Modules**


Model Number	No. of Pins	Description	Regulatory Certification
ATWINC1500-MR210PB	28	Certified Module with ATWINC1500B chip (4Mb Flash) and PCB printed antenna	FCC, IC, CE
ATWINC1500-MR210UB	28	Certified Module with ATWINC1500B chip (4Mb Flash) and u.FL connector	FCC, IC
ATWINC1510-MR210PB	28	Certified Module with ATWINC1510B chip (8Mb Flash) and PCB printed antenna	FCC, IC, CE
ATWINC1510-MR210UB	28	Certified Module with ATWINC1510B chip (8Mb Flash) and u.FL connector	Planned

- Approved regulatory certification IDs for ATWINC1510-MR210PB:
  - United States/FCC ID: 2ADHKATWINC1510
  - Canada
    - IC ID: 20266-ATWINC1510
    - HVIN: ATWINC1510-MR210PB
  - Europe - CE

## 1.2 Kit Overview

The WINC1500-XPRO is an extension board for the SmartConnect-ATWINC15x0-MR210xB Wi-Fi module for the Xplained Pro platform. It connects to any Xplained Pro standard extension header on any Xplained Pro MCU board to provide Wi-Fi functionality.

**Figure 1-1. WINC1500-XPRO Overview**



## 2. Getting Started

The WINC1500-XPRO is designed to connect with an Xplained Pro extension header marked as EXT1. However, it is compatible with all Xplained Pro EXT headers. Refer to the pin description of the Xplained Pro evaluation kit to find out the suitable EXT headers of the Xplained Pro.

### 2.1 Xplained Pro Quick Start

Steps to start exploring the Xplained Pro platform:

1. Download and install [Atmel Studio](#).
2. Launch Atmel Studio.

The operating system installs the driver software automatically the first time the Xplained Pro evaluation kit is connected to a PC. This driver supports 32-bit and 64-bit versions of Microsoft® Windows® XP, Windows Vista®, Windows 7, Windows 8, Windows 10, and Windows Server 2012.

When the Xplained Pro MCU board is powered, the power LED (green) glows and Atmel Studio automatically detects the specific Xplained Pro MCU and extension board(s) that are connected. The kit landing page in Atmel Studio comes with an option to launch Atmel Software Framework (ASF) and Atmel START example application codes for the kit. The target device is programmed and debugged by the on-board Embedded Debugger and therefore no external programmer or debugger tool is required.

### 2.2 Design Documentation and Relevant Links

The following list contains the link to the relevant documents and software for the WINC1500-XPRO:

- [WINC1500-XPRO](#) - Product page
- [WINC1500-XPRO Design Documentation](#) - Package containing schematics, BOM, assembly drawings, 3D plots, layer plots, etc.
- [ATWINC15x0-MR210xB](#) - Wireless module datasheet
- [WINC1500](#) - Wireless chip datasheet
- [ATECC508A-MAHDA-T](#) - Crypto Authentication Device datasheet
- [ATWINC1500B Hardware Design Guidelines - IEEE 802.11 b/g/n IoT Module](#) - Hardware Design Guide
- [Getting Started Guide for ATWINC1500 Wi-Fi using SAM D21 Xplained Pro](#) - User Guide
- [Software Programming Guide for ATWINC1500 Wi-Fi using SAM D21 Xplained Pro](#) - Programming Guide
- [ATWINC1500 Wi-Fi Network Controller - Software Design Guide](#) - Design Guide
- [ATWINC1500 AT Command Reference Guide](#) - Command Reference Guide
- [ATWINC1500 Wi-Fi Network Controller - AP Provision Mode](#) - Application Note
- [ATWINC1500 Wi-Fi Network Controller - Station Mode](#) - Application Note
- [ATWINC1500 Wi-Fi Network Controller - P2P Mode](#) - Application Note
- [ATWINC1500 Wi-Fi Network Controller - HTTP Provision Mode](#) - Application Note
- [TCP Client and Server Operation using ATWINC1500](#) - Application Note
- [ATWINC1500 Weather Client Example](#) - Application Note
- [Xplained Pro products](#) - The Xplained Pro is a series of small-sized and easy-to-use evaluation kits for microcontrollers and other products. It consists of a series of low-cost MCU boards for evaluation and demonstration of features and capabilities of different MCU families

- **Atmel Studio** - Atmel Studio provides a free Atmel IDE for development of C/C++ and assembler code for microcontrollers, and relevant documentation
- **Atmel Data Visualizer** - Atmel Data Visualizer is a program used for processing and visualizing data. Data Visualizer can receive data from various sources such as the Embedded Debugger Data Gateway Interface found on Xplained Pro boards and COM ports
- **EDBG User Guide** - User guide containing more information about the on-board Embedded Debugger

### 3. Xplained Pro

Xplained Pro is an evaluation platform which contains a series of microcontroller boards (evaluation kits) and extension boards. Atmel Studio is used to program and debug the microcontrollers on these boards. Atmel Studio includes ASF and Atmel START, which has drivers and demo code, and Data Visualizer, which supports data streaming and advanced debugging. Xplained Pro evaluation kits can be connected to a wide range of Xplained Pro extension boards through standardized headers and connectors. Xplained Pro extension boards have identification (ID) chips to uniquely identify which boards are connected to the Xplained Pro evaluation kits.

#### 3.1 Hardware Identification System

All Xplained Pro extension boards come with an identification chip (ATSHA204A CryptoAuthentication chip) to uniquely identify the boards that are connected to the Xplained Pro evaluation kit. This chip contains information that identifies the extension with its name and some extra data. When an Xplained Pro extension is connected to an Xplained Pro evaluation kit, the information is read and sent to Atmel Studio. The following table shows the data fields stored in the ID chip with example content.

**Table 3-1. Xplained Pro ID Chip Content**

Data Field	Data Type	Example Content
Manufacturer	ASCII string	Atmel\0'
Product Name	ASCII string	Segment LCD1 Xplained Pro\0'
Product Revision	ASCII string	02\0'
Product Serial Number	ASCII string	1774020200000010\0'
Minimum Voltage [mV]	uint16_t	3000
Maximum Voltage [mV]	uint16_t	3600
Maximum Current [mA]	uint16_t	30

#### 3.2 Xplained Pro Standard Extension Header

All Xplained Pro kits have one or more dual row, 20-pin, 100-mil extension header. The Xplained Pro MCU boards have male headers, while the Xplained Pro extensions have their female counterparts. All connected pins follow the defined pin description in the table.



**Info:** All pins are not always connected on all extension headers.

The extension headers can be used to connect a variety of Xplained Pro extensions to Xplained Pro MCU boards or to access the pins of the target microcontroller on Xplained Pro MCU boards directly.

**Table 3-2. Xplained Pro Standard Extension Header**

Pin Number	Pin Name	Description
1	ID	Pin to communicate with the ID chip on an extension board
2	GND	Ground
3	ADC(+)	Analog-to-Digital Converter; alternatively, a pin for the positive terminal of a differential ADC
4	ADC(-)	Analog-to-Digital Converter; alternatively, a pin for the negative terminal of a differential ADC
5	GPIO1	General purpose I/O pin
6	GPIO2	General purpose I/O pin
7	PWM(+)	Pulse width modulation; alternatively, a pin for the positive part of a differential PWM
8	PWM(-)	Pulse width modulation; alternatively, a pin for the negative part of a differential PWM
9	IRQ/GPIO	Interrupt request pin and/or general purpose I/O pin
10	SPI_SS_B/ GPIO	Slave select pin for Serial Peripheral Interface (SPI) and/or general purpose I/O pin
11	I <sup>2</sup> C_SDA	Data pin for I <sup>2</sup> C interface. Always connected, bus type
12	I <sup>2</sup> C_SCL	Clock pin for I <sup>2</sup> C interface. Always connected, bus type
13	UART_RX	Receiver pin of target device UART
14	UART_TX	Transmitter pin of target device UART
15	SPI_SS_A	Slave select for SPI. This pin should preferably not be connected to anything else.
16	SPI_MOSI	SPI master out slave in pin. Always connected, bus type
17	SPI_MISO	SPI master in slave out pin. Always connected, bus type
18	SPI_SCK	SPI clock pin. Always connected, bus type
19	GND	Ground pin for extension boards
20	VCC	Power pin for extension boards



## 4. Hardware Specifications

### 4.1 Headers and Connectors

#### 4.1.1 WINC1500-XPRO Extension Header

The WINC1500-XPRO implements one Xplained Pro Standard Extension Header marked with EXT in the PCB silkscreen. This header makes it possible to connect the board to any Xplained Pro MCU board. The following table provides pin descriptions for the extension header. Among the interfaces of wireless module, SPI is the only host interface; UART is for debug and I<sup>2</sup>C is for development debug. UART and I<sup>2</sup>C signals are accessed through debug connectors J103 and J104 respectively. So, UART\_RXD and UART\_TXD connections of wireless module with host can be separated by removing R117 and R118 to access them only at J103. To find the location of these resistors on board refer to [WINC1500-XPRO Design Documentation in page 5](#). Similarly, I2C\_SDA and I2C\_SCL connections of the wireless module with the host can be separated by removing R107 and R108 respectively; I<sup>2</sup>C connection in J100 can be used to the control crypto device by the host.

**Table 4-1. WINC1500-XPRO Extension Header**

Pin Number	Pin Name	Description
1	ID_DATA	Communication line to ID chip
2	GND	Ground
3	NC	-
4	NC	-
5	RESET_N	Active-low hard reset to the board
6	WAKE	Active-high host wake control signal to the wireless module
7	NC	-
8	NC	-
9	IRQN	Interrupt output from the wireless module to the host
10	CHIP_EN	Active-high module enable signal to wireless module from host
11	I2C_SDA	Data line for I <sup>2</sup> C interface
12	I2C_SCL	Clock line for I <sup>2</sup> C interface
13	UART_RX	Receive pin of target MCU UART interface
14	UART_TX	Transmit pin of target MCU UART interface
15	SPI_SSN	Active-low Slave select signal of the SPI interface to wireless module from host
16	SPI_MOSI	Master out, Slave in signal of target MCU SPI interface
17	SPI_MISO	Master in, Slave out signal of target MCU SPI interface
18	SPI_SCK	Clock line of the SPI interface

Pin Number	Pin Name	Description
19	GND	Ground
20	VCC_TARGET	Target +3.3V supply voltage from the host MCU board

#### 4.1.1.1 Power Measurement Header

The current measurement header (J102) can be used to measure the total current consumed by the ATWINC15x0-MR210xB module using a voltmeter. To measure the total current consumption of the module, remove the jumper from J102 and connect a voltmeter across its pins. A 1Ω resistor available on-board across the jumper gives a 1:1 relationship between voltage drop and current consumption.

#### 4.1.1.2 Debug Connectors

The Debug UART Header (J103) is not mounted on the board. The following table provides connector and module pin descriptions. This connector should be mounted for debug using this UART. A USB Hi-Speed to UART Cable like **FTDI** is needed to connect J103 with PC to print debug log. The following settings are recommended for making serial port setup for debug UART communication. To find the latest settings for serial port setup refer to [Getting Started Guide for ATWINC1500 Wi-Fi using SAM D21 Xplained Pro in page 5](#)

- Baud rate : 115200
- Data : 8 bit
- Parity : none
- Stop : 1 bit
- Flow control : none

**Table 4-2. Debug UART Connector J103**

Pin on UART Connector	Pin on ATWINC15x0-MR210xB module	Function
1	19	UART RX
2	14	UART TX
3	28	Ground

The Debug I<sup>2</sup>C Header (J104) is not mounted on the board. The following table provides connector and module pin descriptions. This I<sup>2</sup>C connector should be mounted only for development debug. An I2C/SPI Host Adapter like **Aardvark** is needed to connect J104 with PC.

**Table 4-3. Debug I<sup>2</sup>C Connector J104**

Pin on I <sup>2</sup> C connector	Pin on ATWINC15x0-MR210xB module	Function
1	2	I <sup>2</sup> C SCL
2	28	Ground
3	3	I <sup>2</sup> C SDA
4	-	Not Connected

The I<sup>2</sup>C and UART pins of the wireless module are also connected with Extension port receptacle J101. The connector can be used for connecting an extension board or for debugging purposes. It is currently not mounted on the board.

**Table 4-4. Extension Port / Debug Connector J101**

Pin on Extension Port	Pin on ATWINC15x0-MR210xB module	Function
1	3	I <sup>2</sup> C_SDA
2	-	NC
3	2	I <sup>2</sup> C_SCL
4	19	UART_RXD
5	28	GND
6	14	UART_TXD
7	-	NC
8	28	GND
9	4	RESET_N
10	23 and 20	VCC_MODULE (+3.3V)

## 4.2 WINC1500-XPRO Peripherals

### 4.2.1 ATWINC15x0-MR210xB Control Signals

The ATWINC15x0-MR210xB main control pins are connected to the Xplained Pro extension header. SPI is the only host interface.

**Table 4-5. ATWINC15x0-MR210xB Control Signals**

Pin on Extension Header	Pin on ATWINC15x0-MR210xB module	Function
5	4	RESET_N
6	11	WAKE
9	13	IRQ_N
10	22	CHIP_EN
15	16	SPI_SSN
16	15	SPI_MOSI
17	17	SPI_MISO
18	18	SPI_SCK

### 4.2.2 LED

There is one dual green/red LED on the Xplained Pro extension board that is controlled by the ATWINC15x0-MR210xB. These LEDs are used to show application status.

**Table 4-6. LED Connection**

Pin on ATWINC15x0-MR210xB module	Function
27	GPIO 5 (Green LED)
1	GPIO 6 (Red LED)

### 4.2.3 Crypto Device

The WINC1500-XPRO features a CryptoAuthentication™ device (ATECC508A). The same I<sup>2</sup>C interface lines are shared between the two slave devices (WINC1500 module and crypto device). Host MCU from the Xplained Pro MCU board will be the Master for this I<sup>2</sup>C. I<sup>2</sup>C connections of the wireless module with the host can be separated by removing R107 and R108 for communication between crypto device and MCU. If there is any issue in this communication, Pull-up resistors R104 and R105 should be mounted.

**Table 4-7. Crypto Device Connection**

Pin on ATWINC15x0-MR210xB module	Function
3	I2C data
2	I2C clock

## 4.3 Hardware Revision History

### 4.3.1 Identifying Product ID and Revision

The revision and product identifier of the WINC1500-XPRO can be found by looking at the sticker on the bottom side of the PCB. The identifier and revision are printed in plain text as A09-nnnn\rr, where nnnn is the identifier and rr is the revision. The label also contains a 10 digit serial number unique to each board.

The product identifier for the WINC1500-XPRO is A09-2442.

### 4.3.2 Revision

Revision 6 of the WINC1500 Xplained Pro is the initial released version. Revision 12 of the WINC1500 Xplained Pro is the latest released version.

## 5. Ordering Information

Following table describes the ordering details of the ATWINC1500-XPRO evaluation boards.

**Table 5-1. Ordering Details**

Model Number	Ordering Code	Kit Description	Package Contents
WINC1500-XPRO	ATWINC1500-XPRO	ATWINC1500 Xplained Pro extension kit	ATWINC1500 Xplained Pro Extension board
WINC1500-XSTK	ATWINC1500-XSTK	ATWINC1500 Xplained Pro starter kit	SAMD21 Xplained Pro, WINC1500 Xplained Pro Extension board, I/O1 Xplained Pro Extension board and Two USB Type A to Micro B Cables (1.5m)

## 6. Document Revision History

### Revision A (May 2017)

- Initial release of this document using the Microchip format.

### Previously Released Atmel Revisions

Doc. rev.	Date	Comment
42388B	17/11/2015	Wireless module part number updated.
42388A	15/04/2015	Initial document release.

## The Microchip Web Site

---

Microchip provides online support via our web site at <http://www.microchip.com/>. This web site is used as a means to make files and information easily available to customers. Accessible by using your favorite Internet browser, the web site contains the following information:

- **Product Support** – Data sheets and errata, application notes and sample programs, design resources, user's guides and hardware support documents, latest software releases and archived software
- **General Technical Support** – Frequently Asked Questions (FAQ), technical support requests, online discussion groups, Microchip consultant program member listing
- **Business of Microchip** – Product selector and ordering guides, latest Microchip press releases, listing of seminars and events, listings of Microchip sales offices, distributors and factory representatives

## Customer Change Notification Service

---

Microchip's customer notification service helps keep customers current on Microchip products. Subscribers will receive e-mail notification whenever there are changes, updates, revisions or errata related to a specified product family or development tool of interest.

To register, access the Microchip web site at <http://www.microchip.com/>. Under "Support", click on "Customer Change Notification" and follow the registration instructions.

## Customer Support

---

Users of Microchip products can receive assistance through several channels:

- Distributor or Representative
- Local Sales Office
- Field Application Engineer (FAE)
- Technical Support

Customers should contact their distributor, representative or Field Application Engineer (FAE) for support. Local sales offices are also available to help customers. A listing of sales offices and locations is included in the back of this document.

Technical support is available through the web site at: <http://www.microchip.com/support>

## Microchip Devices Code Protection Feature

---

Note the following details of the code protection feature on Microchip devices:

- Microchip products meet the specification contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is one of the most secure families of its kind on the market today, when used in the intended manner and under normal conditions.
- There are dishonest and possibly illegal methods used to breach the code protection feature. All of these methods, to our knowledge, require using the Microchip products in a manner outside the operating specifications contained in Microchip's Data Sheets. Most likely, the person doing so is engaged in theft of intellectual property.
- Microchip is willing to work with the customer who is concerned about the integrity of their code.

- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of their code. Code protection does not mean that we are guaranteeing the product as “unbreakable.”

Code protection is constantly evolving. We at Microchip are committed to continuously improving the code protection features of our products. Attempts to break Microchip’s code protection feature may be a violation of the Digital Millennium Copyright Act. If such acts allow unauthorized access to your software or other copyrighted work, you may have a right to sue for relief under that Act.

## Legal Notice

---

Information contained in this publication regarding device applications and the like is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. MICROCHIP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION, INCLUDING BUT NOT LIMITED TO ITS CONDITION, QUALITY, PERFORMANCE, MERCHANTABILITY OR FITNESS FOR PURPOSE. Microchip disclaims all liability arising from this information and its use. Use of Microchip devices in life support and/or safety applications is entirely at the buyer’s risk, and the buyer agrees to defend, indemnify and hold harmless Microchip from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights unless otherwise stated.

## Trademarks

---

The Microchip name and logo, the Microchip logo, AnyRate, AVR, AVR logo, AVR Freaks, BeaconThings, BitCloud, CryptoMemory, CryptoRF, dsPIC, FlashFlex, flexPWR, Heldo, JukeBlox, KeeLoq, KeeLoq logo, Klear, LANCheck, LINK MD, maXStylus, maXTouch, MediaLB, megaAVR, MOST, MOST logo, MPLAB, OptoLyzer, PIC, picoPower, PICSTART, PIC32 logo, Prochip Designer, QTouch, RightTouch, SAM-BA, SpyNIC, SST, SST Logo, SuperFlash, tinyAVR, UNI/O, and XMEGA are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

ClockWorks, The Embedded Control Solutions Company, EtherSynch, Hyper Speed Control, HyperLight Load, IntelliMOS, mTouch, Precision Edge, and Quiet-Wire are registered trademarks of Microchip Technology Incorporated in the U.S.A.

Adjacent Key Suppression, AKS, Analog-for-the-Digital Age, Any Capacitor, AnyIn, AnyOut, BodyCom, chipKIT, chipKIT logo, CodeGuard, CryptoAuthentication, CryptoCompanion, CryptoController, dsPICDEM, dsPICDEM.net, Dynamic Average Matching, DAM, ECAN, EtherGREEN, In-Circuit Serial Programming, ICSP, Inter-Chip Connectivity, JitterBlocker, KlearNet, KlearNet logo, Mindi, MiWi, motorBench, MPASM, MPF, MPLAB Certified logo, MPLIB, MPLINK, MultiTRAK, NetDetach, Omniscient Code Generation, PICDEM, PICDEM.net, PICTail, PureSilicon, QMatrix, RightTouch logo, REAL ICE, Ripple Blocker, SAM-ICE, Serial Quad I/O, SMART-I.S., SQI, SuperSwitcher, SuperSwitcher II, Total Endurance, TSHARC, USBCheck, VariSense, ViewSpan, WiperLock, Wireless DNA, and ZENA are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

SQTP is a service mark of Microchip Technology Incorporated in the U.S.A.

Silicon Storage Technology is a registered trademark of Microchip Technology Inc. in other countries.

GestIC is a registered trademark of Microchip Technology Germany II GmbH & Co. KG, a subsidiary of Microchip Technology Inc., in other countries.

All other trademarks mentioned herein are property of their respective companies.

© 2017, Microchip Technology Incorporated, Printed in the U.S.A., All Rights Reserved.



ISBN: 978-1-5224-1750-7

## Quality Management System Certified by DNV

---

### ISO/TS 16949

Microchip received ISO/TS-16949:2009 certification for its worldwide headquarters, design and wafer fabrication facilities in Chandler and Tempe, Arizona; Gresham, Oregon and design centers in California and India. The Company's quality system processes and procedures are for its PIC<sup>®</sup> MCUs and dsPIC<sup>®</sup> DSCs, KEELOQ<sup>®</sup> code hopping devices, Serial EEPROMs, microperipherals, nonvolatile memory and analog products. In addition, Microchip's quality system for the design and manufacture of development systems is ISO 9001:2000 certified.

## Worldwide Sales and Service

AMERICAS	ASIA/PACIFIC	ASIA/PACIFIC	EUROPE
<p><b>Corporate Office</b> 2355 West Chandler Blvd. Chandler, AZ 85224-6199 Tel: 480-792-7200 Fax: 480-792-7277 Technical Support: <a href="http://www.microchip.com/support">http://www.microchip.com/support</a> Web Address: <a href="http://www.microchip.com">www.microchip.com</a></p> <p><b>Atlanta</b> Duluth, GA Tel: 678-957-9614 Fax: 678-957-1455</p> <p><b>Austin, TX</b> Tel: 512-257-3370</p> <p><b>Boston</b> Westborough, MA Tel: 774-760-0087 Fax: 774-760-0088</p> <p><b>Chicago</b> Itasca, IL Tel: 630-285-0071 Fax: 630-285-0075</p> <p><b>Dallas</b> Addison, TX Tel: 972-818-7423 Fax: 972-818-2924</p> <p><b>Detroit</b> Novi, MI Tel: 248-848-4000</p> <p><b>Houston, TX</b> Tel: 281-894-5983</p> <p><b>Indianapolis</b> Noblesville, IN Tel: 317-773-8323 Fax: 317-773-5453 Tel: 317-536-2380</p> <p><b>Los Angeles</b> Mission Viejo, CA Tel: 949-462-9523 Fax: 949-462-9608 Tel: 951-273-7800</p> <p><b>Raleigh, NC</b> Tel: 919-844-7510</p> <p><b>New York, NY</b> Tel: 631-435-6000</p> <p><b>San Jose, CA</b> Tel: 408-735-9110 Tel: 408-436-4270</p> <p><b>Canada - Toronto</b> Tel: 905-695-1980 Fax: 905-695-2078</p>	<p><b>Asia Pacific Office</b> Suites 3707-14, 37th Floor Tower 6, The Gateway Harbour City, Kowloon</p> <p><b>Hong Kong</b> Tel: 852-2943-5100 Fax: 852-2401-3431</p> <p><b>Australia - Sydney</b> Tel: 61-2-9868-6733 Fax: 61-2-9868-6755</p> <p><b>China - Beijing</b> Tel: 86-10-8569-7000 Fax: 86-10-8528-2104</p> <p><b>China - Chengdu</b> Tel: 86-28-8665-5511 Fax: 86-28-8665-7889</p> <p><b>China - Chongqing</b> Tel: 86-23-8980-9588 Fax: 86-23-8980-9500</p> <p><b>China - Dongguan</b> Tel: 86-769-8702-9880</p> <p><b>China - Guangzhou</b> Tel: 86-20-8755-8029</p> <p><b>China - Hangzhou</b> Tel: 86-571-8792-8115 Fax: 86-571-8792-8116</p> <p><b>China - Hong Kong SAR</b> Tel: 852-2943-5100 Fax: 852-2401-3431</p> <p><b>China - Nanjing</b> Tel: 86-25-8473-2460 Fax: 86-25-8473-2470</p> <p><b>China - Qingdao</b> Tel: 86-532-8502-7355 Fax: 86-532-8502-7205</p> <p><b>China - Shanghai</b> Tel: 86-21-3326-8000 Fax: 86-21-3326-8021</p> <p><b>China - Shenyang</b> Tel: 86-24-2334-2829 Fax: 86-24-2334-2393</p> <p><b>China - Shenzhen</b> Tel: 86-755-8864-2200 Fax: 86-755-8203-1760</p> <p><b>China - Wuhan</b> Tel: 86-27-5980-5300 Fax: 86-27-5980-5118</p> <p><b>China - Xian</b> Tel: 86-29-8833-7252 Fax: 86-29-8833-7256</p>	<p><b>China - Xiamen</b> Tel: 86-592-2388138 Fax: 86-592-2388130</p> <p><b>China - Zhuhai</b> Tel: 86-756-3210040 Fax: 86-756-3210049</p> <p><b>India - Bangalore</b> Tel: 91-80-3090-4444 Fax: 91-80-3090-4123</p> <p><b>India - New Delhi</b> Tel: 91-11-4160-8631 Fax: 91-11-4160-8632</p> <p><b>India - Pune</b> Tel: 91-20-3019-1500</p> <p><b>Japan - Osaka</b> Tel: 81-6-6152-7160 Fax: 81-6-6152-9310</p> <p><b>Japan - Tokyo</b> Tel: 81-3-6880-3770 Fax: 81-3-6880-3771</p> <p><b>Korea - Daegu</b> Tel: 82-53-744-4301 Fax: 82-53-744-4302</p> <p><b>Korea - Seoul</b> Tel: 82-2-554-7200 Fax: 82-2-558-5932 or 82-2-558-5934</p> <p><b>Malaysia - Kuala Lumpur</b> Tel: 60-3-6201-9857 Fax: 60-3-6201-9859</p> <p><b>Malaysia - Penang</b> Tel: 60-4-227-8870 Fax: 60-4-227-4068</p> <p><b>Philippines - Manila</b> Tel: 63-2-634-9065 Fax: 63-2-634-9069</p> <p><b>Singapore</b> Tel: 65-6334-8870 Fax: 65-6334-8850</p> <p><b>Taiwan - Hsin Chu</b> Tel: 886-3-5778-366 Fax: 886-3-5770-955</p> <p><b>Taiwan - Kaohsiung</b> Tel: 886-7-213-7830</p> <p><b>Taiwan - Taipei</b> Tel: 886-2-2508-8600 Fax: 886-2-2508-0102</p> <p><b>Thailand - Bangkok</b> Tel: 66-2-694-1351 Fax: 66-2-694-1350</p>	<p><b>Austria - Wels</b> Tel: 43-7242-2244-39 Fax: 43-7242-2244-393</p> <p><b>Denmark - Copenhagen</b> Tel: 45-4450-2828 Fax: 45-4485-2829</p> <p><b>Finland - Espoo</b> Tel: 358-9-4520-820</p> <p><b>France - Paris</b> Tel: 33-1-69-53-63-20 Fax: 33-1-69-30-90-79</p> <p><b>France - Saint Cloud</b> Tel: 33-1-30-60-70-00</p> <p><b>Germany - Garching</b> Tel: 49-8931-9700</p> <p><b>Germany - Haan</b> Tel: 49-2129-3766400</p> <p><b>Germany - Heilbronn</b> Tel: 49-7131-67-3636</p> <p><b>Germany - Karlsruhe</b> Tel: 49-721-625370</p> <p><b>Germany - Munich</b> Tel: 49-89-627-144-0 Fax: 49-89-627-144-44</p> <p><b>Germany - Rosenheim</b> Tel: 49-8031-354-560</p> <p><b>Israel - Ra'anana</b> Tel: 972-9-744-7705</p> <p><b>Italy - Milan</b> Tel: 39-0331-742611 Fax: 39-0331-466781</p> <p><b>Italy - Padova</b> Tel: 39-049-7625286</p> <p><b>Netherlands - Druenen</b> Tel: 31-416-690399 Fax: 31-416-690340</p> <p><b>Norway - Trondheim</b> Tel: 47-7289-7561</p> <p><b>Poland - Warsaw</b> Tel: 48-22-3325737</p> <p><b>Romania - Bucharest</b> Tel: 40-21-407-87-50</p> <p><b>Spain - Madrid</b> Tel: 34-91-708-08-90 Fax: 34-91-708-08-91</p> <p><b>Sweden - Gothenburg</b> Tel: 46-31-704-60-40</p> <p><b>Sweden - Stockholm</b> Tel: 46-8-5090-4654</p> <p><b>UK - Wokingham</b> Tel: 44-118-921-5800 Fax: 44-118-921-5820</p>