# PRD-ELEC



# INSECT KILLER Model: PE01138

## IMPORTANT SAFETY INFORMATION

## Please read these instructions carefully before use and retain for future reference.

- When using electrical appliances basic safety precautions should be followed.
- Check that the voltage indicated on the rating plate corresponds with that of the local network before connecting the appliance to the mains power supply.
- High voltage! Do not touch the inner electric grids.
- · Never insert any metal objects inside the grid while it is in operation.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety in a safe way and understands the hazards involved.
- Children should be supervised to ensure that they do not play with the appliance.
- This appliance is not to be used in locations where flammable vapour or explosive dust is likely to exist.
- This appliance is designed for indoor use only.
- The appliance cannot be used in a garage, stable or similar environment.
- This appliance is intended for domestic use only. It should not be used for commercial purposes.
- Do not operate the appliance with a damaged plug or cord, after a malfunction or after being dropped or damaged in any way.
- If the supply cord is damaged, it must be replaced by a qualified engineer in order to avoid injury or hazard.
- Clean the collection tray regularly. It's recommended that you clean the device monthly or more frequently if necessary.

# WHAT'S INCLUDED


- Insect Killer combined with 13A plug.
- User manual.


# HOW IT WORKS

- The Electronic Insect Killer utilises ultra-violet light, which is the most effective lure for light sensitive flying insects, such as flies, moths and mosquitoes.
- The insects are electrocuted by the high voltage inner grid.
- The Electronic Insect Killer involves no chemicals, no sprays, no mess, has no smell and is pollution-free and harmless to humans and pets.

#### MAINTENANCE

If the lamp inside the Insect Killer requires replacing, follow the steps below. **CAUTION:** Ensure the appliance is disconnected from the mains prior to changing the lamp.





Remove the collection tray by squeezing the two recesses on the tray firmly and pulling the tray away. Note: Remove the tray over a rubbish bag to avoid dropping any insects. Release the clips of the lamp cover using a screwdriver. Pull the screwdriver in the direction indicated above.





Pull the connector away from the pin and gently move to one side.



To remove the lamp, hold the end of the lamp and pull it up towards yourself.

- **5.** When fitting a new lamp ensure it is securely fitted with the two pins facing towards you at the base of the appliance and with the pins set parallel to the lines on the base of the Insect Killer (see Fig. 3).
- **6.** Once the lamp is in place reverse the above instructions to re-fit the connector and collection tray.
- **7.** To re-fit the lamp cover simply place it back over the connector and pins, before clipping it back into place.

Note: The connector can be fitted onto any of the two pins.


# CLEANING THE COLLECTION TRAY

The collection tray will require regular cleaning. It is recommended that the tray is emptied and cleaned on a monthly basis or earlier if necessary.

- Ensure the Insect Killer is disconnected from the mains power prior to cleaning.
- To empty the tray, hold the appliance over a rubbish bag before squeezing the two recesses firmly on either side of the collection tray to dislodge it, then pull the tray down and away from the outer mesh.
- Empty the insects into the bag and wipe the tray with a soft, dry cloth if required.
- Once the tray is clean, push it back up onto the Insect Killer, ensuring it clips back into place and is secure.

#### **RELATED PRODUCTS**

When the lamp in this product reaches the end of its life, the recommended replacement is the PRO-ELEC Spare Tube (Model: PE01139).



INFORMATION ON WASTE DISPOSAL FOR CONSUMERS OF ELECTRICAL & ELECTRONIC EQUIPMENT.

When this product has reached the end of its life it must be treated as Waste Electrical & Electronics Equipment (WEEE). Any WEEE marked products must not be mixed with general household waste, but kept separate for the treatment, recovery and recycling of the materials used. Contact your local authority for details of recycling schemes in your area.

Made in China. PR2 9PP Version 1.0