

# PRO-SIGNAL



## 3-Way Speaker Selector Switch PSG08231

Please read these instructions carefully before use and retain for future reference.

### IMPORTANT SAFETY INFORMATION


*When using electrical appliances basic safety precautions should always be followed.*

- To prevent fire or shock hazard, do not expose this product to rain or moisture.
- Beware that listening for long periods and at high volume levels may cause fatigue and hearing damage.

## OVERVIEW

- A compact solution to connect up to 3 pairs of loudspeakers to one audio source.
- NOTE:** standard 8ohm loudspeakers should be used to maintain safe impedance levels for the amplifier.

## CONNECTIONS



- Connect the source equipment loudspeaker output to the Switch spring clip speaker input terminals noting the polarity.
- Connect up to 3 pairs of speakers to the spring clip output terminals noting the polarity. Use terminals A for the most frequently used and least used to terminals C.

## OPERATION

- When the source equipment is outputting a signal, pressing the appropriate button on the front panel directs the output to the chosen loudspeakers.

## SPECIFICATIONS

Rating	100W (rms) per channel
Dimensions (W x H x D)	137 x 46 x 105mm

## CLEANING & MAINTENANCE

- Clean the outside casing with a soft cloth lightly moistened with a mild detergent
- Never use any abrasive or solvents.



INFORMATION ON WASTE DISPOSAL FOR CONSUMERS OF ELECTRICAL & ELECTRONIC EQUIPMENT.

When this product has reached the end of its life it must be treated as Waste Electrical & Electronic Equipment (WEEE). Any WEEE marked products must not be mixed with general household waste, but kept separate for the treatment, recovery and recycling of the materials used. Contact your local authority for details of recycling schemes in your area.



Made in Taiwan PR2 9PP  
Man Rev 1.0