

Color: 🔳 light gray

Electrical data		
Ratings per IEC/EN		
Nominal voltage (III/3)	400 V	
Rated impulse voltage (III/3)	6 kV	
Rated current	25 A	

Physical data	
Width	61.2 mm / 2.409 inches
Jumper assignment	1-2-3-4-5-6-7-8-9-10-11-12
Material data	
Note (material data)	<a href="_blank">Information on material specifications can be found here</a>
Color	light gray
Fire load	0.052 MJ
Weight	6 g
Commercial data	
Product Group	22 (TOPJOB S)
eCl@ss 10.0	27-14-11-40
eCl@ss 9.0	27-14-11-40
ETIM 8.0	EC000489
ETIM 7.0	EC000489
PU (SPU)	25 pcs
Packaging type	Bag

Customs tariff number

Country of origin

GTIN

DE

4055143692366

85366990990

## Data Sheet | Item Number: 2002-482

https://www.wago.com/2002-482

### **Environmental Product Compliance**

**RoHS Compliance Status** 



Compliant,No Exemption

## Approvals / Certificates

Declarations of conformity and manufacturer's declarations



ApprovalStandardCertificate NameRailway<br/>WAGO GmbH & Co. KG-Railway Ready

C	Downloads
E	Environmental Product Compliance
(	Compliance Search
	Environmental Product Compliance 2002-482

Documentation						
Additional Information			Bid Text			
Technical Section	pdf 2142.18 KB	$\downarrow$	2002-482	19.02.2019	xml 2.72 KB	$\downarrow$
			2002-482	27.04.2017	doc 24.00 KB	$\downarrow$

CAD/CAE-Data	
CAD data	CAE data
2D/3D Models 2002-482	EPLAN Data Portal 2002-482
	WSCAD Universe 2002-482

ZUKEN Portal	
2002-482	$\underline{\checkmark}$

## Installation Notes

## Data Sheet | Item Number: 2002-482

https://www.wago.com/2002-482

#### Commoning






Orient the staggered jumpers' red stripes on the inside. Insert the staggered jumper and push down until it hits the backstop. Commoning two potentials in one single jumper slot via extremely slim staggered jumpers.

#### Commoning



Orient the staggered jumpers' red stripes on the inside. Insert the staggered jumper and push down until it hits the backstop.

#### Commoning



Removing a staggered jumper: Insert the operating tool between the staggered jumpers, then lift up the jumper.

#### Commoning



Staggered jumper (seven contacts) Breaking off contact lugs. Individual jumper contacts can be broken off by bending them. The remaining piece of insulation will meet requirements for clearances and creepage distances.



Staggered jumpers Marking with a felt-tip pen.

# Staggering jumpers in a single jumper slot:

Custom staggered jumpers can be created, e.g., for bridging over a terminal block with a different potential. Make sure that only one contact lug is in contact with the terminal block.

The contact lugs of the customized staggered jumpers contact the terminal blocks via the gaps created in the second jumper. Insert and press the ready-made jumper assembly into the jumper slot until it hits the backstop.

Subject to changes. Please also observe the further product documentation!